

LIOB-588 I/O Controller

Installation instructions

Instructions de montage


Montageanweisung


Montagevoorschrift

Istruzioni di montaggio

Instrucciones de montaje

Monteringsanvisning





BUTTONS	
RESET DIAL	Reset Button Turn-and-Push Dial

STATUS LED	
OFF	Unconfigured
GREEN	In Operation
ORANGE	In Manual / overwrite mode
RED	Error
FLASHING	Traffic

CONNECTORS		
Input 24V	1	24 V MINUS or AC
PWR Supply	2	24 V PLUS or AC




Do not connect terminal 2 with ground!

UNIVERSAL INPUT	3	Input UI1
	4	Input GND
	5	Input UI2
	6	Input UI3
	7	Input GND
	8	Input UI4
	9	Input UI5
	10	Input GND
	11	Input UI6


UNIVERSAL INPUT	12	Input UI7
	13	Input GND
	14	Input UI8
	15	Input UI9
	16	Input GND
	17	Input UI10

EXT top row	18T	GND
	19T	B
	20T	A
RS485 bottom row	18B	GND
	19B	+
	20B	-

DIGITAL OUTPUT	21	DO1
	22	DO1
	23	DO2
	24	DO2
	25	DO3
	26	DO3
	27	DO4
	28	DO4
	29	DO5
	30	DO5
	31	DO6
	32	DO6
ANALOG OUTPUT	33	DO7
	34	DO7
	35	DO8
	36	DO8
	37	AO1
	38	GND
ANALOG OUTPUT	39	AO2
	40	AO3
	41	GND
	42	AO4
	43	AO5
	44	GND
	45	AO6




4.5 lb-in/0.5 Nm



Weidmüller


2 poles: BLZP 5.08/02/180
6 poles: BLZP 5.08/06/180
8 poles: BLZP 5.08/08/180
9 poles: BLZP 5.08/09/180

0.2 - 2.5 mm²



6 poles: B2CF 3.50/06/180

0.14 - 1.5 mm²
AWG26-AWG16




DHCP: ON

User: admin


Password: loytec4u

Please update the firmware of the device first, see www.loytec.com/support/download

35 mm x 7.5 mm DIN rail (EN 50022, BS 5584, DIN 46277-3)



installation DIN rail 1.0



label 1.1