

---

# LINX Configurator

For L-INX™ , L-GATE™, L-ROC™, L-IOB™, L-DALI™

## User Manual

LOYTEC electronics GmbH



## Contact

LOYTEC electronics GmbH  
Blumengasse 35  
1170 Vienna  
AUSTRIA/EUROPE  
support@loytec.com  
<http://www.loytec.com>

Version 7.0

Document № 88086706

LOYTEC MAKES AND YOU RECEIVE NO WARRANTIES OR CONDITIONS,  
EXPRESS, IMPLIED, STATUTORY OR IN ANY COMMUNICATION WITH YOU,  
AND

LOYTEC SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF  
MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THIS  
PRODUCT IS NOT DESIGNED OR INTENDED FOR USE IN EQUIPMENT  
INTENDED FOR SURGICAL IMPLANT INTO THE BODY OR OTHER  
APPLICATIONS INTENDED TO SUPPORT OR SUSTAIN LIFE, FOR USE IN FLIGHT  
CONTROL OR ENGINE CONTROL EQUIPMENT WITHIN AN AIRCRAFT, OR FOR  
ANY OTHER APPLICATION IN WHICH IN THE FAILURE OF SUCH PRODUCT  
COULD CREATE A SITUATION IN WHICH PERSONAL INJURY OR DEATH MAY  
OCCUR. LOYTEC MAKES NO REPRESENTATION AND OFFERS NO WARRANTY  
OF ANY KIND REGARDING OF ANY THIRDPARTY COMPONENTS MENTIONED  
IN THIS MANUAL.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted,  
in any form or by any means, electronic, mechanical, photocopying, recording, or  
otherwise, without the prior written permission of LOYTEC.

LC3020™, L-Chip™, L-Core™, L-DALI™, L-GATE™, L-INX™, L-IOB™,  
LIOB-Connect™, LIOB-FT™, L-IP™, LPA™, L-Proxy™, L-Switch™, L-Term™,  
L-VIS™, L-WEB™, L-ZIBI™, ORION™ stack and Smart Auto-Connect™ are  
trademarks of LOYTEC electronics GmbH.

LonTalk®, LONWORKS®, Neuron®, LONMARK®, LonMaker®, *i.LON*®, and LNS® are  
trademarks of Echelon Corporation registered in the United States and other countries.

# Contents

<b>1</b>	<b>Introduction .....</b>	<b>15</b>
1.1	Overview .....	15
1.2	Scope.....	16
1.3	Crash Dumps .....	16
<b>2</b>	<b>Quick-Start Guide .....</b>	<b>17</b>
2.1	Software Installation .....	17
2.2	Getting Started with the LINX Configurator .....	17
<b>3</b>	<b>Concepts .....</b>	<b>19</b>
3.1	<b>Data Points.....</b>	<b>19</b>
3.1.1	Overview.....	19
3.1.2	Timing Parameters .....	19
3.1.3	Default Values .....	20
3.1.4	Persistency .....	20
3.1.5	Parameters.....	21
3.1.6	Behavior on Value Changes.....	22
3.1.7	Custom Scaling .....	23
3.1.8	Protected Data Points .....	23
3.1.9	System Registers .....	23
3.1.10	User Registers .....	25
3.1.11	Structures .....	26
3.1.12	Property Relations.....	26
3.1.13	Convertible Engineering Units.....	28
3.2	<b>Math Objects .....</b>	<b>28</b>
3.2.1	General Properties.....	28
3.2.2	Usage Hints.....	29
3.2.3	Function List .....	29
3.3	<b>Connections.....</b>	<b>31</b>
3.3.1	Local Connections .....	31
3.3.2	Multi-Slot Connections .....	32
3.3.3	Automatic Generation and Templates.....	33
3.3.4	Global Connections.....	34
3.3.5	Forward Delay .....	35
3.4	<b>AST Features .....</b>	<b>35</b>
3.4.1	Alarming .....	35
3.4.2	Historical Alarm Log .....	37
3.4.3	Scheduling .....	37

3.4.4	Trending .....	40
3.4.5	E-mail .....	40
3.4.6	Historic Filters .....	41
<b>3.5</b>	<b>I/O Technology .....</b>	<b>43</b>
3.5.1	I/O Configuration .....	43
3.5.2	STId Card Reader Mode .....	51
3.5.3	I/O Data Points .....	52
3.5.4	Default I/O Configuration .....	55
<b>3.6</b>	<b>CEA-709 Technology .....</b>	<b>55</b>
3.6.1	CEA-709 Device .....	55
3.6.2	CEA-709 Data Points .....	56
3.6.3	Static Interface Changes .....	57
3.6.4	Limitations for Local CEA-709 Schedulers .....	58
3.6.5	Limitations for CEA-709 Alarm Servers .....	58
3.6.6	Limitations for Local CEA-709 Trends .....	58
3.6.7	Dynamic Polling in CEA-709 .....	58
3.6.8	CEA-709 Data Points in Connections .....	59
<b>3.7</b>	<b>BACnet Technology .....</b>	<b>59</b>
3.7.1	BACnet Data Points .....	59
3.7.2	BACnet Alarming .....	60
3.7.3	BACnet Schedulers and Calendars .....	60
3.7.4	BACnet Trend Logs .....	61
3.7.5	Dynamic Polling in BACnet .....	62
3.7.6	BACnet Data Points in Connections .....	62
3.7.7	Native BACnet Objects for I/Os .....	63
<b>3.8</b>	<b>IEC61131 Variables .....</b>	<b>65</b>
<b>3.9</b>	<b>Regular Expressions .....</b>	<b>65</b>
<b>3.10</b>	<b>Scripts .....</b>	<b>67</b>
<b>4</b>	<b>The LINX Configurator .....</b>	<b>68</b>
<b>4.1</b>	<b>Installation .....</b>	<b>68</b>
4.1.1	Software Installation .....	68
4.1.2	Registration as an LNS Plug-In .....	68
4.1.3	CEA-709 Operating Modes .....	70
4.1.4	Language Setting .....	70
<b>4.2</b>	<b>Data Point Manager .....</b>	<b>71</b>
4.2.1	Folder List .....	71
4.2.2	Network Port Folders .....	73
4.2.3	Data Point List .....	73
4.2.4	Property View .....	75
4.2.5	Tracking Data Point Usage .....	77



4.2.6	Managing Multistate Maps .....	78
4.2.7	Organizing Favorites.....	79
4.2.8	Managing Property Relations.....	80
4.2.9	CEA-709 Properties .....	80
4.2.10	BACnet Properties .....	81
<b>4.3</b>	<b>Project Settings.....</b>	<b>82</b>
4.3.1	General.....	83
4.3.2	Data Point Naming Rules.....	85
4.3.3	System Settings.....	86
4.3.4	OPC.....	87
4.3.5	Project Information .....	88
<b>4.4</b>	<b>Using the LINX Configurator .....</b>	<b>88</b>
4.4.1	Starting Stand-Alone.....	88
4.4.2	Uploading the Configuration .....	90
4.4.3	Create User Registers.....	91
4.4.4	Configuration Download .....	92
4.4.5	Upload the System Log.....	93
4.4.6	Backup and Restore .....	94
4.4.7	Create Projects for SI and U.S. Units.....	94
<b>4.5</b>	<b>Connections.....</b>	<b>96</b>
4.5.1	Create a New Connection .....	96
4.5.2	Create Connections from a CSV File.....	99
4.5.3	Modify Connections .....	99
4.5.4	Create a Multi-Slot Connection .....	100
4.5.5	Create a Math Block Adaptor .....	101
4.5.6	Connection Overview .....	103
4.5.7	Create a Global Connection .....	104
4.5.8	Automatic Generation of Connections.....	105
4.5.9	Create an Auto-Generate Template.....	106
4.5.10	Create a Complex Auto-Generate Template .....	107
4.5.11	Managing Connection Resources.....	108
<b>4.6</b>	<b>E-mail Templates .....</b>	<b>109</b>
4.6.1	Create an E-mail Template .....	109
4.6.2	Trigger E-mails.....	110
4.6.3	Attachments .....	111
4.6.4	Limit E-mail Send Rate .....	111
<b>4.7</b>	<b>Local Schedule and Calendar.....</b>	<b>112</b>
4.7.1	Create Calendar Patterns.....	112
4.7.2	Create a Local Scheduler .....	112
4.7.3	Configure Scheduled Data Points .....	113

4.7.4	Configure Scheduled Events .....	114
4.7.5	Configure Exception Days .....	116
4.7.6	Configure Control Data Points .....	117
4.7.7	Using the SNVT_tod_event .....	118
4.7.8	Using the Local Scheduler.....	118
<b>4.8</b>	<b>Local Alarming .....</b>	<b>118</b>
4.8.1	Create an Alarm Server .....	118
4.8.2	Create an Alarm Condition.....	119
4.8.3	Deliver Alarms via E-mail.....	122
4.8.4	Create an Alarm Log .....	123
4.8.5	Multi-Edit Alarm Conditions .....	124
<b>4.9</b>	<b>Local Trending.....</b>	<b>124</b>
4.9.1	Create a Local Trend .....	124
4.9.2	Configure Trended Data Points .....	126
4.9.3	Trend Triggers.....	127
4.9.4	Download Trend Data in CSV Format .....	127
4.9.5	Deliver Trend Data via E-mail .....	128
4.9.6	Technology Trends.....	128
<b>4.10</b>	<b>Remote AST Objects .....</b>	<b>129</b>
4.10.1	Remote Scheduler and Calendar .....	129
4.10.2	Alarm Clients .....	129
4.10.3	Remote Trend Logs .....	130
<b>4.11</b>	<b>Math Objects.....</b>	<b>131</b>
4.11.1	Create a Math Object.....	131
4.11.2	Editing a Math Object .....	132
<b>4.12</b>	<b>Historic Filters .....</b>	<b>133</b>
4.12.1	Create and Remove Historic Filters .....	133
4.12.2	Managing Historic Filter Resources .....	134
<b>4.13</b>	<b>Automated Data Point Handling .....</b>	<b>134</b>
4.13.1	Data Point Modification by Export/Import .....	134
4.13.2	Data Point Creation from CSV .....	135
4.13.3	Data Point Templates .....	136
4.13.4	Creation from Data Point Template CSV .....	136
<b>4.14</b>	<b>Using L-WEB .....</b>	<b>137</b>
4.14.1	Create a new L-WEB Project .....	137
4.14.2	Start a Graphical L-WEB Design .....	138
4.14.3	Organize L-WEB Projects.....	139
<b>4.15</b>	<b>I/Os.....</b>	<b>140</b>
4.15.1	Add L-IOB Modules .....	140
4.15.2	L-IOB Device Settings .....	141

4.15.3 Configure I/Os .....	142
4.15.4 Manage I/O Configurations .....	143
4.15.5 Using I/O Data Points .....	144
4.15.6 Printing Labels .....	145
4.15.7 Run-Hours.....	145
<b>5 CEA-709 .....</b>	<b>147</b>
<b>5.1 Project Settings.....</b>	<b>147</b>
5.1.1 CEA-709 Settings .....	147
5.1.2 CEA-709 Settings for L-DALI Models .....	148
5.1.3 AST Settings .....	149
<b>5.2 CEA-709 Workflow.....</b>	<b>151</b>
5.2.1 Replace a Device .....	151
5.2.2 Adding the Device to LNS.....	151
5.2.3 Replace a Device in LNS .....	154
5.2.4 Workflows for CEA-709.....	157
<b>5.3 CEA-709 Configuration.....</b>	<b>160</b>
5.3.1 Starting as an LNS Plug-In .....	160
5.3.2 Scanning for Network Variables.....	161
5.3.3 Importing Network Variables .....	162
5.3.4 Scanning NVs online from the Network .....	163
5.3.5 Select and Use Network Variables.....	165
5.3.6 Change the NV Allocation.....	166
5.3.7 Create Static NVs.....	166
5.3.8 Create External NVs .....	167
5.3.9 Configuration Download over LNS .....	168
5.3.10 Enable Legacy NM Mode.....	170
5.3.11 Build XIF for Port Interface.....	170
5.3.12 Upload Dynamic NVs from Device .....	170
<b>5.4 Advanced CEA-709 Configuration.....</b>	<b>171</b>
5.4.1 Import Devices from XIF Templates .....	171
5.4.2 Install Unconfigured Devices.....	172
5.4.3 Using Feedback Data Points .....	173
5.4.4 Working with Configuration Properties.....	173
5.4.5 Working with UNVTs, UCPTs.....	175
5.4.6 Configure User-Defined Function Blocks .....	175
5.4.7 Incremental Scans .....	176
<b>6 BACnet .....</b>	<b>177</b>
<b>6.1 Project Settings.....</b>	<b>177</b>
6.1.1 BACnet Settings .....	177

6.1.2	BACnet Settings for L-DALI Models .....	178
<b>6.2</b>	<b>BACnet Workflow .....</b>	<b>179</b>
6.2.1	Involved Configuration Files.....	179
6.2.2	Engineer Online.....	179
6.2.3	Engineer Offline .....	180
<b>6.3</b>	<b>BACnet Configuration .....</b>	<b>181</b>
6.3.1	Scan for BACnet Objects .....	181
6.3.2	Import from EDE or IEIEJ File .....	183
6.3.3	Use Imported BACnet Objects .....	183
6.3.4	Create a Client Mapping.....	184
6.3.5	Create Server Object .....	185
6.3.6	Export Server Objects to an EDE File .....	186
6.3.7	Import Server Objects from an EDE File .....	186
6.3.8	Map other Properties than Present_Value .....	187
6.3.9	Enable International Character Support .....	187
6.3.10	Read the Active Priority .....	188
6.3.11	Write and Read with Priority .....	188
6.3.12	Duplicate BACnet Devices with Data Points .....	189
<b>7</b>	<b>M-Bus .....</b>	<b>191</b>
<b>7.1</b>	<b>Configurator.....</b>	<b>191</b>
7.1.1	Activating M-Bus Configuration.....	191
7.1.2	Data Point Manager for M-Bus .....	191
7.1.3	Folder List .....	192
7.1.4	Network Port Folders .....	193
7.1.5	M-Bus Properties.....	193
7.1.6	M-Bus Device Capabilities.....	194
<b>7.2</b>	<b>M-Bus Workflow .....</b>	<b>194</b>
7.2.1	Offline Engineering .....	194
7.2.2	Online Engineering.....	195
<b>7.3</b>	<b>Using the Configurator for M-Bus .....</b>	<b>195</b>
7.3.1	Automatic Naming .....	195
7.3.2	Scanning the M-Bus Network .....	196
7.3.3	Network Management Functions .....	198
7.3.4	Manual Configuration of Data Points.....	201
7.3.5	Importing via Device Templates .....	203
7.3.6	Creating Device Templates .....	205
7.3.7	Poll Groups.....	207
7.3.8	Trending Synchronized Meter Data .....	209
7.3.9	M-Bus Protocol Analyzer.....	209
7.3.10	Device Replacement.....	211

<b>8 Modbus .....</b>	<b>213</b>
<b>8.1 Configurator .....</b>	<b>213</b>
8.1.1 Activating Modbus Configuration .....	213
8.1.2 Data Point Manager for Modbus.....	214
8.1.3 Folder List.....	214
8.1.4 Network Port Folders.....	215
8.1.5 Modbus Properties .....	215
8.1.6 Modbus Workflow .....	215
<b>8.2 Using the Configurator for Modbus .....</b>	<b>216</b>
8.2.1 Modbus Management Functions.....	216
8.2.2 Manual Configuration of Data Points .....	220
8.2.3 Data Point Creation with Online Test .....	222
8.2.4 Importing via Device Templates.....	224
8.2.5 Creating Device Templates .....	225
8.2.6 Poll Groups .....	226
8.2.7 Create Modbus Slave Data Points.....	228
8.2.8 Structured Modbus Data Points .....	229
8.2.9 Modbus Protocol Analyzer .....	230
<b>9 KNX .....</b>	<b>232</b>
<b>9.1 Configurator .....</b>	<b>232</b>
9.1.1 Activating KNX Configuration.....	232
9.1.2 KNX Project Settings.....	233
9.1.3 Data Point Manager for KNX .....	235
9.1.4 Folder List.....	235
9.1.5 Network Port Folders.....	235
9.1.6 KNX Properties.....	236
<b>9.2 KNX Workflow.....</b>	<b>236</b>
9.2.1 Selecting a KNX Interface .....	237
9.2.2 Reserve a Physical Address .....	237
9.2.3 Coupler Configuration .....	237
9.2.4 Use KNX Data Types in IEC61131 .....	238
9.2.5 Setup a Configurator Project.....	239
9.2.6 ETS Project Export .....	240
9.2.7 Configurator Project Import.....	240
9.2.8 Creating Data Points .....	242
9.2.9 Editing KNX Data Points.....	243
9.2.10 Alarming, Scheduling and Trending .....	243
<b>10 SMI.....</b>	<b>244</b>
<b>10.1 Configurator .....</b>	<b>244</b>

10.1.1	Activating SMI .....	244
10.1.2	Data Point Manager for SMI .....	244
10.1.3	Port Folder .....	245
<b>10.2</b>	<b>SMI Workflow .....</b>	<b>247</b>
10.2.1	Creating SMI Devices from Device Templates .....	247
10.2.2	Commission SMI Devices .....	248
10.2.3	Organize SMI Devices .....	248
10.2.4	Using Power-On Data Points .....	249
<b>11</b>	<b>EnOcean .....</b>	<b>250</b>
<b>11.1</b>	<b>Configurator .....</b>	<b>250</b>
11.1.1	Activating EnOcean .....	250
11.1.2	Data Point Manager for EnOcean .....	251
11.1.3	Port Folder .....	251
<b>11.2</b>	<b>EnOcean Workflow .....</b>	<b>251</b>
11.2.1	Creating EnOcean Devices from Device Templates .....	251
11.2.2	Edit EnOcean Data Points .....	252
11.2.3	Alarming, Scheduling and Trending .....	252
11.2.4	Teach-In EnOcean Devices .....	252
11.2.5	Organize EnOcean Devices .....	253
<b>12</b>	<b>MP-Bus .....</b>	<b>254</b>
<b>12.1</b>	<b>Configurator .....</b>	<b>254</b>
12.1.1	Activating MP-Bus .....	254
12.1.2	Data Point Manager for MP-Bus .....	255
12.1.3	Port Folder .....	255
<b>12.2</b>	<b>MP-Bus Workflow .....</b>	<b>255</b>
12.2.1	Creating MP-Bus Devices from Device Templates .....	255
12.2.2	Edit MP-Bus Data Points .....	256
12.2.3	Alarming, Trending and Scheduling .....	256
12.2.4	Commission MP-Bus Devices .....	256
12.2.5	Organize MP-Bus Devices .....	257
<b>13</b>	<b>OPC Client .....</b>	<b>258</b>
<b>13.1</b>	<b>Configurator .....</b>	<b>258</b>
13.1.1	Port Folder .....	258
13.1.2	Data Point Properties .....	258
13.1.3	OPC Device Manager .....	258
<b>13.2</b>	<b>OPC Client Workflow .....</b>	<b>260</b>
13.2.1	Integrate Devices via OPC .....	260
13.2.2	Integrate Sub-Trees and Relocate .....	261
<b>14</b>	<b>ekey .....</b>	<b>262</b>

<b>14.1</b>	<b>Configurator .....</b>	<b>262</b>
14.1.1	Activating ekey .....	262
14.1.2	Data Point Manager for ekey .....	262
14.1.3	Port Folder .....	263
<b>14.2</b>	<b>ekey Workflow.....</b>	<b>264</b>
14.2.1	Create From Device Templates.....	264
14.2.2	Enroll Fingerprint Readers.....	264
14.2.3	Enroll Users and Fingers.....	265
<b>15</b>	<b>DALI .....</b>	<b>267</b>
<b>15.1</b>	<b>Non-programmable Models .....</b>	<b>267</b>
15.1.1	Configurator.....	267
15.1.2	DALI Workflow .....	286
<b>15.2</b>	<b>Programmable Models.....</b>	<b>290</b>
15.2.1	Configurator.....	290
15.2.2	DALI Workflow .....	291
<b>16</b>	<b>Script Engine.....</b>	<b>296</b>
<b>16.1</b>	<b>Overview .....</b>	<b>296</b>
<b>16.2</b>	<b>Script Resources .....</b>	<b>297</b>
<b>16.3</b>	<b>Script Objects .....</b>	<b>299</b>
<b>16.4</b>	<b>Developing Scripts.....</b>	<b>300</b>
16.4.1	Data Point Integration .....	300
16.4.2	Using Libraries .....	301
16.4.3	Write a Script Object Resource.....	302
16.4.4	Serial Port .....	303
16.4.5	Open Ports in the Firewall .....	304
16.4.6	Prototyping .....	304
16.4.7	Debugging.....	305
<b>16.5</b>	<b>Prototyping on the PC .....</b>	<b>306</b>
16.5.1	Set up a Project .....	306
16.5.2	Setting up an Attach Configuration in Visual Studio Code .....	307
<b>17</b>	<b>File Formats .....</b>	<b>309</b>
<b>17.1</b>	<b>Data Point CSV File.....</b>	<b>309</b>
<b>17.2</b>	<b>CEA-709 NV Import File.....</b>	<b>310</b>
<b>17.3</b>	<b>Terminal Configuration File .....</b>	<b>312</b>
<b>18</b>	<b>Application Notes.....</b>	<b>313</b>
<b>18.1</b>	<b>The LSD Tool .....</b>	<b>313</b>
<b>18.2</b>	<b>Use of Static, Dynamic, and External NVs on a Device .....</b>	<b>313</b>
<b>19</b>	<b>References .....</b>	<b>314</b>
<b>20</b>	<b>Revision History.....</b>	<b>315</b>





## Abbreviations

100Base-T .....	100 Mbps Ethernet network with RJ-45 plug
Aggregation.....	Collection of several CEA-709 packets into a single CEA-852 packet
AST.....	Alarming, Scheduling, Trending
BACnet .....	Building Automation and Control Network
BBMD.....	BACnet Broadcast Management Device
BDT .....	Broadcast Distribution Table
BOOTP .....	Bootstrap Protocol, RFC 1497
CA.....	Certification Authority
CEA-709 .....	Protocol standard for LONWORKS networks
CEA-852.....	Protocol standard for tunneling CEA-709 packets over IP channels
CN.....	Control Network
COV .....	change-of-value
CR.....	Channel Routing
CS.....	Configuration Server that manages CEA-852 IP devices
DA.....	Data Access (Web service)
DHCP.....	Dynamic Host Configuration Protocol, RFC 2131, RFC 2132
DIF, DIFE .....	Data Information Field, Data Information Field Extension
DL .....	Data Logger (Web service)
DNS .....	Domain Name Server, RFC 1034
DST.....	Daylight Saving Time
EEP .....	EnOcean Equipment Profile
GMT.....	Greenwich Mean Time
IP.....	Internet Protocol
IP-852.....	logical IP channel that tunnels CEA-709 packets according CEA-852
LAN .....	Local Area Network
LSD Tool .....	LOYTEC System Diagnostics Tool
MAC .....	Media Access Control
MD5 .....	Message Digest 5, a secure hash function, see Internet RFC 1321
M-Bus .....	Meter-Bus (Standards EN 13757-2, EN 13757-3)
MIB.....	Management Information Base
MS/TP.....	Master/Slave Token Passing (this is a BACnet data link layer)
NAT .....	Network Address Translation, see Internet RFC 1631
npm .....	Node Package Manager (see <a href="http://www.npmjs.com">www.npmjs.com</a> )
NV.....	Network Variable
OPC.....	Open Process Control
OPC UA .....	OPC Unified Architecture
PEM .....	Privacy Enhanced Mail
PLC .....	Programmable Logic Controller
RNI.....	Remote Network Interface
RSTP.....	Rapid Spanning Tree Protocol (Standard IEEE 802.1D-2004)
RTT .....	Round-Trip Time
RTU .....	Remote Terminal Unit

SCPT .....	Standard Configuration Property Type
SSH.....	Secure Shell
SL .....	Send List
SMTP .....	Simple Mail Transfer Protocol
SNMP .....	Simple Network Management Protocol
SNTP .....	Simple Network Time Protocol
SSL .....	Secure Socket Layer
STP .....	Spanning Tree Protocol (Standard IEEE 802.1D)
TLS.....	Transport Layer Security
UCPT.....	User-defined Configuration Property Type
UI.....	User Interface
UNVT.....	User-defined Network Variable Type
UTC .....	Universal Time Coordinated
VIF, VIFE.....	Value Information Field, Value Information Field Extension
VPN.....	Virtual Private Network
WLAN.....	Wireless LAN
XML .....	eXtensible Markup Language

# 1 Introduction

---

## 1.1 Overview

The LINX Configurator is the configuration software used for the L-INX, L-GATE, L-ROC, L-IOB, and L-DALI products. These products contain a number of components and network technologies, such as the protocols BACnet, CEA-709, KNX, Modbus, M-Bus, MP-Bus, SMI, EnOcean, DALI, ekey.

Data from the supported network technologies are available as data points in the automation server. Those data points are freely configurable via the configuration software, which provides a fast and easy way to configure a LOYTEC device using online network scans, import/export features or device templates. Data points between different network technologies can be connected to each other for data transfer between those network technologies (gateway). Data points are also subject to alarming, trending and scheduling (AST) functions of the automation server. The usage of math objects allows basic calculations and the built-in E-mail client allows the LOYTEC device to transmit e-mails on certain conditions. Generated alarms can be configured to send e-mails to predefined addresses. Alarms can also be stored in a historical *alarm log*. Trended data collected by the device and is available in CSV format and through a dedicated Web service.

Only the L-INX and L-IOB Controller family contains a freely programmable controller that can operate on all data points. The controller application is developed using the provided IEC-61131 compliant design tool. The L-ROC family also contains a freely programmable controller, which is developed under L-STUDIO following IEC-61499. The L-DALI family is designed for lighting applications and has a built-in constant light controller.

The LINX Configurator is used for:

- Offline configuration of a L-INX, L-GATE, L-ROC, L-IOB, L-DALI device
- Data point configuration
- I/O configuration
- Alarming, trending, scheduling, E-Mail configuration
- Generating local connections for gateway functions
- Auto-connecting from one technology to another
- Math object configuration for advanced transformations
- L-WEB visualization project management and configuration
- Online device operations, such configuration download, network scans, backup/restore.

## 1.2 Scope

This document covers the LINX Configurator with version 7.0 and how it is used to configure a LOYTEC device. The device setup itself and its operation on the Web interface is not the scope of this manual and covered in the respective LOYTEC Device User Manual.

---

## 1.3 Crash Dumps

The LINX Configurator is able to send crash dumps to LOYTEC in order to improve software quality. It does not do so automatically but provides a convenient way to send the crash dump by E-Mail. The crash dump data contains a screenshot, the current data point configuration and a memory dump of the LINX Configurator process. The user can control the contents of the crash dump before submission. By allowing E-Mail submission the user agrees that the data is used by LOYTEC to solve a particular software problem. The data is not stored or used for any other purpose.

## 2 Quick-Start Guide

This chapter shows step-by-step instructions on how to set up the LINX Configurator and get ready to configure a LOYTEC device.

---

### 2.1 Software Installation

The LINX Configurator must be used to setup the data point configuration of the LOYTEC device. The Configurator is installed as a plug-in tool for all LNS-based network management tools as well as a stand-alone tool (for systems without LNS).

System requirements:

- LNS 3.1 SP8 U1, LNS 3.2 TE SP5, OpenLNS (for LNS mode),
- Windows 7, Windows 8, Windows 10 or Windows Server 2003 (32 bit), Windows Server 2008, Windows Server 2012, Windows Server 2016,
- Internet Explorer 10 or higher.

The LINX Configurator can be downloaded from the LOYTEC Web site <http://www.loytec.com>. When asked for the type of installation, there are two options to choose from. Select **Typical** to install the required program files. Select **Full** to install the LONMARK resource files along with the software. This option is useful, when the system does not have the newest resource files.

---

### 2.2 Getting Started with the LINX Configurator

Before setting up a gateway, a working IEC61131 program or creating an L-WEB visualization, the data points of the LOYTEC device need to be set up. These can be data points of L-IOB I/Os, network variables, BACnet objects, and other available technologies. LINX Configurator

#### To Start a Configurator Project

1. Start the LINX Configurator software by selecting Windows **Start → Programs → LOYTEC LINX Configurator → LOYTEC LINX Configurator**. The application starts up and displays the data point manager screen as shown in Figure 1.
2. When the device is online, connect to the device by clicking on the **Connect to device** speed button as indicated by the red rectangle in Figure 1.




Figure 1: LINX Configurator main screen.

3. For detailed information on how to create data points out of the network please refer to Section 5.3 for CEA-709 or 6.3 for BACnet.

# 3 Concepts

---

## 3.1 Data Points

### 3.1.1 Overview

Data points are part of the fundamental device concept to model process data. A data point is the basic input/output element on the device. Each data point has a value, a data type, a direction, and a set of meta-data describing the value in a semantic context. Each data point also has a name and a description. The entire set of data points is organized in a hierarchy using a folder structure. Folders can be created as needed and have a folder name and description.

At the data point level, the specific technological restrictions are abstracted and hidden from the user. Working with different technologies at this level involves common work-flows for all supported technologies.

The direction of a data point is defined as the “network view” of the data flow. This means, an input data point obtains data from the network. An output data point sends data to the network. This is an important convention to remember as different technologies may define other direction semantics. If a data point can both receive and send data on the network, its direction is set to value, indicating no explicit network data flow.

The basic classes of data points are:

- **Analog:** An *analog* data point typically represents a scalar value. The associated data type is a *double precision* machine variable. Meta-data for analog data points include information such as value range, engineering units (SI and U.S.), precision, and resolution.
- **Binary:** A *binary* data point contains a Boolean value. Meta-data for binary data points includes human-readable labels for the Boolean states (i.e., active and inactive texts).
- **Multi-state:** A *multi-state* data point represents a discrete set of states. The associated data type is a signed integer machine variable. Each state is identified by an integer value, the *state ID*. State IDs need not be consecutive. Meta-data of a multi-state data point includes human-readable descriptions for the individual states (state texts) and the number of available states.
- **String:** A *string* data point contains a variable-length string. The associated data type is a character string. International character sets are encoded in UTF-8. A string data point does not include any other meta-data.
- **User:** A *user* data points contains un-interpreted, user-defined data. The data is stored as a byte array. A user data point does not include any other meta-data. This type of data point also serves as a container for otherwise structured data points and represents the entirety of the structure.

### 3.1.2 Timing Parameters

Apart from the meta-data, data points can be configured with a number of timing parameters. The following properties are available to input or output data points, respectively:

- **Pollcycle** (input, value): The value is given in seconds, which specifies that this data point periodically polls data from the source. This is referred to as static polling.
- **Receive Timeout** (input, value): This is a variation on the poll cycle. When receive timeout is enabled, the data point must receive a value update within the receive timeout period. If it does not receive a value, a technology may actively poll the source. If no value has been received after another period, the data point is set offline and triggers a fault alarm, if configured. Writing data from any source (network technology, connection, logic program) the receive timeout is reset.
- **Poll-on-startup** (input, value): If this flag is set, the data point polls the value from the source when the system starts up. Once the value has been read, no further polls are sent unless a poll cycle has been defined.
- **Minimum Send Time** (output): This is the minimum time that elapses between two consecutive updates. If updates are requested more often, they are postponed and the last value is eventually transmitted after the minimum send time. Use this setting to limit the update rate.
- **Maximum Send Time** (output): This is the maximum time without sending an update. If no updates are requested, the last value is transmitted again after the maximum send time. Use this setting to enable a heart-beat feature.

Dynamic polling is a feature that some network technologies offer. With static polling the pollcycle is used to permanently poll values over the network. This is required for data points that require constant value updates a fixed pollcycle (for example to trend the data). For other data points that do not need permanent value updates, so-called dynamic polling is activated, as soon as the values are needed (for example displayed on the data point Web UI or in L-WEB). If dynamic polling is active, the data points are polled using the configured pollcycle. When the data is no longer needed, polling stops and no longer puts a burden on the network. The advantage is that a few data points can be refreshed at a higher rate at a time compared to static polling, where all data points must permanently share the available network bandwidth.

Background polling can be enabled in the project settings. With this feature enabled, all input data points, which rely on polling depending on the underlying network technology, are polled one-by-one in a round-robin fashion. This happens even if no pollcycle is set or dynamic polling is activated on those data points. The frequency of the background polling can be defined in the project settings. The default is 60 polls per minute.

### 3.1.3 Default Values

Default values can be defined for data points when needed. The value of a data point will be set to the defined default value, if no other value source initializes the data point. Default values are beneficial, if certain input data points are not used by the network and need a pre-defined value, e.g., for calculations. Default values are overridden by persistent values or values determined by poll-on-startup.

### 3.1.4 Persistency

Data point values are by default not persistent. This means that their value is lost after a power-on reset. There exist different strategies for initializing data points with an appropriate value after the device has started.

For input data points, the value can be actively polled from the network when starting up. Use the Poll-on-Startup feature for this behavior. Polling the network values has the advantage that intermediate changes on the network are reflected. An input data point can be made persistent, if the last received value shall be available after a power-on reset before a poll-on-startup completes. This can be beneficial, if the remote device is temporarily offline and the last value is considered usable.

For output data points, the value can be restored after starting up by the application. For example, if the output data point's value is determined by an input data point and a math



object, or the output data point is in a connection with an input, the input can poll its value on startup. If the output data point has no specific other value source, e.g., it is a configuration parameter set by the user, it can be made *persistent*.

To make a data point persistent, enable the Persistent property of the respective data point. The persistency option is only available for the base data point classes analog, binary, multi-state, string and user. More complex objects such as calendars, schedules, etc., have their own data persistency rules. Persistency is also available for unlinked favorites.

For structured data points, only all or none of the structure members can be made persistent. The configuration of the top-level data point, which represents the entire structure, serves as a master switch. Setting the top-level data point to be persistent enables persistency for all sub-data points. Clearing it disables persistency for all sub-data points.

### 3.1.5 Parameters

A data point can be qualified as a *parameter* data point. This is accomplished in the Configurator software by setting a **Parameter** check box on the data point. Those parameter data points are automatically persistent and will typically have a default value. Their purpose is to store parameterization values, which can be changed from the default value at run time and influence the behavior of the device or the logic running on the device. This way, a number of devices can have the same basic configuration and be adapted by parameter values. Examples are sunblind run times for control logic or descriptive strings for the L-WEB visualization.

The qualified parameter data points are also exported via a parameter file, which contains the entire set of current parameter values including meta-information for external tools to display parameter data in a human-readable way. The LWEB-900 parameter view can process such parameter data points and manage them for a large number of devices. For more information on how to manage parameters on your devices please refer to the LWEB-900 manual [5].

When changing parameters on the device or via the LWEB-900 parameter view, they are out of sync with their default values in the configuration. As a default it assumed that parameters are managed by LWEB-900 and the Configurator does not download and overwrite parameter values to the device.

The project settings can be changed to have the Configurator manage parameters (see Section Figure 2). In this mode the Configurator provides a mechanism to resolve value conflicts and to merge changed parameters back into the configuration. This is accomplished in the parameter merge dialog when uploading or downloading the configuration (see Figure 2). The user can select a resolution in the drop-down box. The arrow indicates in which direction the parameter values shall be copied: Copy value from device to default value, write default value to the device or NONE to leave configuration and value on device separate.




Figure 2: Parameter merge dialog.

When selecting a resolution on single parameters it affects only those parameters. When selecting a resolution on a folder it affects all data points under this folder. Click on **Ignore** to skip the parameter merge process.

L-IOB parameters are not managed by LWEB-900 and the Configurator always tries to merge L-IOB parameters that have been changed on the device. Frequent changes made to manual/auto mode can be ignored by checking **Always ignore L-IOB manual/auto mode differences**.

When creating a new configuration, the Configurator assigns a new project ID. This is a GUID-style ID which uniquely identifies a data point configuration. When the project ID changes, the LOYTEC device clears all persistent values and accepts the default values of the new configuration. Refer to Section 4.3.1 that describes the project ID in the project settings.

### 3.1.6 Behavior on Value Changes

The value of a data point can change, if it is written by the application or over the network. For all data points (input, output and value) the application (connection, user control, etc.) can be notified, when the value is written to. The property **Notify on any COV** defines, whether the notification is done with each write or only if the value changes (change-of-value, COV). If notify on any COV is disabled, writing the same value multiple times will result in multiple notifications.

When the value of an output data point is updated, an update is usually sent out onto the network. The property **Send-On-Delta** decides how the update is reflected on the network. If send-on-delta is inactive, each update of the value is sent, even if the value does not change. If send-on-delta is active, only value changes are sent. The send-on-delta property is only valid for output data points.

For analog data points, the COV or send-on-delta takes an extra argument, which specifies by what amount the value must change to regard it as a change for action. Both, COV and send-on-delta for analog data points check the **Analog Point COV Increment** property. A change is detected, if the value increment is bigger or equal to the specified increment. If the property is '0.0', all updates are reported, even if the value does not change. The **Notify on any COV** property modifies this behavior to detecting any change, regardless of the COV increment.

Data point usages, such as COV trend logs or math objects may specify their own COV deltas on analog data points. These can be bigger than the data point COV itself, but never smaller.

### 3.1.7 Custom Scaling

Custom scaling is applied to all analog data points when they communicate values to or from the network. This feature can be used, if a network data point has engineering units not suitable for the application (e.g., grams instead of kilograms). The scaling is linear and applied in the direction from the network to the application as:

$$A = k N + d,$$

where  $N$  is the network value,  $k$  the *custom scaling factor*,  $d$  the *custom scaling offset*, and  $A$  the application value. When sending a value to the network, the reverse scaling is applied. If this property is enabled, the analog values are pre-scaled from the technology to the data point. The custom scaling is in addition to any technology-specific scaling factors and can be applied regardless of the network technology.

### 3.1.8 Protected Data Points

Some data points are created automatically depending on the model currently selected. They are protected against manipulation by the user. Therefore they cannot be deleted or moved and their properties cannot be modified. System registers (see Section 3.1.9) fall into this category. In addition some models (e.g. L-DALI) come with a predefined interface which cannot be changed either.

### 3.1.9 System Registers

The device provides a number of built-in system registers. They are present without a data point configuration. The system registers, such as the System time or the CPU load, can be exposed to the OPC server. By default, all system registers are checked for being exposed to OPC. To reduce the number of needed OPC tags, you may deselect certain system registers, which are not useful in a specific project.

System registers are read-only by default. System register can also serve as a testing setup for the OPC XML-DA communication without a network data point configuration. The *System Time* register is updated every second and may serve for testing subscriptions. The *Authentication Code* register can be used to verify writing to OPC tags.

The available system registers and a short description of their function are listed below:

- **State Summary:** This multi-state register contains one of the following values:
  - **OK** (1): The device is in normal state. All modules are running without problems.
  - **WARNING** (2): Some modules on the device reported a warning. The device may not function as expected.
  - **ERROR** (3): Some modules on the device reported an error. The device is not functioning as expected.
- **System Time:** This register is an *analog* data point. It supplies the system time of the local clock in UTC as seconds since 1.1.1970. It increments each second. Example: 1302533716.
- **Time UTC:** This register is a structured data point. It supplies the system time as UTC broken down to year, month, day, hour, minutes and seconds.
- **Time Local:** This register is a structured data point. It supplies the system time as local time broken down to year, month, day, hour, minutes and seconds.
- **Unit System:** This register shows the unit system the device is currently running on. It can be either metric (SI) or U.S.
- **Unit System Set:** This register can be written to. It can request a change to another unit system. When changing it, the device needs to be rebooted to let this change become

effective. This can be done via the **Command** system register or any other reboot mechanism.

- **CPU Load:** This register is an *analog* data point. It displays the average system CPU load in percent over the last minute. Example: 17 %.
- **Free Memory:** This register is an *analog* data point. It displays the current amount of free RAM memory in Bytes. Example: 20522288 Bytes.
- **Free Flash:** This register is an *analog* data point. It displays the current amount of free memory in Bytes of the Flash storage. Example: 8482688 Bytes.
- **Supply Voltage:** This register is an *analog* data point. It displays the currently measured supply voltage in volts. Example: 15.1 V. Note, that for AC powered devices the voltage reading is  $VAC * \sqrt{2}$ , e.g., 24VAC reads as 34V.
- **System Temp:** This register is an *analog* data point. It displays the currently measured system temperature in degrees Celsius. Example: 39 °C.
- **Application Vendor, Authentication Code, and Authentication Result:** These registers can be used to implement an IP protection mechanism for application programs, such as IEC61131 programs.
- **Serial Number:** This register is a *string* data point. It displays the device's serial number as an ASCII string. Example: "011401-000AB001D1E4".
- **MAC Address:** This register is a *user* data point. It displays the device's MAC address as an array of 6 hexadecimal Bytes. Example: 000AB001D1E4.
- **Firmware Version:** This register is a *string* data point. It displays the device's firmware version as an ASCII string. Example: "4.1.0".
- **Device IP Address:** This register is a *string* data point. It displays the device's IP address as an ASCII string. Example: "10.101.18.204".
- **Device IP Port:** This register is an *analog* data point. It displays device's HTTP port as an integer value. Example: 80.
- **TZ Offset:** This register is an *analog* data point. It displays the time zone offset relative to UTC in seconds. This means a positive value for a time zone, which lies east of Greenwich. The offset includes daylight savings time. The local time can be derived by adding this register to the system time register. Example: +7200 for GMT+1 (Paris, Berlin, Vienna) including DST.
- **Device Status:** This register is a *string* data point. It contains an XML document with the device status file contents. It is not displayed on the Web UI.
- **Ethernet Link Mask:** This register is a *multistate* data point. It displays the link information of the Ethernet port. Example: "Eth 1".
- **Hostname:** This register is a *string* data point. It displays the host name, which has been configured in the IP settings. Example: "my\_linx".
- **Position Longitude:** This register is an *analog* data point. It displays the longitude part of the device's location in degrees. Writing to the corresponding data point **Position Longitude\_Set** sets the device's longitude in degrees. Example: -16.33472.
- **Position Latitude:** This register is an *analog* data point. It displays the latitude part of the device's location in degrees. Writing to the corresponding data point **Position Latitude\_Set** sets the device's latitude in degrees. Example: 48.22056.
- **Position Altitude:** This register is an *analog* data point. It displays the altitude of the device's location in meters above sea level. Writing to the corresponding data point **Position Altitude\_Set** sets the device's altitude in meters above sea level. Example: 200 m.
- **Sun Azimuth, Sun Elevation:** These registers represent the sun position depending on the current day time and geographical location. The registers are updated once a minute.

- **Secure Mode:** On models providing a firewall, this binary register enable the firewall to restrict access to the services provided in the **Secure Services** register.
- **Secure Services:** On models providing a firewall, this string register selects the services which should be available when **Secure Mode** is **TRUE**. This registers accepts a space-separated list of service names. If the selected services would make the device unconfigurable, a default configuration with HTTPS and SSH enabled is selected. The available service names are:
  - **HTTP:** Enables access to the configuration pages via HTTP.
  - **HTTPS:** Enables access to the configuration pages via HTTPS.
  - **SSH:** Enables access to the SSH server.
  - **OPC:** Enables access to the OPC XML-DA server.
  - **OPCUA:** Enables access to the OPC UA server.
  - **ICMP:** Allows incoming ICMP packets (recommended).
- **Command:** This multi-state register can be written to any value other than None to execute the selected command:
  - **None (1):** No command is executed. This is the default value.
  - **Warm Reboot (2):** The device immediately performs a warm reboot.
  - **Cold Reboot (3):** The device immediately performs a cold reboot.
  - **Save Parameters (4):** Pending parameter changes are committed to Flash memory.
  - **Reset Parameters (5):** All persistent values are reset to their default values. The device reboots immediately after writing this command.

### 3.1.10 User Registers

The device can be configured to contain user registers. In contrast to system registers, these are only available as a part of the data point configuration. User registers are data points on the device that do not have a specific technological representation on the control network. Thus, they are not accessible over a specific control network technology.

A register merely serves as a container for intermediate data (e.g., results of math objects, calculation parameters). The register can have the following, basic data types:

- **Double:** A register of base type *double* is represented by an *analog* data point. It can hold any scalar value. No specific scaling factors apply.
- **Signed Integer:** A register of base type *signed integer* is represented by a *multi-state* data point. This register can hold a set of discrete states, each identified by a signed stats ID.
- **Boolean:** A register of base type *Boolean* is represented by a *binary* data point. This register can hold a Boolean value.
- **String:** A register of base type *string* is represented by a *string* data point. This register can hold a variable-length character string in UTF-8 format.
- **Variant:** A register of base type *variant* is represented by a *user* data point. This register can hold any user-defined data of up to a specified length of Bytes. This length is defined when creating the register and cannot be changed at run time.

Since a register has no network direction, it can be written and read. Therefore, it is created as a value data point by default. It is also possible to create two data points for each register, one for writing the register (output) and one for reading the register (input). In this case a suffix is added to the register name to identify the respective data point. For example, the register *MyValue* will have two data points generated for: *MyValue\_Read* and *MyValue\_Write*.

### 3.1.11 Structures

Complex data belonging semantically together may be structured. The data point model allows mapping structure types onto user-defined data points of *variant* type. This can be necessary, if a network technology carries such structured data or if a user-defined register shall provide structured data for access through a single data point. In any case, the structure is modeled as a top-level data point and a hierarchy of sub-data points representing the structure members.

The top-level data point is a user data point of variant data type. It contains the image of the entire structure as a Byte array. Each structure field is then modeled as a sub-data point of the appropriate class (e.g. analog, binary, or multi-state). A structure field may itself be a structure going down one level in the hierarchy of sub-data points.

An example is shown in Figure 3. In this case a user register of two Bytes is bound to a structure type mapping the two bytes on analog data points. The two sub-data points *byte\_0* and *byte\_1*.

example2_Read	1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	In
byte_0	1.1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	In
byte_1	1.2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	In


Figure 3: Example of a structured data point.

The structure types are available in a type repository with the Configurator. This repository is divided into scopes. Within each scope a type has a unique name. When selecting a type, the scope and the type name needs to be specified.

Favorites can also be structured. A structured favorite can be created by dragging a structured data point into the favorites folder. As a default, the structure top is linked to the structure top of the target data point while all sub-element are linked to their respective target sub-elements. It is also possible to unlink the structure top and link its sub-elements to different individual data points. When entirely unlinked, the structured favorite behaves like a structured user register.

### 3.1.12 Property Relations

A data point possesses a number of properties, which influence the behavior and appearance of the data point. Examples are data point name, poll cycle or alarm limits. Most of those properties are determined by the configuration and are static during operation of the device. Some of those properties, however, shall get a default value from the configuration and be modified during run-time. Modification may be carried out by the user by setting the property value over the Web UI, by L-WEB over the Web service or by a PLC program.

In some cases property values shall also be updated by other data points, e.g. a user register or a technology data point. In this case the data point property is linked to another data point following a given, semantic relation. This is modeled as a *property relation*. Property relations appear as data point links with the respective property names underneath their governing data point. An example is shown in Figure 4. They are marked with a link symbol . When hovering with the mouse over the link symbol, a bubble help appears describing the property relation.

reg_bool_fb_alarm_Read	7	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	
feedbackValue -> User Registers.master_feedback_Read	7.1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	
enableAlarm	7.2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Value	
inAlarm	7.3	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Value	

Figure 4: Example of property relations.

The property relations can be accessed like regular sub-data points from the Web UI, by L-WEB over the OPC web service or by a PLC program. For this usage, no linkage against

other data points is necessary. Property relations may, however, also be linked to other data points, e.g. 'feedbackValue' in Figure 4. In this case the linked data point is used as the related property. The user may right-click on a linked property relation and choose **Go to related data point** from the context menu. For mass engineering property relation links to other data points refer to Section 4.2.8.

The following properties are available as property relations:

- **feedbackValue:** This property relation is used for feedback alarm conditions. The data point value is compared against the feedback value. An alarm is generated, if these values differ (by a certain amount). It exists only, if an alarm condition has been created.
- **enableAlarm:** This property relation is used to enable or disable alarm generation on the data point. It exists only, if an alarm condition has been created.
- **inAlarm:** This property relation is TRUE, if the data point is in an alarm. It exists only, if an alarm condition has been created.
- **ackPend:** This property relation is TRUE, if the data point's alarm needs acknowledgement. It exists only, if an alarm condition has been created.
- **highLimit:** This property relation defines the high limit for analog alarms. It exists only, if an alarm condition has been created.
- **lowLimit:** This property relation defines the low limit for analog alarms. It exists only, if an alarm condition has been created.
- **deadband:** This property relation defines the dead band for analog alarms. It exists only, if an alarm condition has been created.
- **msgNormal, msgOffnormal, msgFault:** These property relations define the alarm message for the respective alarm transition. They exist only, if an alarm condition has been created.
- **msgHigh, msgLow:** For analog alarm conditions, these property relations define alarm messages for the high-limit and low-limit alarm. They exist only, if an alarm condition has been created.
- **nativeAlarm:** This property relation links to a technology data point, which is required for alarms reported to another technology. It exists only, if an alarm condition has been created and alarms are reported to the given technology (e.g. BACnet). This property relation cannot be modified by the user.
- **reportTo:** This property relation exists only in generic alarm servers. It may be linked to a technology alarm server to report alarms to that network technology.
- **totalActive, totalUnacked, totalAcked:** These property relations exist only in alarm servers. They contain counters for active unacknowledged, inactive unacknowledged, active acknowledged alarm records of the alarm server, respectively.
- **ackAll:** This property relation exists only in alarm servers. When writing TRUE, all alarms on that alarm server are acknowledged.
- **historicFilter:** This property relation exists for data points that have at least one historic filter assigned (see Section 3.4.6).
- **enable:** For Schedulers can be enabled or disabled by the use of this property relation. If the enable data point has been defined in the scheduler's configuration, this property relation is linked to that data point.
- **enableFb:** This property relation shows the enable state of the scheduler. If the enable feedback data point has been defined in the scheduler's configuration, this property relation is linked to that data point.
- **presetName:** This property relation of type string shows the preset name of the currently scheduled value. If the preset name data point has been defined in the scheduler's configuration, this property relation is linked to that data point.

- **timeToNext:** This analog property relation contains the number of minutes till the next scheduled state changes. It can be used to implement an optimum start algorithm.
- **nextState:** This property relation contains the next scheduled state. It can be used to implement an optimum start algorithm.
- **nextPresetName:** This property relation contains the preset name of the next scheduled state, if such name exists. Otherwise it stays at invalid value.

### 3.1.13 Convertible Engineering Units

Analog data points possess one or more unit properties that define the physical unit of the underlying scalar value, e.g., “°C”. The engineering unit is displayed as a human-readable text to the user. The text can be freely entered by the user to describe the nature of the scalar value. The Configurator matches this text against its database of known engineering units. If it can identify the unit, it is denoted as a *convertible unit* with a green checkmark ✓.

Convertible units are linked to additional meta-information in the metric (SI) or U.S. unit system. For each data point the Configurator offers unit representations in the respective unit system. Data points will provide values in that unit system. These may be different from values transported over an underlying network. For those technologies the Configurator defines a fixed *network unit*.

Important properties of convertible units when used are:

- Unit representations can be configured for the metric (SI) and U.S. unit system. The device can be configured to run in either unit system and provides data point values in the respective unit. Automatic conversion from network units to the chosen unit system is performed.

---

**Important!**

***When changing the unit system, the device needs to be rebooted and will reset all persistent values to their default values converted to the chosen unit system.***

---

- Automatic unit conversion in local connections is performed, if data points with compatible convertible units are connected (e.g. ‘1000 W’ are converted to ‘1 kW’). No custom scaling is required.
- Auto-generated data points in connections are created such that they have a best-matching unit in their target technology (e.g., the best-matching SNVT is created out of a BACnet data point of a certain engineering unit).

For example, a data point has a fixed network unit in °C. As it is a convertible unit, the user can define a representation for that data point in the metric (SI) system (°C) and one in the U.S. system (°F). Depending on the selected unit system, the received value on the network is converted either to °C or °F. All data point values on the device are processed in the selected unit system, including the Web UI, OPC server, parameter file, global connections, and programmable logic. For more information on how to start a project in SI or U.S. units, please refer to Section 4.4.7.

---

## 3.2 Math Objects

### 3.2.1 General Properties

Math objects are advanced application objects that can execute mathematical operations on data points. A math object takes a number of input data points (variables  $v_1, v_2, \dots, v_n$ ) and calculates a result value according to a specified formula. The result is written to a set of output data points. The formula is calculated each time one of the input data points updated its value. The formula is only evaluated if all of the input data points have a valid value (i.e., don’t show the *invalid value* status).



Using the assigned variable names, immediate values, parenthesis, operators and function names, the user can enter a formula in the usual way (infix notation). Apart from the functions in the next Section, the short-hand operators +, -, /, \*, %, AND, OR, XOR, ^, &, |, =, !=, <, >, <=, >= can be used directly. Further, it is possible to use parenthesis to define the precedence of the operations.

Example: `(v1 + v2) * sqrt(pow(v3,0.1))`

*Note:*

*As usual practice in programming languages, the comma is used to separate arguments in expressions and the **decimal point** is used in decimal values. The expression `sum(4,5)*2` evaluates to 18, while `sum(4.5)*2` evaluates to 9.*

As you enter the formula, it will be parsed and the resulting sequence of calculations will be displayed in a list at the right of the property page. This list shows your formula in reverse polish notation (RPN), also known as postfix notation, as used by many scientific pocket calculators.

### 3.2.2 Usage Hints

A few functions end with a ... (three dots) in the argument list. This means that they accept a variable number of arguments. When used in the formula, they will fetch all available values from the stack and then calculate the result, which will be put back on the stack and be the only value on the stack, since all other values were used as input to the function.

This behavior causes some limits in how these functions may be used. You are on the safe side, if you use such a function only as the outermost function (infix), or as the last function on the stack (postfix) for example:

`sum(v1, v2, exp(v3, -1))`

Or the postfix equivalent: `v1, v2, v3, -1, exp, sum`

If you have to use it as an argument to another function, it may only be the first argument; otherwise the formula cannot be processed by the math object, which internally uses an RPN machine, with precompiled instructions for optimal performance. Example:

`add(avg(v1, v2, v3), 5)` or `avg(v1, v2, v3)+5` will work.

`add(5, avg(v1, v2, v3))` or `5 + avg(v1, v2, v3)` will NOT work.

Another property of those functions is that they ignore input values, which have the invalid value. Therefore, assuming `v1=5`, `v2=invalid`, `v3=3` the calculation `add(v1,v2,v3)` evaluates to 8 while `v1+v2+v3` returns invalid. This can be used to purposely allow inputs in the calculation that have no value.

To limit the number of re-calculations, the data point option **Only Notify on COV** should normally be checked on all connected input data points. This avoids recalculating the formula and writing a value to the output data point when it is already clear that the result will be the same, because the input value did not change. The same option can also be checked for the output data point to avoid unnecessary writes to the output data point, in case the inputs changed but the result of the formula is still the same.

### 3.2.3 Function List

The currently supported math function calls are listed in Table 1.

Function	Return Value
add(v1,v2)	$v1 + v2$
sub(v1,v2)	$v1 - v2$
mul(v1,v2)	$v1 * v2$
div(v,d)	$v / d$
mod(v,m)	Returns the remainder of dividing v by m, where v and m should be integer values. Fractional values will be rounded to the nearest integer automatically
max(v1,...)	Returns the maximum of all values on the value stack
min(v1,...)	Returns the minimum of all values on the value stack
avg(v1,...)	Returns the arithmetic mean value of all values on the stack
log(v)	Returns the natural logarithm of v
log2(v)	Returns the base 2 logarithm of v
log10(v)	Returns the base 10 logarithm of v
exp(v)	Returns the value of e (the base of natural logarithms) raised to the power of v
exp2(v)	Returns the value of 2 raised to the power of v
exp10(v)	Returns the value of 10 raised to the power of v
sqrt(v)	Returns the non-negative square root of v
pow(v,exp)	Returns the value of v raised to the power of exp
round(v)	Round v to the nearest integer
floor(v)	Round v down to the nearest integer
ceil(v)	Round v up to the nearest integer
sum(v1,...)	Returns the sum of all values on the stack
and(b1,b2)	logical AND of the Boolean values b1 and b2 $(b1 \& b2)$
or(b1,b2)	logical OR of the Boolean values b1 and b2 $(b1    b2)$
xor(b1,b2)	logical exclusive OR of the values b1 and b2 $(b1 ^ b2)$
not(b)	logical inverse of the Boolean value b $(!b)$
lt(v1,v2)	returns 1 if v1 is lower than v2, else returns 0 $(v1 < v2)$
le(v1,v2)	returns 1 if v1 is lower or equal v2, else 0 $(v1 \leq v2)$
eq(v1,v2)	returns 1 if v1 equals v2, else 0 $(v1 = v2)$
ge(v1,v2)	returns 1 if v1 is greater or equal v2, else 0 $(v1 \geq v2)$
gt(v1,v2)	returns 1 if v1 is greater than v2, else 0 $(v1 > v2)$
if(b,vt,vf)	returns vt if b is true, else returns vf $(b ? vt : vf)$
encode(b1,...)	Reads all values from the stack, converts them to Boolean values and encodes them into an integer value, where the first value is used as the LSB and the last value as the MSB.
sin(v1)	Returns the sine of v1, where v1 is given in radians
cos(v1)	Returns the cosine of v1, where v1 is given in radians
tan(v1)	Returns the tangent of v1, where v1 is given in radians
sinh(v1)	Returns the hyperbolic sine of v1, which is defined mathematically as $(\exp(v1) - \exp(-v1)) / 2$
cosh(v1)	Returns the hyperbolic cosine of v1, which is defined mathematically as $(\exp(v1) + \exp(-v1)) / 2$
tanh(v1)	Returns the hyperbolic tangent of v1, which is defined mathematically as $\sinh(v1) / \cosh(v1)$
asin(v1)	Returns the arc sine of v1; that is the value whose sine is v1
acos(v1)	Returns the arc cosine of v1; that is the value (in radians) whose cosine is v1
atan(v1)	Returns the arc tangent of v1; that is the value (in radians) whose tangent is v1
asinh(v1)	Returns the inverse hyperbolic sine of v1; that is the value whose hyperbolic sine is v1
acosh(v1)	Returns the inverse hyperbolic cosine of v1; that is the value whose hyperbolic cosine is v1
atanh(v1)	Returns the inverse hyperbolic tangent of v1; that is the value whose hyperbolic tangent is v1

Function	Return Value
gamma(v1)	Returns the value of the Gamma function for the argument v1. The Gamma function is defined by $\Gamma(x) = \int_0^\infty t^{x-1} e^{-t} dt$ . It is defined for every real number except for no positive integers. For nonnegative integral m one has $\Gamma(m+1) = m!$ and, more generally, for all x: $\Gamma(x+1) = x * \Gamma(x)$ For $x < 0.5$ one can use $\Gamma(x) * \Gamma(1-x) = \pi / \sin(\pi * x)$
abs(v1)	computes the absolute value of the argument v1

Table 1: Available math functions.

## 3.3 Connections

### 3.3.1 Local Connections

With the use of connections data points can interact with each other. Connections specify which data points exchange values with each other. Various types of connections – from “1:n” to “m:n” connections – are supported. Data points added to a connection specify whether they feed a value into the connection (send) or they receive a value from the connection (receive).

This means, the following connections are possible:

- 1 input data point is connected and writes to n output data points,
- m input data points are connected and write to 1 output data point,
- m input data points are connected and write to n output data point.

The most common connection will be the 1:1 connection. This is the type of connection that is auto-generated by the Configurator software. Other types must be created manually or by a template in the Configurator.

In the 1:n connection the input value is distributed to all n output data points. In the m:1 connection, the most current input value is written to the output data point. When polling the output data point in poll-through mode (maximum cache age is set on the output), the value from the first input data point is polled. The same holds true for a m:n connection. The default data flow of data points in a connection is a result of the data point direction. This can be overridden by a custom setting (i.e. an output data point can be configured as an input to the connection).

Connections can connect data points of different technologies with each other (also mixed among the target data points). When connecting data points of different classes the exchanged values need to be converted. The connection inherits the type of the first data point class. If data points of a different class are added to this connection, an *adaptor* needs to be defined. For example an analog value connection has a multi-state output data point. Adaptors can be saved in a library and re-used later for similar conversions.

The following conversions apply:

- **Analog to Analog:** The value range is capped on the output data points. This means, if the input value in the hub does not fit into the range of an output data point, the value is capped to the biggest or smallest allowed value. If the input and output data points both have convertible units the value is converted. The user can also specify a simple math formula as an adaptor. In this case no implicit unit conversion is performed.
- **Binary/Multi-state to Analog:** The Boolean or state value is directly converted to an analog value (e.g. state ID ‘4’ is written as ‘4.0’) as a default. The user should specify an adaptor to map the Boolean or state value to designated analog values.

- **Analog to Binary/Multi-state:** As a default the analog value is converted to the next Boolean or state value (e.g. '1.2' is written as state ID '2'). The user should specify an adaptor with its own translation of value ranges to state values.
- **Multi-state to Multi-state:** Multi-state data points that have different state maps lead to a conversion of their state values. The state maps of inputs and outputs are ordered by state ID in ascending order. The state value of the input is then ranked as the n-th state and propagated over the connection. For example, the input state ID '1' is the 2nd state and the output's 2nd state has the state ID '0'. If the output data point has less states than the input, the output state is limited to its highest state ID. The user should specify an adaptor that defines which input state maps to which output state.
- **Binary to Binary:** Binary data points can be connected without conversion.
- **String to String:** String data points can only be connected to string data points.
- **User to User:** User data points can only be connected to user data points. If the length is different, only valid bytes are written or excess bytes are truncated, respectively.
- **SNVT\_switch to Analog/Binary/Multi-state:** The user data point of a SNVT\_switch can be connected to analog, binary, and multi-state data points.
- **Analog/Binary/multi-state to SNVT\_switch:** Analog, binary, and multi-state data points can be directly connected to a SNVT\_switch user data point.

### 3.3.2 Multi-Slot Connections

Connections between structured data points often need to connect each structure member separately. To increase the overview in the project on the involved, single connections, a *multi-slot connection* can be created for local connections. This is a connection with several slots for transporting separated values over the connection. Each slot has a number and a name and can connect two or more data points. Data points added to other slots do not share their values across slots. One can think of such a connection as a cable with many wires. An example is shown in Figure 5 (a). The data point 'IN A' sends its value to 'OUT X' but not 'OUT Y'.




Figure 5: Multi-slot connection (a) and multi-slot with math block adaptor (b).

Some gateway applications also require a functional mapping between different data point structures in one connection. A multi-slot connection can be used with a math block adaptor to accomplish this task. A math block has  $n$  inputs and  $m$  outputs. The multi-slot connection has a slot for each input and output, which can be connected to the respective data points as depicted in Figure 5 (b). For this multi-slot connection the math block adaptor defines a fixed layout of the slots; no more slots can be added to this connection.

In a math block adaptor with  $n$  inputs  $v_1, v_2, \dots, v_n$  each output  $o_i$  is calculated as a formula depending on all inputs  $o_i = f_i(v_1, v_2, \dots, v_n)$ . Each output has two math formulae following the same format as used in math objects (see Section 3.2):

- Output value formula: This formula calculates the output value as a function of all input values.
- Output enable formula: This formula calculates an output enable (result > 0 is enable) for the output. If the output is enabled, the output value will be written to the output. If the output is disabled, the calculated output value is not written to the output.

In addition, each input slot can be configured whether it shall trigger the calculation or not. Normally, any change in any input triggers the calculation of all outputs.

### 3.3.3 Automatic Generation and Templates

In a gateway application the systems engineer has a typical workflow: He will be confronted with some network equipment of one technology that needs to be exposed to another network technology. The task of generating the counterparts of data points in another technology and connecting them is covered by the *smart auto-generate and connect* method. The existing data points are called *sources* and the generated data points are called *targets*.

In principle, the Configurator supports auto-generate for all source technologies but generation is limited to select target technologies. Depending on availability on the device model, the following technologies can be target for auto-generation:

- CEA-709 (static NVs),
- BACnet (server objects),
- Registers,
- Modbus (slave registers).

The target data point is generated with opposite direction and of the same class as the source data point. Depending on the target technology, however, certain restrictions apply on what can be generated. Typical issues are engineering units, state maps and data point structures. The folder structure of the source data points is replicated for the target data points.

For example, when generating matching counter parts to NVs, there are two types of NVs to be considered: Simple NVs that hold only one value (scalar or enumeration), and structured NVs, that consist of a number of fields. For simple NVs only one BACnet object per NV is generated. For structured NVs, one BACnet object is generated for each structure member. This method is called structure flattening. Some target technologies do support structures and no flattening is applied. When generating an analog target, a data point with the best-matching engineering unit is created. If the target allows arbitrary engineering units this will be the same as the source engineering unit. If the target has only a limited number of engineering units, the technology object with the best-matching unit is created. Multi-state target data points are created with an equal number of states and compatible state IDs. For example the CEA-709 state IDs are sorted and renumbered to start at '1' in BACnet (i.e., a '-1' of MOTOR\_NUL in CEA-709 maps to a '1' of MOTOR\_NUL in BACnet). This is necessary as the SNVT states '-1' and '0' cannot be represented in BACnet as a raw value, because allowed BACnet multi-states start at 1.

The Configurator provides a preview dialog that shows, which target data points will be created. Thus, the implicit generation rules are visible to the user. If the target technology provides several options on what to generate, the user can change the default in this dialog. The setting is stored in the project and will be applied again with the next generation. The project settings also provide defaults for auto-generation. How exactly data points are created depends on the target technology. Refer to the technology sections for more information how data points are used in connections.

For more advanced connection tasks that involve specific adaptors *auto-generate templates* must be used. An auto-generate template contains the source data point, the desired target

data point and the local connection with all appropriate adaptors. There are two types of auto-generate templates:

- **Simple auto-generate template.** This template contains exactly one source data point (scalar or structured). It may contain one or more target data points, which will be generated. This template can be applied on any selection of single source data points. If the type of the source data point matches the one in the template, this auto-generate template can be selected to generate the target data points. This template type can be used to generate special target objects for certain scalar source data points using adaptors. It can also be used to connect structure elements of the source to structure elements of a target using a math block adaptor.
- **Complex auto-generate template.** This template contains more than one source data points. This type must be used, if two or more sources shall generate the targets in a specific way. Since no single source data points can be matched in this case, the source data points which belong together must be grouped under a folder. Math block adaptors can be used with complex auto-generate templates.

Auto-generate templates can use configurable placeholders for data point name, data point description, server object name, server object description. These placeholders are evaluated when the template is applied and new data point instances are created. The available placeholders are listed in Table 2.

Placeholder	Meaning
<code>%{name}</code>	In simple auto-generate templates this expands to the source data point name.
<code>%{descr}</code>	In simple auto-generate templates this expands to the source data point description.
<code>%{native_name}</code>	In simple auto-generate templates this expands to the native name (e.g. register name, NV programmatic name, server object name) of the source data point. If no such native name exists, the data point name is used instead.
<code>%{native_descr}</code>	In simple auto-generate templates this expands to the native object description (e.g. server object description) of the source data point. If no such native description exists, the data point description is used instead.
<code>%{path}</code>	This placeholder expands to the source data point/folder path. The path extends up until the respective data point folder root folder. Example: The source data point is located in 'CEA-709 Port.Datapoints.Floor1.Room202'. The path expands to 'Floor1.Room202'.
<code>%{folder_descr}</code>	This placeholder expands to the folder description of data point's parent folder. Folder descriptions are copied from source to generated folders.

Table 2: Placeholders in auto-generate templates.

### 3.3.4 Global Connections

Global connections provide the same notions as local connections but extend beyond the scope of one device. A global connection establishes a data cloud with a system-wide name. Data points added to a global connection can send data into that connection or receive data from the connection. The data is transferred over an IP-based network. All data is automatically matched by the global connection name. This makes global connections especially useful to provide certain global data in a system, without knowing who will be reading that data. Examples are weather station data, wind alarms or global on/off.

Global connections cannot use adaptors for conversions as in local connections. If conversions are needed, an intermediate register data point must be used to receive/send data from/to the global connection. The adaptor needs to be installed with a local connection between the register and the data point, which requires the conversion.

The system in which the data cloud of a global connection is established is defined by an IP-852 channel. This channel is not related to the CEA-709 technology; it is purely used to define the set of devices exchanging data through global connections. It can, however, coexist with an IP-852 channel for CEA-709. The configuration of the IP-852 channel is done by adding devices to a configuration server. This is described in closer detail in Section

„Configuration Server for Managing the IP-852 Channel” of the LOYTEC Device User Manual.

A global connection has the following properties:

- **Max Send Time:** This timing parameter of the global connection specifies a time in seconds, in which a value update is transmitted into the connection, even if not value has changed. This is typically used for heartbeat functions.
- **Min Send Time:** This timing parameter of the global connection specifies a time in seconds, for which transmissions will be delayed after sending out a value into the connection. This setting can be used to limit the transmission rate to the connection.

The following properties are derived from the data points in a global connection:

- **Receive Timeout:** A data point with a receive timeout will be put into the state offline, if it does not receive a value within the specified period of time (see Section 3.1.2). This also applies to values received from the global connection.
- **Poll on startup:** If a data point in the global connection has the poll on startup feature enabled (see Section 3.1.2), an initial value update will be triggered for the global connection.

How a global connection is created and configured in the Configurator software is described in Section 4.5.7. Note, that the number of configurable global connections on a device is limited per device model.

### 3.3.5 Forward Delay

Connections can be used to implement stagger delay with randomization. This is beneficial for applications with load shedding. All receive items in a connection, both local and global, can be configured with a *delay*. The delay can be specified as a constant delay in seconds, or as an interval, in which the actual delay will be randomized.

These are example delay settings:

- 0s: No delay is imposed on received updates.
- 10s: Each received update on the receive data point will be delayed for 10 seconds.
- 10-60s: Each received update is delayed randomly between 10s and 60s.

If updates are generated faster than they are forwarded because of the delay, the last update overwrites any pending updates. No queueing is implemented for delayed updates over connections.

---

## 3.4 AST Features

### 3.4.1 Alarming

The alarming architecture comprises a number of entities. Objects that monitor values of data points and generate alarms depending on an *alarm condition* are called *alarm sources*. The alarms are reported to an *alarm server* on the same device. The alarm server maintains a list of alarm records, called the *alarm summary*. The alarm server is the interface to access the local alarms.

Generic alarm servers provide the maximum set of alarming features and can be accessed over L-WEB (via the Web service) or the Web UI. Data points of all network technologies can be alarmed through generic alarm servers. Technology alarm servers can be used to expose access to the alarms to network technologies that support it. Generic alarm servers can be configured to report their generic alarms to technology alarm servers. For example, a generic alarm server may report its alarms to both CEA-709 and BACnet alarm servers.

An alarm record contains the information about a specific alarm. This includes information about the alarm time, the source of the alarm (i.e., which data point caused the alarm), an alarm message, an alarm value, an alarm type, an alarm priority, and an alarm state. An alarm record undergoes a number of state changes during its life-cycle. When the alarm occurs, it is *active*. At this point the alarm time, alarm message, alarm value is notified using the alarm priority. When the alarm condition subsides, the alarm becomes *inactive*. At this point the clear time and the clear message is notified using the normal priority. The priority levels are configurable on the alarm server, where 0 is the highest and 255 is the lowest priority.

Alarm messages are texts that may contain variable placeholders. These placeholders are expanded when the alarm transition occurs. Table 3 lists the available placeholders and their meanings.

Name	Placeholder	Expands to
Name	<code>%{name}</code>	The name of the alarmed data point.
Path	<code>%{path}</code>	The path of the data point, not including the data point name itself.
Description	<code>%{descr}</code>	The description of the alarmed data point.
Alarm Value	<code>%{val}</code>	The value causing the alarm.
Low Limit	<code>%{lo}</code>	The low limit configured for the alarm in a low-limit alarm.
High Limit	<code>%{hi}</code>	The high limit configured for the alarm in a high-limit alarm.
Deadband	<code>%{db}</code>	The deadband configured for the alarm.
Comm. Value	<code>%{commVal}</code>	The commanded value when the feedback value differs from it in a feedback alarm. In a feedback alarm the placeholder <code>%{val}</code> expands to the feedback value.
BACnet Name	<code>%{bacName}</code>	The BACnet server object name of the alarmed data point, which may differ from the data point name. If the technology is not BACnet, this is equivalent to <code>%{name}</code> .
BACnet Descr	<code>%{bacDescr}</code>	The BACnet server object description of the alarmed data point, which may differ from the data point description. If the technology is not BACnet, this is equivalent to <code>%{descr}</code> .

Table 3: Placeholders in alarm texts.

Alarm transitions (to an alarm state, to the normal state) can be acknowledged by an operator. Which of those transitions requires an acknowledgement is configurable on the alarm server. If an active alarm is acknowledged it becomes *active acknowledged*. Active alarms can also become inactive, but an acknowledgement is still required. Then they become *ack-pending*. When an alarm is inactive and was acknowledged it finally disappears from the alarm summary.

An alarm state can be of different alarm types. The alarm type specifies the class of the alarm. The following alarm types exist:

- **Off-Normal Alarm:** This alarm type is a generic alarm class that applies to binary and multi-state alarm conditions. It indicates that the alarmed data point is on an off-normal operating condition that triggered the alarm. An alarm value is supplied. In technology alarm servers, restrictions may apply.
- **High/Low Limit Alarm:** This alarm type is typical for analog alarm conditions. It applies when the alarmed value is over or under the defined alarm limits. An alarm value is supplied. In technology alarm servers, restrictions may apply.
- **Fault Alarm:** This alarm type is indicating that the monitored data point is in a fault state. This is different from off-normal or high/low limit alarms. The value of the data point is within the specifications of the alarm condition but the data point itself is considered faulty. This can stem from an unreliable value or an offline value, i.e., if the data point is offline. No alarm value is supplied.

Alarms may be generated from a given data point value (alarm value or value range) or by comparing a data point command value with a feedback value (feedback alarm). When



defining a feedback alarm, the alarmed data point represents the command value and has a 'feedbackValue' property relation (see Section 3.1.12). This property relation can be linked to another data point, which effectively provides the feedback value.

Alarmed data points also possess other property relations. The 'enableAlarm' property relation can be used to disable or enable alarm conditions when linked to a data point. The property relations 'highLimit', 'lowLimit', 'deadband' can be used to modify analog alarm conditions. The property relations 'inAlarm' and 'ackPend' are TRUE if a data point is in an alarm state or needs acknowledgement, respectively.

When a data point is alarmed by a generic alarm server, which reports to a technology that requires a dedicated technology data point (e.g., an alarm for a user register is reported to BACnet), the required data point is automatically created and linked via the 'nativeAlarm' property relation.

Alarm server objects possess property relations that provide a counter value of active unacknowledged, active acknowledged, and inactive unacknowledged alarms. These property relations may be linked to other data points that can be used to process this information.

Other devices can access the alarm information through a technology alarm server or the Web service. These devices are *alarm clients*. They register with the alarm server and get notified about changes to the alarm summary. Alarm clients can be used to display the current alarm summary and to acknowledge alarm transitions. Depending on the underlying technology, some restrictions may apply to the available alarm information and acknowledgement behavior. Refer to the technology sections for more information.

### 3.4.2 Historical Alarm Log

The alarm summary of the alarm objects contains a live list of currently active and acknowledge-pending alarms. As soon as an alarm becomes inactive and has been acknowledged, it disappears from the alarm summary. To store a historical log of alarm transitions an *alarm log* is utilized. An alarm log can log transitions of one or more alarm objects.

The alarm log is always local and stored as a file on the device. The size of an alarm log is configurable. The alarm log operates as a ring buffer. As soon as its size limit is reached, the oldest alarm log records are overwritten by newer alarm transitions. The alarm log is available on the Web UI or can be uploaded from the device as a CSV file. The CSV file can also be used as an e-mail attachment.

### 3.4.3 Scheduling

Schedulers are objects that schedule values of data points on a timely basis. A scheduler object is configured by which data points it shall schedule. This configuration is done by the system engineer once, when the system is designed. The configuration of the times and values that shall be scheduled is not part of that initial configuration and may be changed later. This distinction has to be kept in mind.

A scheduler object sets its data points to predefined values at specified times. The function of the scheduler is state-based. This means, that after a given time, the scheduler maintains this state. It can re-transmit the scheduled values as appropriate (e.g., when rebooting). The predefined values are called *value presets*. A value preset contains one or more values under a single label (e.g., "occupied" schedules the values { 20.0, TRUE, 400 } ). Each preset can also be configured with a display color.

Which value preset is scheduled at what time is defined by a *scheduled event*. The event defines the starting time, value preset and end time in a 24-hour period. Events can be one-time events or recurring events. A schedule typically consists of a number of recurring and one-time events, for instance one event for the weekdays Monday through Sunday. See Figure 6 for an example of a schedule in a given calendar week.




Figure 6: Example of a recurring event in a schedule.

How scheduled events are recurring can be defined by choosing the appropriate event type:

- **One-time:** This event occurs exactly on one defined date.
- **Daily:** This event occurs every day, starting at a given date and ending at a given date.
- **Weekly:** This event occurs every week on the specified weekday.
- **Monthly:** This event occurs every month following a date range or a defined rule (e.g. every last Friday).
- **Yearly:** This event occurs every year following a date range or a specific day every year.
- **Default:** This is a special event. The selected preset value will be in effect 00:00 to 24:00 hours every day if no other event occurs.
- **Calendar:** For some tasks the regular recurrence such as on weekdays is not sufficient. This can be implemented by defining events based on a *calendar*. For instance, there may be a calendar for holidays. The calendar contains a number of *calendar patterns*. Each calendar pattern describes a pattern of dates on which an event shall occur, e.g., *Holidays*.

One can define a set of scheduled events that are recurring differently. For example one event is defined for regular workdays (Monday through Friday). Another event is defined based on the holidays calendar pattern. This will lead to overlapping events between workday and holiday for those weekdays, which are holidays.

The resolution of this overlap is simple: Each event is configured with a *priority*. Should an overlap occur, the event with the higher priority will be in effect (e.g., Dec 25<sup>th</sup> in Holidays overrides the regular workday event). An example is shown in Figure 7. The detailed view shows the two overlapping events and the preview shows the effective schedule. Note, if two events with the same priority exist, it is not defined, which one is in effect. Therefore, always use distinct priorities.

Priorities are numbers, but some priorities have been pre-assigned, e.g. highest, override, normal, low. Please also refer to the technology-specific limitations described in Section 4.7 to learn about special behavior of the respective networking technology.

If no event is in effect at a given time, the *schedule default* becomes effective. This can be defined to be any of the defined presets. In Figure 7 the scheduler will write out “unoccupied” after 12:30 as no other event exists. A special schedule default is *silent*. With the silent default the scheduler will be inactive, if no event is in effect. This means it will not update its scheduled data points until the next scheduled event, not even at midnight. Thus, using the silent default one can build an event-based scheduler.




Figure 7: Example with overlapping events and different priorities.

The configuration of calendar-based recurrence is done by calendar patterns in the calendar. Each calendar pattern contains a number of pattern entries. These entries can define the following:

- A single date: This defines a single date. Wildcards may be used in the year to specify Dec 25<sup>th</sup> of every year.
- A date range: This defines a range. Starting with a start date and ending with the end date. No wildcards should be used.
- A Week-and-Day definition: This defines dates based on a week, such as every 1st Friday in a month, every Monday, every last Wednesday of a month.

A schedule defines at which time instants certain states of the scheduled data points are maintained. The *next-state* feature allows looking up to 48 hours ahead into the future and predicts when the next scheduled state change will occur. There are two data points involved: the *timeToNext* is a counter in minutes to the next scheduled event, and the *nextState* data point is the state of the next scheduled event. This information can be used by controllers for optimum start algorithms (e.g., pre-heat a room for the scheduled occupancy state). Use the *SNVT\_tod\_event* in CEA-709 to accomplish this task. With generic schedulers and BACnet schedulers use the scheduler's property relations *timeToNext* and *nextState* (see Figure 8).

Datapoint Name	No.	Direction	OPC	Use	ID
calendar	1	Value	<input checked="" type="checkbox"/>	1	1039
Schedule_reg1	2	Value	<input checked="" type="checkbox"/>	0	1060
enable -> User Registers.sched_enable	2.1	Value	<input checked="" type="checkbox"/>	0	106F
enableFb	2.2	In	<input checked="" type="checkbox"/>	0	1070
nextPresetName	2.3	In	<input checked="" type="checkbox"/>	0	1074
nextState	2.4	In	<input checked="" type="checkbox"/>	0	1073
presetName	2.5	In	<input checked="" type="checkbox"/>	0	1071
timeToNext	2.6	In	<input checked="" type="checkbox"/>	0	1072
User Registers.reg1	2.7				105F

Figure 8: Property relations of a scheduler object.

When a scheduler is executing the schedule on the local device, it is called a *local scheduler*. Such a scheduler is configured to schedule data points and later its daily schedules can be modified. When accessing the daily schedules of a scheduler, which executes on a remote device, the object is called a *remote scheduler*. A remote scheduler has the same interface to the user to modify daily schedules. A remote scheduler object can be used as a user-interface for schedulers that execute on different devices.

A generic scheduler and calendar is a universal kind of AST object that is not visible on a control network (such as CEA-709 or BACnet). Generic schedulers/calendars are accessible by L-WEB and Web services only. The limitations on scheduled events and calendar patterns are listed in Table 4. For technology schedulers/calendars refer to the BACnet and CEA-709 technology sections instead (Section 3.6.4 and 3.7.3).

Limitation for number of	Value
Scheduled events	40
Scheduled events (at weekday priority)	24
Date entries per calendar pattern	100
Calendar patterns in the calendar	25

Table 4: Limitations of generic scheduler/calendar objects

### 3.4.4 Trending

Trending refers to the ability to log historical values of data points over time. A trend log object is responsible for this task. The generic trend log object provides the maximum set of features and can be accessed by L-WEB and the Web service. It can be configured to record historical data of any data point on the device. Log records are generated either in fixed time intervals, on change-of-value (COV) conditions, or when a trigger is activated. The fixed intervals can be optionally aligned to the wall time (e.g., to the top of the hour). After a reboot the recording is resumed at the aligned intervals. Trend log objects can trend either local or remote data points. Technology trend log objects can be used to record historical values of the respective technology data points and expose them to network technologies that support it. These historic logs are separate from the generic trend logs and certain restrictions of the technology may apply.

The trend data is stored in a binary format on the device. The capacity of a given trend log is configured. The trend log can be operated in one of two modes: In *linear mode* the trend file fills up until it reaches its capacity. It then stops logging. In *ring buffer* mode the oldest log records are overwritten when the capacity is reached.

Devices with SD cards also allow backups of the trend logs on external Flash storage. This backup can be triggered by the user over the LCD display or be triggered by certain actions. The trend data is stored in CSV format under a folder identifying the device by serial number and the trends sub-directory, e.g. '016101-8000000DEA51/trends'. The SD card can be used on different devices. In this case different device directories will be created. The trend backup files can be opened directly on a PC. The backup on external storage can be enabled individually per trend log.

A fill-level action can be activated, whenever the trend log has logged a percentage of its log size with new log records. A fill-level condition of 70% on a trend log with 1000 items capacity will activate the fill-level trigger every 700 logged records. This trigger can be used to send E-Mails or backup trend data on external storage if available.

Trended data points can be logged as their actual values at given time instants or as an aggregated value over the defined log interval. Aggregation can be calculated as minimum, maximum, or average. Aggregation can be beneficial, if the trended value changes more frequently than the selected log interval. Using aggregation, the log interval can be chosen to limit the amount of logged data while preserving information of the trended value.

For technology trend log objects, certain restrictions apply as to how many data points can be trended in one trend log and which trend modes are available. Refer to the technology sections for more information.

### 3.4.5 E-mail

The e-mail function can be combined with the other AST features. The format of an e-mail is defined through *e-mail templates*. An e-mail template defines the recipients, the e-mail text, value parameters inserted into the text and triggers, which invoke the transmission of an e-mail. An e-mail template can also specify one or more files to be sent along as an attachment.

The e-mail text content can contain text and configurable placeholders. The placeholders expand to their content when the e-mail is transmitted. Placeholders can also be used in other text fields, such the Subject field. The placeholders available for e-mail templates are listed in Table 5.

Placeholder	Meaning
<code>%{vn}</code>	This placeholder expands to the content of a data point variable defined in the e-mail template. The <i>n</i> refers to the <i>n</i> -th data point variable in the list. The data point variable list specifies this index.
<code>%{vn.name}</code>	This placeholder expands to the name of the data point variable.
<code>%{vn.descr}</code>	This placeholder expands to the description of the data point variable.
<code>%{vn.src_name}</code>	If the data point variable is an alarm, this placeholder expands to the source name of the alarmed data point, for which a new alarm is reported.
<code>%{vn.src_path}</code>	If the data point variable is an alarm, this placeholder expands to the source path of the alarmed data point, for which a new alarm is reported.
<code>%{vn.al_descr}</code>	If the data point variable is an alarm, this placeholder expands to the message of the reported alarm. For a to-alarm transition it contains the alarm message, for a to-normal transition it contains the clear message, for a to-fault transition it contains the fault message.
<code>%{vn.al_type}</code>	If the data point variable is an alarm, this placeholder expands to the alarm type of the reported alarm.
<code>%{vn.al_state}</code>	If the data point variable is an alarm, this placeholder expands to the state of the reported alarm.
<code>%{vn.al_tm}</code>	If the data point variable is an alarm, this placeholder expands to the alarm time of the reported alarm.
<code>%{vn.cl_tm}</code>	If the data point variable is an alarm, this placeholder expands to the clear time of the reported alarm.
<code>%{vn.ack_tm}</code>	If the data point variable is an alarm, this placeholder expands to the acknowledge time of the reported alarm.
<code>%{vn.ack_src}</code>	If the data point variable is an alarm, this placeholder expands to the acknowledge source text of the reported alarm. If the alarm has not been acknowledge, this is empty.
<code>%{vn.al_val}</code>	If the data point variable is an alarm, this placeholder expands to the value which triggered the alarm (alarm value).
<code>%{mailid}</code>	This placeholder expands to the mail ID used for the transmitted message. This mail ID is different for each message.
<code>%{timestamp}</code>	This placeholder expands to the mail timestamp seen in the transmitted message.
<code>%{last_timestamp}</code>	This placeholder expands to the mail timestamp of the previous transmitted message.

Table 5: Placeholders in e-mail templates.

A prerequisite to sending e-mails is the configuration of an e-mail account on the device. This can be done on the Web UI. It is recommended to use the e-mail server of your Internet provider. For public mailers, enable the required authentication. SSL/TLS e-mail authentication is supported for using Hotmail, gmail or Yahoo!.

The amount of generated e-mails can be limited using a rate limit algorithm. The transmission of e-mails can be disabled altogether by using a special data point. That data point can be scheduled or driven over the network.

If an e-mail cannot be sent (e.g. the mail server is not reachable), the mail delivery is retried up to 24 times every 30 minutes.

### 3.4.6 Historic Filters

For certain applications historic values of a given base data point, both recent and far into the past, can be of interest. This can be accomplished with *historic filters*. Historic filters allow processing historic values of the base data point according to a filter function. One or more

such functions can be defined per base data point. The result of the historic filter is written to *historicFilter* property relations. For each historic filter function a time period can be defined at which the base value is sampled, e.g., every first of the month at midnight, and how many samples ago. Historic filters can be created for any analog, binary, or multi-state data point. It is not necessary to create a trend log.

The following sampling periods can be defined, which allow for a certain sampling tolerance interval if the device is not online at the sampling time:

- Value every  $x$  minutes aligned to full hour ( $x = 1, 2, 5, 10, 15, 20, 30$  min), 0 or 1 samples ago,
- Hourly value at full hour, 0..24 samples ago (tolerance 15 minutes),
- Daily value at HH:MM:SS of the day, 0..60 samples ago (tolerance 5 hours),
- Weekly value at HH:MM:SS on weekday (Mon..Sun), 0..10 samples ago (tolerance 1 day),
- Monthly value at HH:MM:SS on day of month (1..31, last), 0..24 samples ago (tolerance 6 days),
- Yearly value at HH:MM:SS on DD/MM of the year, 0..5 samples ago (tolerance 10 weeks).

By using historic filter data points it is possible to implement numerous calculations on historic values of the base data point. For example it is possible to create two filter data points with a daily sampling period recording the energy consumption at midnight, one holding the most current sample (today at midnight) and the other the previous sample (yesterday day at midnight). This is shown in Figure 9.

No.	Name	Type	Day	Time	samples ago	Subtract from
0	midnight_today	Value at hh:mm:ss of the day	N/A	00:00:00 h	0	
1	midnight_yesterday	Value at hh:mm:ss of the day	N/A	00:00:00 h	1	
2	consumed_today	Value at hh:mm:ss of the day	N/A	00:00:00 h	0	current
3	consumed_yesterday	Value at hh:mm:ss of the day	N/A	00:00:00 h	1	midnight_today

Figure 9: Example historic filters for daily consumption.

For calculating the difference between the current value and any historic value, the filter definition can be configured in a delta mode. This is a shortcut to creating a math object subtracting the historic filter data point value from the current value of the underlying data point or the value of another filter item. The example shows two results: Filter item '2' yields the consumption to-the-hour of the current day (subtract value at midnight from current value). Filter item '3' yields yesterday's consumption (subtract the value of midnight yesterday from midnight today). The resulting values are available in data points, which can be visualized or trended.

The historic filters definitions are managed by historic filter resources. These are templates and stored in the project resources. They can be applied to data points. When editing an historic filter template, all existing historic filter relations are updated accordingly. For more

information on how to configure historic filters in the Configurator please refer to Section 4.12.

---

## 3.5 I/O Technology

### 3.5.1 I/O Configuration

Each I/O in a L-IOB device has certain configuration properties which are specific to that I/O. Not all listed properties are available for all I/Os, dependent on the hardware type and certain other configuration properties. The following sections describe the I/O properties and their dependencies.

#### 3.5.1.1 Name

The name property is available for all I/Os. It is the user defined name of the I/O (e.g.: 'Temperature1').

#### 3.5.1.2 HardwareType

The hardware type property is available for all I/Os. The following hardware types are available (dependent on the L-IOB model):

- **IN Analog/Digital:** universal analog/digital input (UI) which can be configured to measure resistance, voltage, or current (with or without internal shunt). Observe that this hardware type is also used for the internal pressure sensor (e.g. 'PRESS' in LIOB-184). In this case, 0V refers to 0Pa (Pascal) and 10V to 500Pa.
- **IN Digital:** digital S0 input (DI).
- **OUT Analog:** analog 0-10 V output (AO).
- **OUT Relay 6A:** digital 6 A relay output (DO).
- **OUT Relay 10A:** digital 10 A relay output (DO).
- **OUT Relay 16A:** digital 16 A relay output (DO).
- **OUT Triac:** digital 1 A triac output (DO).

This hardware type property can not be configured of course. Refer to the Section "Specifications" of the respective product's User Manual for a detailed specification of the different I/O hardware types.

#### 3.5.1.3 SignalType

The signal type property is available for I/Os of hardware type "IN Analog/Digital". The following signal types can be configured:

- **Resistance:** measures resistance of about 1 k $\Omega$  to 100 k $\Omega$ . A value bigger than 500 k $\Omega$  is detected as a disconnected sensor (except if NoValCorr flag is set, see Section 3.5.1.14).
- **Voltage 0-10V:** measures voltage from 0 to 10 V.
- **Voltage 2-10V:** measures voltage from 2 to 10 V. A value smaller than 1.75 V is detected as a disconnected sensor (except if NoValCorr flag is set, see Section 3.5.1.14).
- **Current 4-20mA ext. Shunt:** measures current from 4 to 20 mA. A value smaller than 3.5 mA is detected as a disconnected sensor (except if NoValCorr flag is set, see Section 3.5.1.14). An external shunt of 249  $\Omega$  must be used for correct measurement.

- **Current 4-20mA int. Shunt:** measures current from 4 to 20 mA. A value smaller than 3.5 mA is detected as a disconnected sensor (except if NoValCorr flag is set, see Section 3.5.1.14). No external shunt is required. This setting is only available on some universal inputs which have an internal shunt, see Section “Specifications” of the respective product’s User Manual. Observe that changing the signal type to this setting may result in changing the setting on other universal inputs too. In this case, a Configurator message will inform the user of the changes.

### 3.5.1.4 Interpretation

The interpretation property is available for all I/Os. Depending on the hardware type and signal type, the following interpretations can be configured:

- **CustomNTC:** This interpretation is only available for universal inputs (hardware type “IN Analog/Digital”) with signal type “Resistance”. It is used for connecting a custom NTC temperature sensor to the input. The parameters of the NTC can be setup as described in Section 3.5.1.25.
- **PT1000:** This interpretation is only available for universal inputs (hardware type “IN Analog/Digital”) with signal type “Resistance”. It is used for connecting a PT1000 temperature sensor to the input.
- **NTC10K:** This interpretation is only available for universal inputs (hardware type “IN Analog/Digital”) with signal type “Resistance”. It is used for connecting an NTC10K temperature sensor to the input.
- **NTC1K8:** This interpretation is only available for universal inputs (hardware type “IN Analog/Digital”) with signal type “Resistance”. It is used for connecting an NTC1K8 temperature sensor to the input.
- **Ni1000:** This interpretation is only available for universal inputs (hardware type “IN Analog/Digital”) with signal type “Resistance”. It is used for connecting an Ni1000 temperature sensor to the input.
- **Linear:** This interpretation is only available for universal inputs (hardware type “IN Analog/Digital”). It is used to perform a linear transformation from a physical input value (resistance, voltage, or current, see Section 3.5.1.3) to the actual value, the sensor is supposed to measure (e.g. temperature, see Section 3.5.1.5). The input range is specified by the signal type:
  - Resistance: 0 ... 10 kΩ
  - Voltage 0-10V: 0 ... 10 V
  - Voltage 2-10V: 2 ... 10 V
  - Current 4-20mA ext. Shunt: 4 ... 20 mA
  - Current 4-20mA int. Shunt: 4 ... 20 mA

The output range is specified by MinValue and MaxValue, see Section 3.5.1.21. In case of signal type “Voltage 2-10V” e.g. a measured value of 2 V would be transformed into MinValue and a measured value of 10 V would be transformed into MaxValue.

- **Frequency:** This interpretation is available for all inputs. It is used to measure the frequency of the digital input resp. universal input in digital mode. The period used for measurement is specified by the MinSendTime parameter, see Section 3.5.1.23.
- **Translation Table:** This interpretation is only available for universal inputs (hardware type “IN Analog/Digital”). It is used to perform a transformation from a physical input



value (resistance, voltage, or current, see Section 3.5.1.3) to the actual value, the sensor is supposed to measure (e.g. temperature, see Section 3.5.1.5) using a transformation table. The table can be selected with TransTable, see Section 3.5.1.24. The tables can be setup for each L-IOB device as explained at the end of Section 4.15.4.

- **Frequency Table:** This interpretation is available for all inputs. It is used to perform a transformation from a frequency value (measured as described above) to the actual value, the sensor is supposed to measure (e.g. velocity, see Section 3.5.1.5) using a transformation table. The table can be selected with TransTable, see Section 3.5.1.24. The tables can be setup for each L-IOB device as explained at the end of Section 4.15.4.
- **Physical Unit Count:** This interpretation is available for all inputs. It is used to count in a certain physical unit. The unit is setup with DataType and SIUnit\_OnText, see Sections 3.5.1.5 and 3.5.1.16. The increment for each pulse is setup using the Resolution property, see Section 3.5.1.17.
- **Digital:** This interpretation is available for all I/Os. In case of an analog output, the off and on output values are specified with OffValue and OnValue, see Section 3.5.1.27.
- **Pulse Count:** This interpretation is available for all inputs. It is used to count pulses of the digital input or universal input in digital mode. It is also used for connecting the code signal of STId card readers, see Section 3.5.2. Like in the “Physical Unit Count” interpretation, a unit and an increment can be setup for calculating a value of a certain physical unit. However, in case of the “Pulse Count” interpretation, this calculation is only used for display on the L-IOB LCD UI. The data point remains a 32-bit counter.
- **Occupancy:** This interpretation is available for all inputs. See Section 3.5.1.26 for details.
- **Clock:** This interpretation is available for all interrupt-capable inputs. It is used for connecting the clock signal of STId card readers, see Section 3.5.2.
- **Card Data:** This interpretation is available for all inputs. It is used for connecting the data signal of STId card readers, see Section 3.5.2.
- **Analog:** This interpretation is only available for analog outputs (hardware type “OUT Analog”). It is used to output a voltage between 0 and 12 V. In case of using data type “Percentage” (see Section 3.5.1.5), the output value (in percent) is scaled using the MinValue and MaxValue properties (see Section 3.5.1.21). An output value of 50% would e.g. translate into an actual voltage of just in the middle between MinValue and MaxValue, an output value of 100% would translate into a voltage of MaxValue. Note that an output value of 0% is still always translated into 0V. As soon as the output value is slightly raised above 0% however, the voltage jumps to MinValue.
- **PWM:** This interpretation is available for all outputs. It is used to generate a pulse width modulated output signal. The period is setup with PWMPeriod, see Section 3.5.1.28. In case of an analog output, the off and on output values are specified with OffValue and OnValue, see Section 3.5.1.27. The output value (in percent) is scaled using the MinValue and MaxValue properties (see Section 3.5.1.21). An output value of 50% would e.g. translate into an actual pulse width of just in the middle between MinValue and MaxValue, an output value of 100% would translate into a pulse width of MaxValue. Note that an output value of 0% is still always translated into zero pulse width (always off). As soon as the output value is slightly raised above 0% however, the pulse width jumps to MinValue. This scaling is typically used to correctly control slow actuators like heating valves. If a valve e.g. requires a pre-heating time of 1 min, using a PWM period of 10 min, the MinValue can be set to 10% to compensate the pre-heating time. For further information on optimal control of your actuator in PWM mode, please refer to the corresponding data sheet. When the output value changes during a PWM period, the new value will be applied in the current period if possible. If the value decreases, the physical output will be switched off earlier, or immediately, if the newly defined point in time has already elapsed. If the value increases, the physical output will be switched off later, if it

was still switched on when the value changes. Otherwise, the new value will be applied starting with the next period. When a PWM output is in manual operating mode (see Section 3.5.1.9), a new period is started immediately whenever the manual value is changed.

- **Fading:** This interpretation is available for all analog outputs. It is equal to the “Analog” interpretation except for the behavior on a value change. The output is not immediately set to the new value but instead a slow fading from the current value to the new value is performed. The transition time used for fading from the current value to the new value (fading time) is setup in the property **DeadTime**, see Section 3.5.1.6. Since this time is constant, the transition speed depends on the difference between current and new value.
- **Ramping:** This interpretation is available for all analog outputs. It is equal to the “Fading” interpretation except that the **DeadTime** property (see Section 3.5.1.6) specifies the time it takes to ramp from the minimum value to the maximum value (ramping time). This way, the transition speed between current and new value is always equal, independent of the difference between the two values.

### 3.5.1.5 DataType

The data type property is available for all inputs with interpretation “Linear”, “Translation Table”, “Frequency Table”, “Physical Unit Count”, “Digital”, “Occupancy”, and “Switch Mode”, as well as for outputs with interpretation “Digital”, “Analog”, “Fading”, or “Ramping”. It specifies the physical quantity of the I/O. For outputs with interpretation “Digital”, the data type can be chosen between “Switch” and “Duration”. In case of “Duration”, the output has the following characteristics:

- If a positive output value is written, it is interpreted as a period (in [ms]) in which the output shall be switched on. After that period, the output is automatically switched off again. The feedback value of the output is initially set to the given period and stays there until the output is switched off. After that, the feedback value is set to 0.
- If 0 is written to the output value, the output is switched off immediately.
- If a negative output value is written, the output is switched on permanently.

### 3.5.1.6 DeadTime for Fading and Ramping

For interpretation “Fading”, the **DeadTime** property specifies the fading time from the current value to the new value. For interpretation “Ramping”, the **DeadTime** property specifies the ramping time from the minimum to the maximum value (independent of current and new value).

### 3.5.1.7 IOFunc, GroupNumber, and DeadTime for Interlocked Mode

The IO function, group number, and dead time properties are available for all digital outputs. If **IOFunc** is set to “Interlocked”, the **GroupNumber** property can be used to form different interlocked groups. Further, for each interlocked output, the **DataType** can be chosen between “Switch” and “Duration”. The digital outputs belonging to one interlocked group have the following characteristics:

- **DataType “Switch”:**
  - If “true” is written to the output value, the output is switched on permanently.
  - If “false” is written to the output value, the output is switched off immediately.
- **DataType “Duration”:**

- If a positive output value is written, it is interpreted as a period (in [ms]) in which the output shall be switched on. After that period, the output is automatically switched off again. The feedback value of the output is initially set to the given period and stays there until the output is switched off. After that, the feedback value is set to 0.
- If 0 is written to the output value, the output is switched off immediately.
- If a negative output value is written, the output is switched on permanently.
- Whenever an output is switched on (as described above), it is checked before if another output in the same interlocked group is already switched on. In this case, the other output is switched off immediately. Then, for a period setup with **DeadTime**, all outputs of the group remain off. After that, finally the new output is switched on (either for a certain period or permanently).

The interlocked mechanism can be used e.g. for sunblind motors where it must be ensured that the up and down motors are never active at the same time.

### 3.5.1.8 IOFunc, GroupNumber, and SubGroupNumber for Card Reader Mode

The IO function, group number, and sub group number properties are available for all inputs used for connecting the signals of an STId card reader, see Section 3.5.2.

### 3.5.1.9 OperatingMode, OverrideValue, and DefaultValue

The operating mode property is available for all I/Os. For inputs, the **OperatingMode** property has the following meaning:

- **Disabled:** The physical input is disabled and the data point is set to **DefaultValue**. This can be used to disable unused inputs.
- **Auto:** The input measures the value from the connected sensor.
- **Override:** The physical input is disabled and the data point is set to **OverrideValue**.
- **Manual:** The physical input is disabled and the data point is set by the user on the L-IOB LCD UI. This can be used to simulate input values for the logic application.

The **DefaultValue** is also used for inputs, when no sensor value has yet been read from the physical input or a sensor error is detected. For outputs, the **OperatingMode** property has the following meaning:

- **Disabled:** The output value set by the logic application is ignored and the physical output (as well as the feedback value) is set to **DefaultValue**.
- **Auto:** The physical output (and feedback value) is set as requested by the logic application.
- **Override:** The output value set by the logic application is ignored and the physical output (as well as the feedback value) is set to **OverrideValue**. This can be used e.g. for providing a constant supply voltage to a sensor.
- **Manual:** The output value set by the logic application is ignored and the physical output (as well as the feedback value) is set by the user on the L-IOB LCD UI. This can be used to test actuators.

### 3.5.1.10 Persistent Flag

The persistent flag is available for all outputs. For the local outputs of a L-IOB I/O Controller, it has no effect, since persistency is handled by the data point layer in this case, see Section 3.1.4. For remote LIOB-45x/55x devices, it specifies the behavior of the L-IOB outputs after a power cycle or when the L-IOB device loses connection to the L-IOB host. If it is set, the output is set to the last stored value in the mentioned scenarios. If it is cleared, the output is set to the DefaultValue (see Section 3.5.1.9). Since the output values are only stored in the L-IOB device approx. every 20 minutes, it is possible that even in the first case, the output value temporarily changes.

### 3.5.1.11 Invert Flag

The invert flag is available for all I/Os in digital/PWM mode or where the input is used to count pulses or detect occupancy. In the first case, the invert flag is used to invert the input or output. In the second case, the flag specifies whether the pulse shall be detected at the positive or negative edge. For occupancy detection, the flag specifies the occupied state of the sensor. Observe that if the SignalType is set to "Resistance" (see Section 3.5.1.3), the Invert flag is set by default. This is because the ON / OCCUPIED state usually refers to a low resistance value ("CLOSED" contact) whereas the OFF / UNOCCUPIED state usually refers to a high resistance value ("OPEN" contact).

### 3.5.1.12 AnalInvert Flag

The analog invert flag is available for all voltage or current inputs with interpretation "Linear" or "Translation Table" (see Section 3.5.1.4) and for all outputs with interpretation "Analog", "Fading", or "Ramping". It inverts the analog range between the MinValue and the MaxValue. For a 0-10V sensor with linear interpretation e.g., 0V would result in a live value of MaxValue and 10V results in the MinValue.

### 3.5.1.13 Sqrt Flag

The square root flag is available for all voltage, current, or pressure inputs with interpretation "Linear" or "Translation Table" (see Section 3.5.1.4). It performs a square root operation on the signal range. The formulas for the different sensor signal types are listed below:

- 0-10V Sensor or Pressure Sensor:  $Usqrt = \sqrt{U * 10V}$
- 2-10V Sensor:  $Usqrt = 2V + \sqrt{(U - 2V) * 8V}$
- 4-20mA Sensor:  $Isqrt = 4mA + \sqrt{(I - 4mA) * 16mA}$

Values below the signal range (below 0V, 2V, or 4mA) are not converted. The  $Usqrt$  or  $Isqrt$  value is then used instead of the  $U$  or  $I$  value for further calculation (linear transformation or translation table). The square root flag can be used e.g. to easily calculate a flow value instead of a differential pressure.

### 3.5.1.14 NoValCorr Flag

The NoValCorr flag is available for all inputs with signal type "Resistance", "Voltage 2-10V", "Current 4-20mA ext. Shunt", or "Current 4-20mA int. Shunt" and interpretation "CustomNTC", "PT1000", "NTC10K", "NTC1K8", "Ni1000", "Linear", or "Translation Table". If it is set, the detection of disconnected sensors is switched off and every measured value is processed, see also Section 3.5.1.3.

### 3.5.1.15 PulseTime Flag

The pulse time flag is available for all inputs with interpretation "Pulse Count" or "Physical Unit Count" (see Section 3.5.1.4). It activates the pulse time data point.

### 3.5.1.16 SIUnit\_OnText and USUnit\_OffText

The SI unit / on text and US unit / off text properties are available for all I/Os. In case of analog values, the **SIUnit\_OnText** property specifies the unit in SI mode, in case of digital values, it specifies the ON text (shown when the digital I/O is active). In case of analog values, the **USUnit\_OffText** property specifies the unit in US mode, in case of digital values, it specifies the OFF text (shown when the digital I/O is inactive). Using the Configurator (**Project Settings**), the user can choose between SI and US units.

### 3.5.1.17 Resolution

The resolution property is available for all I/Os with an analog data type. It specifies the resolution of the value display in the L-IOB LCD UI as well as the step width for the L-IOB jog dial when manually setting an analog value or property of that I/O. For the interpretations “Physical Unit Count” and “Pulse Count”, it also specifies the increment for each pulse, see Section 3.5.1.4.

### 3.5.1.18 MultUS and OffsUS

The US Multiplier and Offset properties are available for all I/Os with an analog data type and are calculated automatically. Using the Configurator, the user can choose between SI and US units. In case of US units, the I/O values displayed in the L-IOB LCD UI are converted using these properties ( $\text{ValueUS} = \text{ValueSI} * \text{MultUS} + \text{OffsUS}$ ). The US unit is setup in the **USUnit\_OffText** property, see Section 3.5.1.16. Observe that the properties setup in the Configurator as well as the connected data points will still always carry SI units.

### 3.5.1.19 DisplayOnSymbol and DisplayOffSymbol

The display on/off symbol properties are available for inputs with Interpretation “Digital” (see Section 3.5.1.4). They are used to specify the display of the two digital states ON and OFF. For both these states, the following symbols can be chosen:

- **OPEN**: open switch symbol
- **CLOSED**: closed switch symbol
- **OK**: check symbol
- **ERROR**: exclamation mark symbol

### 3.5.1.20 Offset

The offset property is available for inputs with an analog data type. It is added at the end of the calculation to the (already processed) value. This way, e.g. temperature sensors can be calibrated in each room without changing the common application. Observe that in the LCD UI, the resulting input value will be displayed next to the offset value to simplify calibration.

### 3.5.1.21 MinValue and MaxValue

The minimum and maximum value properties are available for all I/Os with an analog data type (except for Interpretation “Physical Unit Count”) as well as for inputs with interpretation “Digital”, “Occupancy, or “Switch Mode”. They are used for:

- scaling inputs with interpretation “Linear” (see Section 3.5.1.4),
- scaling outputs with interpretation “Analog”, “PWM”, “Fading”, or “Ramping” (see Section 3.5.1.4),
- scaling the bar icon in the L-IOB LCD UI,

### 3.5.1.22 COV and MaxSendTime

The **Change-Of-Value** property is available for all inputs with an analog data type. It is used to specify a minimum delta value required to trigger a data point update. If the input value only changes within a range of **-COV** to **+COV**, no update is generated. In any case, after **MaxSendTime** an update is generated to be sure to get the latest value at least at some point in time. If COV is set to 0, every input value change generates an update of the attached data point.

Observe that the **MaxSendTime** property is available for all I/Os (analog and digital) to act as a heartbeat function. For outputs, it is applied both on the output value (heartbeat *to* external L-IOB device) and feedback value (heartbeat *from* L-IOB device or local I/O). Whenever an update is sent from an I/O because of a max send time, the connected data point (input or feedback value) is updated too, even if there is no value change. In cases where this behavior is not desired, the “Analog Point COV Increment” or “Only notify on COV” property of the corresponding host data point must be set. See Section 4.2 for where these data point settings can be made.

### 3.5.1.23 MinSendTime

The minimum send time property is available for all I/Os. It specifies the minimum time that has to pass before a new update of an input or output feedback value is generated. If MinSendTime is set to 0, all changes of the inputs or output feedbacks immediately generate updates. For inputs with interpretation “Frequency” or “Frequency Table” (see Section 3.5.1.4), the MinSendTime property also specifies the period used for frequency measurement.

### 3.5.1.24 TransTable

The translation table property is available for all inputs with interpretation “Translation Table” or “Frequency Table” (see Section 3.5.1.4). It specifies the translation table which shall be used for the translation. The configuration of translation tables is explained at the end of Section 4.15.4.

### 3.5.1.25 NTC\_Rn, NTC\_Tn, and NTC\_B

The Rn, Tn, and B properties are available for inputs with interpretation “Custom NTC” (see Section 3.5.1.4). Tn is specified in degree Celsius. Rn is the resistance of the NTC temperature sensor at the temperature Tn. The temperature value is calculated using the formula:

$$T = B * (Tn + 273.16 \text{ degC}) / (B + \ln(R / Rn) * (Tn + 273.16 \text{ degC})) - 273.16 \text{ degC}.$$

T is the calculated temperature in degree Celsius and R is the measured resistance of the NTC temperature sensor.

### 3.5.1.26 HoldTime and DebounceTime

These properties are available for all inputs where the Interpretation is set to “Occupancy”. The HoldTime is also available for the data signal of STId card readers, see Section 3.5.2. The DebounceTime is also available for inputs with interpretation “Digital”.

In interpretation “Occupancy”, the occupied state is detected using a sensor which becomes active (e.g. closes a contact) or creates pulses whenever the room is occupied. These states are converted to an occupancy value in the following way:

- When the occupied state (or a pulse) is detected, the value changes to OCCUPIED and stays there for at least the **HoldTime**.
- As long as the sensor stays in the occupied state or whenever new pulses are detected during the **HoldTime**, the timer for the **HoldTime** is started again.

- When the sensor stays in the unoccupied state until the **HoldTime** exceeds, the state goes back to UNOCCUPIED.
- From this moment on, all pulses from the sensor are ignored for as long as the **DebounceTime** lasts. This is useful e.g. when light is switched off due to detecting the UNOCCUPIED state which leads to new pulses of the sensor and in turn leads to switching on the light again. To break this loop, the debounce time is used.

In case of interpretation “Digital”, the **DebounceTime** is used for spike suppression. It specifies the maximum duration of an unwanted spike to be suppressed.

### 3.5.1.27 OffValue and OnValue

The off and on value properties are available for analog outputs in digital mode. They specify the physical values (voltages) to be output for the OFF (inactive) and ON (active) state.

### 3.5.1.28 PWMPeriod

The PWM period property specifies the period (in seconds) for outputs with Interpretation “PWM” (Pulse Width Modulation), see Section 3.5.1.4.

### 3.5.1.29 NominalPower

The nominal power property is available for all outputs. It specifies the nominal resp. average expected power consumption of the device or appliance (e.g. lamp) connected to the output. For digital outputs it specifies the average power when the output is activated (e.g. relay closed), for analog outputs it specifies the average power when the output is set to 10 V. The nominal power property is used to calculate the energy count data point of the output.

## 3.5.2 STId Card Reader Mode

The L-IOB devices support STId card readers running the ISO2 protocol. Refer to Section “Specifications” of the respective product’s User Manual and the following sections for information on which L-IOB models support STId card readers. The card readers have three signals which must be connected to inputs on the L-IOB device, as explained in the following sections.

### 3.5.2.1 Code Signal

The code signal of the card reader must be connected to a universal or digital input of the L-IOB device. The following properties must be set for that input:

- SignalType (if universal input): “Voltage 0-10V”.
- Interpretation: “Pulse Count”.
- IOFunc: “Cardreader ISO2”.
- GroupNumber: must be equal for all three signals of one card reader.
- SubGroupNumber: will automatically be set to “Code”.
- Invert: checked if signal is low active, check data sheet of card reader.

In its live value, this L-IOB input will represent the number of codes read from the card reader.

### 3.5.2.2 Data Signal

The data signal of the card reader must be connected to a universal or digital input of the L-IOB device. The following properties must be set for that input:

- SignalType (if universal input): “Voltage 0-10V”.
- Interpretation: “Card Data”.
- IOFunc: will automatically be set to “Cardreader ISO2”.
- GroupNumber: must be equal for all three signals of one card reader.
- SubGroupNumber: will automatically be set to “Data”.
- Invert: depends on implementation of card reader, check data sheet.
- HoldTime: specifies the time, a new code remains in the L-IOB data point. After this time, the data point is set back to “0xBF ...”, which means “not available”. If the HoldTime is set to 0, the last read value remains until a new value is read.

In its live value, this L-IOB input will represent the read code in a 20-byte array (40 decimal digits).

### 3.5.2.3 Clock Signal

The clock signal of the card reader must be connected to a interrupt-capable universal or digital input of the L-IOB device. The corresponding interpretation “Clock” will only be available in the Configurator software, if the input is interrupt-capable. The following properties must be set for that input:

- SignalType (if universal input): “Voltage 0-10V”.
- Interpretation: “Clock”.
- IOFunc: will automatically be set to “Cardreader ISO2”.
- GroupNumber: must be equal for all three signals of one card reader.
- SubGroupNumber: will automatically be set to “Clock”.
- Invert: checked if signal is low active, check data sheet of card reader.

The live value of that L-IOB input will not deliver any useful data.

## 3.5.3 I/O Data Points

This section describes the I/O data points available in a LOYTEC device model with local I/Os. For data points which can be read and written, value data points will be created. For each I/O, the most basic data points are created automatically (input value, output value, feedback). In the Configurator, the user can choose to create lots of additional data points on the common and I/O level.

### 3.5.3.1 Common I/O Data Points

The common local I/O data point names are preceded with ‘L1\_1’. There is only one common local I/O data point, which is not assigned to a specific I/O:

- **ManualMode:** flag is set if at least one I/O is in manual mode.

If a LOYTEC device is extended by a LIOB-45x/55x module over the LIOB-IP bus, the common I/O data points for the LIOB-45x/55x module are preceded with ‘L2\_1’, e.g. ‘L2\_1\_ProductCode’. The following common I/O data points exist for a connected LIOB-45x/55x device:



- **ProductCode:** the product code of the connected LIOB-45x/55x, e.g. 'LIOB-450'.
- **DeviceName:** name of the LIOB-45x/55x device.
- **NID:** unique Node ID of the LIOB-45x/55x device.
- **StationID:** must always be 1.
- **PinCode:** pin code for the LCD UI of the LIOB-45x/55x device.
- **ErrorMask:** Contains the last error code of the LIOB-45x/55x device:
  - 0 ... OK (no error)
  - 23 ... Wrong L-IOB device type
  - 25 ... Firmware version too low
  - 28 ... Address mismatch (device not correctly commissioned)
  - 43 ... Device is unconfigured
  - 49 ... Device needs configuration run
  - 51 ... Station ID mismatch
- **CfgExists:** flag is set if configuration for this device exists (always set).
- **Enabled:** flag is set if this device is enabled.
- **Online:** flag is set if this device is online.
- **NotDetected:** flag is set if this device could not be detected.
- **EnableUpgrade:** flag is set if firmware upgrade is allowed for this device.
- **AlternativeUnit:** flag is set if this device shows US units (instead of SI units).
- **ManualMode:** flag is set if at least one I/O is in manual mode.
- **FMWVersion:** firmware version of this device.
- **FMWTimestamp:** firmware build time stamp (date and time) of this device.
- **Serial:** serial number of this device.
- **LastRebootTimestamp:** date and time of last reboot of this device.
- **SystemTemp:** current system temperature of the device.
- **SystemVoltage:** current supply voltage of this device.
- **CPUload:** current CPU load of this device.

### 3.5.3.2 I/O specific Data Points for Inputs

The I/O specific data point names are preceded with 'L1\_1' or 'L2\_1' and the I/O terminal name, e.g. "L1\_1\_UI5\_**Input**".

- **Input:** current value of the input as measured and interpreted by the L-IOB device, if the operating mode is set to "Auto". This data point will go out-of-service, if the sensor is detected disconnected. If the operating mode is set to a mode different than "Auto", the

input value will be set to the corresponding manual, override, or default value, see Section 3.5.1.9.

- **IOStatus**: current status of input. This data point will go from “OK” to “Disconnected”, if the sensor is disconnected.
- **PulseTime**: time between the last two pulses for signal interpretation “Pulse Count” or “Physical Unit Count” (see Section 3.5.1.4). This can be used to quickly detect a change of the derivative of the physical value, e.g. a change of the electric power if the measured physical value is electric energy. Note that the PulseTime data point must be activated via the PulseTime flag, see Section 3.5.1.12.
- **OperatingMode**: see Section 3.5.1.9.
- **OverrideValue**: see Section 3.5.1.9.
- **DefaultValue**: see Section 3.5.1.9.
- **Offset**: see Section 3.5.1.20.
- **MinValue**: see Section 3.5.1.21.
- **MaxValue**: see Section 3.5.1.21.
- **HoldTime**: see Section 3.5.1.26.
- **DebounceTime**: see Section 3.5.1.26.
- **PulseCountInit**: when this data point is written, the pulse count is reset to the written value. This applies to inputs with Interpretation “Pulse Count” or “Physical Unit Count”, see Section 3.5.1.4.

### 3.5.3.3 I/O specific Data Points for Outputs

The I/O specific data point names are preceded with ‘L1\_1’ or ‘L2\_1’ and the I/O terminal name, e.g. “L1\_1\_DO4\_**Output**”.

- **Output**: current value of the output as set by the logic application.
- **Feedback**: the feedback data point will always be set to the current physical value of the output. See Section 3.5.1.9 for details.
- **IOStatus**: current status of output. This data point always has the value “OK”.
- **RunHours**: total time the digital output was switched on.
- **EnergyCount**: energy consumption of the device or appliance (e.g. lamp) connected to the output, see also Section 3.5.1.29.
- **SwitchCycles**: Number of switching cycles of the digital output. This is useful for estimating the expected remaining life time of a relay. Observe that this data point is never reset, not even by a reset to factory defaults.
- **OperatingMode**: see Section 3.5.1.9.
- **OverrideValue**: see Section 3.5.1.9.
- **DefaultValue**: see Section 3.5.1.9.

- **Offset:** see Section 3.5.1.20.
- **MinValue:** see Section 3.5.1.21.
- **MaxValue:** see Section 3.5.1.21.
- **PWMPeriod:** see Section 3.5.1.28.
- **RunHoursInit:** when this data point is written, the RunHours data point is reset to the written value.
- **EnergyCntInit:** when this data point is written, the EnergyCount data point is reset to the written value.
- **NominalPower:** see Section 3.5.1.29.

### 3.5.4 Default I/O Configuration

Every L-IOB device is shipped with a default I/O configuration, which can be used right away. This configuration is dependent on the hardware type (see Section 3.5.1.2) of the corresponding I/O:

- **Universal Inputs (UI):** measure voltage between 0V and 10V. The interpretation is 'Linear' with MinValue 0V and MaxValue 10V.
- **Digital Inputs (DI):** act as switch inputs. The interpretation is 'Digital'.
- **Pressure Sensors (PRESS):** measure pressure between 0Pa and 500Pa (Pascal). The interpretation is 'Linear' with MinValue 0Pa and MaxValue 500Pa.
- **Analog Outputs (AO):** deliver a voltage between 0V and 10V according to the given percentage level. The interpretation is 'Analog' with MinValue 0V and MaxValue 10V.
- **Digital Outputs (DO):** relays or triacs close when the given value goes active and open when the value goes inactive. The interpretation is 'Digital'.

---

## 3.6 CEA-709 Technology

### 3.6.1 CEA-709 Device

A CEA-709 device model implements a LONMARK device which exposes network variables (NVs) and configuration properties (CPs) from the CEA-709 network to data points in the automation server.

LOYTEC devices can have one physical FT port and one IP-852 port, which is accessible over Ethernet. On a device model with the RNI option, the automation server node is internally connected either to the FT port or to the IP-852 port. Which one is used can be configured in the CEA-709 port configuration of the Web interface. The schematic is shown in Figure 10 (a). If configured for the FT channel, the device provides an RNI for remote access to the FT channel. The RNI can be used to commission nodes and trouble-shoot communications on the FT channel.

A device model with the CEA-709 router connects the FT port and the IP-852 port. On such a device the automation server node is always internally connected to the FT port. The schematic is shown in Figure 10 (b).




Figure 10: (a) LonMark node on a device with RNI, (b) LonMark node and router on a device with router option.

If the automation server shall only expose network variables from the local FT channel and there is no IP-852 backbone, then the router is not needed. In this case, the user needs to commission only the device's server node. To attach the FT channel to an IP-852 backbone, the CEA-709 router in the device needs to be commissioned. Refer to the LOYTEC Device User Manual [1] for more information on the built-in router and configuration server.

### 3.6.2 CEA-709 Data Points

Data points in the CEA-709 network are known as network variables (NVs). They have a direction, a name, and a type, known as the standard network variable type (SNVT) or user-defined network variable type (UNVT). In addition to NVs, also configuration properties (CPs) in the CEA-709 network can be accessed as data points. Both standard CP types (SCPTs) and user-defined CP types (UCPTs) are supported.

The typical procedure in configuring the device consists of the following steps:

1. Select the data points of the network to be used on the device (e.g., select the NVs in the CEA-709 network nodes).
2. Create necessary registers, math objects.
3. Select those data points on the device, which shall be exposed as OPC tags or as PLC variables.

The CEA-709 NVs on the device can be created in three different ways:

- **Static NV:** For each selected NV on the network there is a static NV created on the device. This NV can be bound to the NV on the network. Note that adding static NVs to the device results in a change to the default XIF file. The device is assigned a new "model number" to reflect this change (see Section 3.6.3). Static NVs are the way to use NVs in non-LNS systems, where bindings are used for the NVs instead of polling.
- **Dynamic NV:** For each selected NV on the network there is a dynamic NV created on the device. Compared to static NVs, dynamic NVs do not change the XIF interface of the device. The dynamic NVs are created by the network management tool. Currently, only LNS-based tools can manage dynamic NVs. As for static NVs, with dynamic NVs it is possible to use bindings instead of polling.
- **External NV:** The selected NVs on the network are treated as external NVs to the device. The device doesn't create any NVs on the device, but instead uses polling to read from those NVs and explicit updates to write to the NVs. Therefore, no bindings are necessary for external NVs. For input data points using external NVs however, a poll cycle must be configured. If not configured explicitly, a default poll cycle of 60 sec. is chosen. The default poll cycle can be changed in the project settings menu. Note, that the receive timeout option cannot be used with external NVs.

Based on the NV the data point is derived from, the following kinds of data points are created:

- Simple NVs that hold only one scalar value, e.g., SNVT\_amp: Those kinds on NVs are represented as analog data points. The data points holds the current value, NV scaling factors are applied.
- Simple NVs based on an enumeration, e.g., SNVT\_date\_day: Enumeration types result in multi-state data points. They represent the state of the NV.
- Structured NVs that consists of a number of fields, e.g., SNVT\_switch: All structured NVs are represented as user point. That is, the data point is structured similar to the NV it is based on. Beneath the user data point, the individual structure fields are presented as “sub-data points”.

For more information on the different types of network variables and their implications please refer to the application note in Section 18.2. For CPs the allocation type “File” is used.

### 3.6.3 Static Interface Changes

The device can be configured to use static NVs. Unlike dynamic NVs, static NVs cannot be created in the network management tool. They are part of the static interface and are usually compiled into the device. When static NVs are used, the device changes its static interface and boots with a new one.

Each time the static interface of the device changes (i.e., static NVs are added, deleted, or modified), the model number is changed. The model number is the last byte of the program ID. Thus, a change in the static interface results in a change of the program ID and a new device template needs to be created in the network management tool. A new device template usually means that the device has to be deleted and added again in the database. All bindings and dynamic NVs have to be created again for the new device.

When the Configurator software is connected via LNS, it supports the process of changing the device template for the new static interface. It automatically upgrades the device template of the LOYTEC device in the LNS database and restores the previous bindings and dynamic NVs. If the LOYTEC device is not configured with an LNS-based tool, this support is not available. The new static interface is only available in a new XIF file or by uploading the new device template into the database. For more information on the static interface and device templates please refer to the application note in Section 18.2.

---

**Important!**

*It is not recommended to mix manually created, dynamic NVs outside the virtual function block and static NVs. In this case, the Configurator is not able to restore all manually created dynamic NVs.*

---

The Configurator supports model number ranges for different projects. By assigning a model number range to a configuration, the Configurator can draw a new model number from within the specified range. This feature is useful, if different device classes shall be deployed and the model numbers need to be coordinated between installers. In this case, the installers can agree on ranges they are free to use. The model number range can be set on the data points tab as shown in Figure 11.




Figure 11: Setting a model number range in for a project.

### 3.6.4 Limitations for Local CEA-709 Schedulers

CEA-709 schedulers and the CEA-709 calendar adhere to the LONMARK standard objects. For CEA-709, certain restrictions exist that need to be kept in mind. Attached data points can either represent an entire NV or individual elements of a structured NV. CEA-709 schedulers may have several different groups of data points attached, i.e., the value preset may consist of more than one element. For example, a CEA-709 scheduler might schedule a SNVT\_temp and a SNVT\_switch and have 3 elements in each value preset as depicted in Figure 12.

Datapoint	Description	Location	Group	Default	day	night
nvo_setpoint		LINX-110.CEA709 Port.Datapoints -	▼	0.00	21.00	16.00
nvo_switch.value		LINX-110.CEA709 Port.Datapoints -	▼	0.00	0.00	50.00
nvo_switch.state		LINX-110.CEA709 Port.Datapoints -	▼	0.00	0.00	1.00

Figure 12: Example value presets in CEA-709 schedulers.

Priorities of exception days in a CEA-709 scheduler range from 0 (the highest) to 126 (the lowest). The value 127 is reserved as a default for weekdays.

Further, the implementation as LONMARK standard objects requires the use of configuration properties. If the number of CEA-709 schedulers or their capacities for daily schedules and value presets is changed, the resource and static interface of the CEA-709 port changes. The resources reserved for LONMARK calendar and scheduler objects can be changed in the project settings (see Section 5.1.3). When downloading a project, the software verifies if sufficient resources have been configured. If it detects a problem, the user is notified to update the project settings. The Auto-Set feature automatically selects the right amount of resources. The limitations are summarized in Table 6.

Limitation for number of	Default/Max
Scheduled events (total over all priorities)	64/250
Date entries (total over all calendar patterns)	100/500
Calendar patterns in the calendar	5/25

Table 6: Limitations of local CEA-709 scheduler/calendar objects

### 3.6.5 Limitations for CEA-709 Alarm Servers

Local CEA-709 alarming supports only one alarm server object. This alarm server object is represented by the device's LONMARK node object and facilitates the SNVT\_alarm2 output network variable. Acknowledging alarms in the alarm server is adhering to the LONMARK specification and relies on the RQ\_CLEAR\_ALARM mechanism.

### 3.6.6 Limitations for Local CEA-709 Trends

Local CEA-709 trend objects support trending multiple data points in all trend modes, interval, COV, and trigger, including aligned intervals. The enable data point is also supported. All data points can be NVs, registers or of any other technology. There is no LONMARK object linked to the trend object. Consequently, trend data cannot be accessed over a LONMARK mechanism.

### 3.6.7 Dynamic Polling in CEA-709

External input NVs in CEA-709 rely on polling. Static polling can be configured by setting the pollycycle (see Section 3.1.2). In addition, this technology also supports dynamic polling. If the data point Web UI or L-WEB requires a refresh on those NVs, which are otherwise not used, polling is activated at the configured pollycycle. If those data points go out of scope, the polling on the external input NVs is stopped. If no polling is needed at all, the pollycycle setting can be left at zero.

Dynamic polling has no effect on static or dynamic input NVs. These NVs are supposed to have bindings and rely on update events. If static polling is configured via the pollcycle, no change of the pollcycle is made at run-time.

### 3.6.8 CEA-709 Data Points in Connections

All types of CEA-709 data points can be used in local and global connections. All CEA-709 data points can be sources for auto-generating target technology data points. There is a special treatment of the SNVT\_switch, which will generate a binary data point in the target technology.

CEA-709 can also be a technology target for auto-generation (see Section 3.3.3). In this case static NVs with SNVTs are created only. If the source is an input, an NVO will be generated, otherwise an NVI. If the source data point is analog, the SNVT is chosen with the best-matching engineering unit. In many cases there exist SNVTs in fixed-point and floating point versions. The default can be edited in the CEA-709 project settings. If the source is a multi-state data point, a SNVT\_count is generated and the source state map is used. If the source is a binary data point, a SNVT\_switch is created. In the auto-generate preview the user can review and change the desired SNVTs individually before generating the data points.

---

## 3.7 BACnet Technology

### 3.7.1 BACnet Data Points

Data points in the BACnet technology are known as BACnet objects. They have a specific type (e.g. analog input or binary output) and a set of properties, which describe the data point more closely. The actual value is stored in the “Present\_Value”.

On the device, there exist two classes of BACnet data points:

- **BACnet server objects (SO):** These BACnet objects configured by the Configurator software to be allocated *locally* on the device. These objects can be accessed by the BACnet building control system or operating workstations. They support COV subscriptions to deliver value changes in an event-driven way. Local server objects can be created as AI, AO, AV, BI, BO, BV, MI, MO, MV, Accumulator, Pulse Converter, Loop, Large Analog Value, Integer Value, Positive Integer Value, Character String Value, Octet String Value objects.
- **BACnet client mappings (CM):** For certain applications, it is necessary that the device acts as a BACnet client. This functionality can be configured by activating a *client mapping*. Client mappings can be of the type *Read*, *Write* or *Value*. The read client mapping reads out data from a server object, the write client mapping writes values to a server object, and the value client mapping does both. When reading values a read mode can be specified: *Poll*, *COV*, *COV unsol*, or *Auto*. This specifies how the BACnet client accesses other BACnet objects on the BACnet network. The *Auto* mode determines the best way (poll or COV) to talk with other server objects. *Poll* is used for objects that need to read data from other BACnet objects in a periodic manner. *COV* is used to subscribe for COV at other BACnet objects in order to get updates in an event-driven fashion. The *COV unsol* mode lets the client mapping listen for unsolicited COV broadcasts. In this mode, it does neither subscribe nor poll the object. The value client mapping refers to a combined read and write client mapping. When writing a value to this client mapping, the value is written to the remote BACnet object. As soon as the Present\_Value of the remote BACnet object is updated, the value is transferred back using the selected read mode.

The direction of BACnet server objects deserves a closer look. The direction specified for data points in the Configurator software always refers to the network view of the communication. The definition of input and output objects in BACnet, however, refers to the process view, which is opposite to the network. Therefore, a BACnet analog input (AI) object

is modeled as an analog output data point. The direction of client mappings naturally refers to the network communication. Therefore, a write client mapping is represented as an analog output data point.

In BACnet commandable objects can be written with values at a certain priority. The value with the highest priority is in effect. When revoking a written value, the NULL value is written. This takes back the value. When all written values are withdrawn, the Relinquish\_Default value is in effect.

For BACnet server objects the write priority defines which priority is written to the commandable server object. It is possible to create additional *priority write* data points, which can be configured to write at other priority levels. This may be necessary, if two parts of an application are required to write with two different priorities. To know, which priority slots are used in a commandable object, additional *priority read* data points can be added. They reflect the value on a given priority slot.

The default value feature of a data point is mapped to the Relinquish\_Default property for commandable objects. For BACnet objects, which are not commandable, the Present\_Value is initialized with the specified default value.

Analog BACnet objects have no fixed network unit. Depending on the chosen unit system, the analog BACnet object will be created with the specified metric (SI) or U.S. unit in the Engineering\_Unit property. This means that the BACnet server object changes its representation on the BACnet network (i.e., engineering unit and value), when the unit system is changed on the device.

### 3.7.2 BACnet Alarming

BACnet alarming on the device is based on the *intrinsic reporting* mechanism. Currently, algorithmic reporting is not supported. Alarm conditions can only be applied to data points, which map to BACnet server objects. If defined, the intrinsic reporting properties of the underlying BACnet objects are enabled. Alarm conditions can be specified for analog input, output, value objects (AI, AO, AV), for binary input, output, value objects (BI, BO, BV), and for multi-state input, output, value objects (MSI, MSO, MSV). With BACnet intrinsic reporting alarm conditions on binary output (BO) and multi-state output (MSO) can only be feedback alarms. These restrictions do not apply, if the alarm condition reports to a generic alarm server.

Alarm servers in the BACnet technology are mapped to BACnet Notification Class (NC) objects. Each alarm server is mapped to one NC. The notification class number can be configured in the object instance number property of the alarm server object.

Remote alarms in the BACnet technology refer to a remote NC object. When the device starts up, the remote alarm object reads out the current alarm state of the remote NC and reporting objects. To get notified about alarm transitions during run-time, the device registers in the Recipient\_List of the remote NC object.

Some BACnet devices do not send a usable text in their alarm notification messages. For those devices the alarm client provides the option **Ignore alarm message text**. If this option is enabled, the alarm client ignores the message text of an alarm notification and reads the **EventMessageText** (or **Description**) property of the alarmed object instead.

### 3.7.3 BACnet Schedulers and Calendars

BACnet schedulers and the BACnet calendar adhere to the standard schedule and calendar object in BACnet. For each scheduler a BACnet Schedule object is created. The calendar deserves a closer look. For each calendar pattern a BACnet Calendar object is created. The visible calendar on the Web UI is therefore a collection of BACnet calendar objects. Each calendar pattern therefore is associated with a BACnet object instance number. The calendar pattern "Holidays" is for example visible as CAL,1 on the BACnet port.



The BACnet schedule object allows only objects of one selected data type to be scheduled. Therefore, schedulers on BACnet can only schedule one class of data points (e.g., only one group of analog data points). As a consequence, the value preset in BACnet always has only one element. The name of the value preset is not stored in BACnet. It is not accessible over the BACnet network, either. Therefore, a default name is created, such as '22 °C' for an analog value. An example of two scheduled BACnet objects is shown in Figure 13. With the extended BACnet features enabled in the project settings, a preset label can be assigned to a specific scheduled value. For example the value '16 °C' can be assigned 'night'. Click in the column header and type the desired text.

Datapoint	Description	Location	Group	Default	22 °C	night
bac_temp1	temp	BACnet Port.Datapoints 1	0.00	22.00	16.00	
bac_temp2	temp	BACnet Port.Datapoints 1	0.00	22.00	16.00	

Figure 13: Example value presets in BACnet schedulers.

Priorities of exception days in a BACnet scheduler range from 1 (the highest) to 16 (the lowest). Weekdays in BACnet have no priority.

Changing the number of calendar patterns in a BACnet calendar can only be done in the BACnet project settings (see Section 6.1.1) and not during run-time. The individual calendar pattern entries in the calendar patterns can be changed at run-time. Therefore, it is advisable to reserve a suitable number of calendar patterns in a BACnet calendar and leave them empty if not needed immediately. The limitations of scheduled events and calendar patterns are summarized in Table 7.

Limitation for number of	Default/Max
Scheduled events	40
Scheduled events (at weekday priority)	24
Date entries per calendar pattern	40
Calendar patterns in the calendar (configured in project settings)	10/25

Table 7: Limitations of BACnet scheduler/calendar objects

### 3.7.4 BACnet Trend Logs

Trending in the BACnet technology is based on the BACnet TrendLog object. A number of restrictions apply to trend log objects in BACnet. Trend log objects must be created by the Configurator software. These objects are accessible over the BACnet network for other BACnet devices and operator workstations (OWS). All configuration properties can be modified by the Configurator software as well as an OWS. The number of trend log objects cannot be changed at run-time. Therefore, if it is intended that an OWS configures the trend logs, a suitable number of empty trend log objects (i.e., without attached data points) must be created in the Configurator software.

In BACnet trend logs, only one data point can be trended per trend log object. The trended data point can be either a local BACnet server object or a remote BACnet object accessed through a client mapping, showing the referenced property for trending to the OWS. Data points of other technologies and the min/max/avg algorithms can be trended as generic data points without having a BACnet property reference.

BACnet trend logs support interval, COV and trigger-mode logs, aligned intervals are available in interval mode. The setting linear and ring-buffer logging is mapped to the Stop\_When\_Full property of the underlying BACnet trend log object. This setting in the Configurator software is a default and can be overridden by writing to the Stop\_When\_Full property by the OWS. The trend log object adheres to BACnet revision 12.

If an enable data point is configured by the Configurator software, the Log\_Enable property is written with the value of that data point. If no enable data point is configured, the Log\_Enable is TRUE as a default and can be modified over the network.

The fill-level action is mapped to generating a buffer event notification in the BACnet trend log object. The fill-level trigger can still be used for e-mails even if no notification class is configured in the BACnet trend log object. The fill-level percentage maps to the Notification\_Threshold property. The percentage setting in the Configurator software is a default and can be changed by the OWS over the network.

The Notify\_Type and Notification\_Class BACnet properties are usually written by the OWS. If they shall be defined by the data point configuration, configure the **Notify Type** and **Notification Class** data point properties on the trend log object to non-default values. When doing so, the OWS can no longer change them permanently.

The BACnet technology also supports *remote trend logs*. A remote trend log is basically a BACnet trend log client, which accesses trend data on another device. The remote trend can load the trend data from the remote device and supply it to L-WEB or the trend CSV files.

### 3.7.5 Dynamic Polling in BACnet

Reading client mappings in BACnet rely either on COV or on polling. Static polling can be configured as a fallback, if COV is not supported, by setting the pollcycle (see Section 3.1.2). Data points which are not used by other objects do not subscribe via COV or perform polling. In addition, this technology also supports dynamic polling. If the data point Web UI or L-WEB requires a refresh on those client mappings, COV subscriptions are made or polling is activated at the configured pollcycle. If those data points go out of scope, the polling on the remote BACnet object stops and COV is unsubscribed.

If no static polling is needed at all, the pollcycle setting can be left at zero in the client mapping. In this case, only a COV subscription is made, if the device supports COV. If COV is not supported, polling is only started, as soon as the values are required. This is especially important on MS/TP channels with devices, that do not support COV.

### 3.7.6 BACnet Data Points in Connections

BACnet data points can be used in local and global connections. In BACnet commandable objects can be written with values at a certain priority. The value with the highest priority is in effect. When revoking a written value, the NULL value is written. This takes back the value. When all written values are withdrawn, the Relinquish\_Default value is in effect. In other technologies there is no notion of taking a value back. To model this behavior, a distinctive *invalid* value can be written to such a data point. For those data points that do not have an intrinsic invalid value, it can be specified when editing the data point. To make a BACnet object convey that invalid value to the opposite side, enable the property **Relinquish to Invalid**.

BACnet data points can be auto-generated from other data point sources (see Section 3.3.3). Only BACnet server objects can be generated and the connected value is reflected in the Present\_Value property. Which type of BACnet object is created depends on the type of the source data point or of the source structure member. For analog sources, analog objects are created. The best-matching BACnet engineering unit is chosen. Other properties of analog objects are copied from the source data point, including min and max present value. Multi-state objects are created for source enumeration types. Which state IDs exist is documented in the BACnet multi-state texts array. This information is copied from the source and made compatible with BACnet restrictions by renumbering state IDs.

Normally BACnet AI, BI, MI are created out of input source data points and AO, BO, MO out of output source data points. The BACnet project settings allow changing this default to BACnet value objects AV, BV, MI. In the auto-generate preview the user can review and change those object types individually before generating the data points.

### 3.7.7 Native BACnet Objects for I/Os

L-IOB I/Os can optionally be directly exposed to BACnet server objects. In this case, each L-IOB I/O object is represented by one BACnet object. The mapping does more than a regular data point connection for the sensor/actuator value. All relevant I/O configuration properties are mapped to corresponding BACnet properties and reflect actual input/output values, I/O status, override/manual values, operating mode, inversion and adhere to all prescribed BACnet functions.

The type of the created BACnet server object depends on the type of the live value I/O data point. If e.g. a universal input (UI) is used for measuring an analog value, the type of the live value (**Input** data point) will be Double and thus, an Analog Input (AI) BACnet object will be created. Table 8 shows all possible native BACnet object types for I/Os.

I/O	I/O Live Value Type	BACnet Object	Feedback Object
DI/UI	Double	Analog Input (AI) or Accumulator	-
DI/UI	Boolean	Binary Input (BI)	-
DI/UI	LIOB/MagCard	Analog Input (AI)	-
AO/DO	Double	Analog Output (AO)	Analog Input (AI)
AO/DO	Boolean	Binary Output (BO)	-

Table 8: Native BACnet object types for I/Os

A property relation ‘native’ (see Section 3.1.12) is added to the original L-IOB input or output data point, which links to the created native BACnet data point. For an AO object, an additional AI object is generated as the feedback value object. The data point of the AO object has a ‘feedbackValue’ property relation that points to the feedback AI object. For BO objects, a separate feedback object is not required, since a feedback value is already included in the BACnet BO object.

For the STId Card Reader mode (see Section 3.5.2), the I/O live value type of the Card Data input is an array of 40 nibbles which contains the last read Card ID in BCD encoding (LIOB/MagCard). In this case, the first n BCD digits that form a number which can be displayed by a BACnet float are written to the Present\_Value of the created BACnet AI object. An ASCII version of the entire BCD code is written to the Description property of the BACnet object.

For the “Pulse Count” interpretation of inputs (see Section 3.5.1.4), it is possible to choose between an analog input or an accumulator object in the Configurator. The main difference is that accumulator objects can precisely represent 32-bit meter data while analog objects suffer from a loss of resolution.

When using native BACnet objects for L-IOB outputs, the BACnet priority array concept is used in the I/O operating mode ‘Auto’ for determining the physical output value. Other I/O operating modes (‘Override’, ‘Manual’, ‘Disabled’, see Section 3.5.1.9) bypass the BACnet priority array. The physical value is determined by the override value or manual value in this case. The following L-IOB live value and configuration property data points, which can be changed at run-time, are exposed to BACnet properties:

- **Input:** For L-IOB inputs in ‘Auto’ mode, the input value is written to the Present\_Value property of the BACnet input object. When switching from another operating mode to ‘Auto’, the current input value is also written.
- **Output:** The output value written by the controller application to the BACnet output object is reflected at the automatic priority in the Priority\_Array of the BACnet object. The resulting Present\_Value of the BACnet object is then written to the physical output in ‘Auto’ mode.
- **OperatingMode:**

- **Auto:** The BACnet object is in normal operation as described above. Out\_of\_service and OVERRIDDEN flags of the BACnet object are cleared.
- **Override (Input):** The BACnet input object is set to out-of-service. The Present\_Value no longer reflects the physical L-IOB input value. The L-IOB override value is coupled to the Present\_Value and vice-versa. Writing the Out\_Of\_Service property over the BACnet network can turn the 'Override' mode on or off (except if in 'Manual' or 'Disabled' mode).
- **Override (Output):** The BACnet output object is set to out-of-service. The Present\_Value no longer writes to the L-IOB output value. The L-IOB override value is coupled to priority slot '1' and vice-versa. It is removed from priority slot '1' when returning to 'Auto' mode. Writing the Out\_Of\_Service property over the BACnet network can turn the 'Override' mode on or off (except if in 'Manual' or 'Disabled' mode).
- **Manual:** The BACnet object is set OVERRIDDEN. The Present\_Value reflects the manual value and is decoupled from the L-IOB input value (input) or Priority\_Array (output). Out\_Of\_Service is not set. The Out\_Of\_Service, Present\_Value, and Reliability properties are made read-only and can no longer be written over BACnet. This mode cannot be modified over the BACnet network.
- **Disabled:** The BACnet object is set out-of-service, the OVERRIDDEN flag is set, and the reliability is set to 'no fault detected'. The Out\_Of\_Service, Present\_Value, and Reliability properties are made read-only and can no longer be written over BACnet. This mode cannot be modified over the BACnet network.
- **OverrideValue:** In 'Override' mode this value is written to the Present\_Value of the BACnet object at priority '1'. When entering 'Override' mode, the current override value is written. When leaving 'Override' mode, NULL is written at priority '1' for output objects and nothing is done for input objects. For input objects in 'Override' mode, the override value is updated by the Present\_Value when written over BACnet.
- **ManualValue:** In 'Manual' mode, the L-IOB manual value is written to the Present\_Value property of the BACnet object. The Present\_Value cannot be written over BACnet in 'Manual' mode.
- **DefaultValue:** The L-IOB default value is written to the Relinquish\_Default property of the BACnet object and vice-versa, if it exists.
- **Invert:** This L-IOB parameter is written to the Polarity property of BACnet BO and BI objects and vice-versa.
- **IStatus:** The I/O status is reflected in the Reliability property of the BACnet object:
  - NO\_FAULT\_DETECTED: If the I/O does not report any error.
  - NO\_OUTPUT/NO\_SENSOR: If an output or sensor failure is detected.
  - COMMUNICATION\_ERROR: If the L-IOB host reports a communication error.
  - UNRELIABLE\_OTHER: For all other problems.
- **Feedback:** For L-IOB outputs in digital mode, the feedback value is written to the Feedback\_Value property of the BACnet BO object. For L-IOB outputs in analog mode, the feedback value is written to the dedicated BACnet AI object, which is pointed to by the 'feedbackValue' property relation.
- **MinValue, MaxValue, Resolution:** For analog BACnet objects and BACnet Accumulator objects, these L-IOB configuration properties are written to the corresponding BACnet properties when they change. For a BACnet Accumulator object, the L-IOB Resolution is mapped to the BACnet Scale property. The BACnet properties are read-only from the BACnet network.

- **I/O Name and Description:** Initially, the BACnet server object name and description are both set to e.g. 'L1\_1\_UI1' (for UI1), where the preamble is 'L1\_1' for local I/Os and 'L2\_1' for an attached LIOB-55x device. In the Configurator, the BACnet server object name and description can later be modified manually or synchronized with the current I/O name and description.
- **PulseCountInit:** If the BACnet object type is Accumulator and this L-IOB configuration property is written (to reset the pulse counter), the value is also written to the Value\_Set property of the BACnet Accumulator object and vice versa.

---

## 3.8 IEC61131 Variables

IEC61131 variables are used to exchange data with the IEC61131 program. These variables are represented in the data point configuration as register data points and can be connected to other data points, e.g. to CEA-709 NV points, via data point connections.

In contrast to CEA-709 or BACnet variables, IEC61131 variables are always represented as single data point. In case of scalar values (representing CEA-709 scalar or enumeration types) one of the following basic data types might be used:

- **Double:** A register of base type *double* is represented by an *analog* data point. It can hold any scalar value. No specific scaling factors apply.
- **Signed Integer:** A register of base type *signed integer* is represented by a *multi-state* data point. This register can hold a set of discrete states, each identified by a signed state ID.
- **Boolean:** A register of base type *boolean* is represented by a *binary* data point. This register can hold a Boolean value.

Structured IEC61131 variables, representing for example structured NVs, or customer defined IEC61131 structures, are stored as user type:

- **User:** A *user* data point contains un-interpreted, user-defined data. The data is stored as a byte array. A user data point does not include any other meta-data. This type of data point also serves as a container for otherwise structured data points and represents the entire data structure. User data points can only be connected to other user data points of the same data length.

---

## 3.9 Regular Expressions

Some features of the Configurator use regular expressions to perform complex operations on text. These apply to data point filters, naming rules and folder copy and rename. A regular expression is a pattern that describes a set of strings. It is applied to an input text and performs pattern-matching by evaluating the expression string consisting of literal characters to match and meta-characters. Literals match themselves (**abc** matches exactly 'abc') whereas meta-characters may match one or more characters of the input text. The available metacharacters are listed in Table 9. Regular expressions can handle abbreviations, such as **\d** instead of **[0-9]**. The abbreviations provided are listed in Table 10.

Meta-Character	Meaning
.	Matches any single character.
[ ]	Indicates a character class. Matches any character inside the brackets (for example, <b>[abc]</b> matches 'a', 'b', and 'c').
^	If this meta-character occurs at the start of a character class, it negates the character class. A negated character class matches any character except those inside the brackets (for example, <b>[^abc]</b> matches all characters except 'a', 'b', and 'c').
^	If ^ is at the beginning of the regular expression, it matches the beginning of the input (for example, <b>^[abc]</b> will only match input that begins with 'a', 'b', or 'c').
-	In a character class, - indicates a range of characters (for example, <b>[0-9]</b> matches any of the digits '0' through '9').
?	Indicates that the preceding expression is optional: it matches once or not at all (for example, <b>[0-9][0-9]?</b> matches '2' and '12').
+	Indicates that the preceding expression matches one or more times (for example, <b>[0-9]+</b> matches '1', '13', '666', and so on).
*	Indicates that the preceding expression matches zero or more times.
??, +?, *?	Non-greedy versions of ?, +, and *. These match as little as possible, unlike the greedy versions which match as much as possible. Example: given the input '<abc><def>', <b>&lt;.*?&gt;</b> matches '<abc>' while <b>&lt;.*&gt;</b> matches '<abc><def>'.
( )	Grouping operator. Example: <b>([0-9]+,)*[0-9]+</b> matches a list of numbers separated by commas (such as '1' or '1,23,456').
{ }	Indicates a match group. The actual text in the input that matches the expression inside the braces can be retrieved through the sequence <b>\0</b> , <b>\1</b> , etc.
\	Escape character: interpret the next character literally (for example, <b>[0-9]+</b> matches one or more digits, but <b>[0-9]\+</b> matches a digit followed by a plus character). Also used for abbreviations (such as <b>\a</b> for any alphanumeric character; see Table 10 below).
	If \ is followed by a number <i>n</i> , it matches the <i>n</i> -th match group (starting from 0). Example: <b>&lt;{.*?}&gt;.*?&lt;/\0&gt;</b> matches '<head>Contents</head>'.
\$	At the end of a regular expression, this character matches the end of the input. Example: <b>[0-9]\$</b> matches a digit at the end of the input.
	Alternation operator: separates two expressions, exactly one of which matches (for example, <b>T the</b> matches 'The' or 'the').
!	Negation operator: the expression following ! does not match the input. Example: <b>a!b</b> matches 'a' not followed by 'b'.

Table 9: Metacharacters in Regular Expressions.

Abbreviation	Matches
<b>\a</b>	Any alphanumeric character: <b>([a-zA-Z0-9])</b>
<b>\b</b>	White space (blank): <b>([ \t])</b>
<b>\c</b>	Any alphabetic character: <b>([a-zA-Z])</b>
<b>\d</b>	Any decimal digit: <b>([0-9])</b>
<b>\h</b>	Any hexadecimal digit: <b>([0-9a-fA-F])</b>
<b>\n</b>	Newline: <b>(\r (\r?\n))</b>
<b>\q</b>	A quoted string: <b>(\"[^\"]*" '[^']*')*</b>
<b>\w</b>	A simple word: <b>([a-zA-Z]+)</b>
<b>\z</b>	An integer: <b>([0-9]+)</b>

Table 10: Abbreviations for regular expressions

When performing a replace operation on an input text, match groups are used in the output template. Match groups are delimited by curly braces containing a matching pattern. As an example the regular expression **{[0-9]?[0-9]}:{[0-9][0-9]}** contains two match groups. The first match group matches any combination of one or two digits. The second

matches any two-digit combination. To make the replacement effective, the entire regular expression has to match. In the example the regular expression matches any one or two-digit combination followed by a ‘:’ and by any two-digit combination.

Then the output is assembled by specifying an output template. In that output template, both literal text and references to the match groups can be specified. The first match group is denoted by `\0`, the second by `\1` and so on. Using the output template `ref\0-\1` on the example expression, the following input texts will produce these results:

- “ab1:22c” matches, replacement is “ref1-22”,
- “foo22:11bar” matches, replacement is “ref22-11”,
- “ab22:1c” does not match, no replacement results in “ab22:1c”.

---

## 3.10 Scripts

LOYTEC devices that support scripting provide a JavaScript-based scripting engine. Scripts are executed in a separate process on the device and are able to work with data points. The Configurator provides *script resources* that constitute the base modules of scripting. Script resources are embedded into the data point configuration and are deployed onto the device. For more information on the scripting engine refer to Chapter 16.

# 4 The LINX Configurator

This Chapter gives step-by-step instructions on how to commission the LOYTEC device, create a data point configuration with network variables, BACnet objects, how to expose those data points to the automation server, and how to map data points to other technologies in the universal gateway.

---

## 4.1 Installation

### 4.1.1 Software Installation

The LINX Configurator must be used to setup the data point configuration of the LOYTEC device. The Configurator is installed as a plug-in tool for all LNS-based network management tools as well as a stand-alone tool (for systems without LNS).

System requirements:

- LNS 3.1 SP8 U1, LNS 3.2 TE SP5, OpenLNS (for LNS mode),
- Windows 7, Windows 8, Windows 10 or Windows Server 2003 (32 bit), Windows Server 2008, Windows Server 2012,
- Internet Explorer 10 or higher.

The LINX Configurator can be downloaded from the LOYTEC Web site <http://www.loytec.com>. When asked for the type of installation, there are two options to choose from. Select **Typical** to install the required program files. Select **Full** to install the LONMARK resource files along with the software. This option is useful, when the system does not have the newest resource files.

### 4.1.2 Registration as an LNS Plug-In

If the a CEA-709 device model shall be configured using LNS-based tools (e.g., NL200 or LonMaker), the LINX Configurator needs to be registered as an LNS plug-in. In the following, the process is described for LonMaker TE. Otherwise, please refer to the documentation of your network management tool on how to register an LNS plug-in.

#### To Register in LonMaker TE

1. Open LonMaker and create a new network.
2. Click **Next** until the plug-in registration tab appears in the Network Wizard. Select the **LOYTEC LINX Configurator (Version X.Y)** from the list of **Not Registered** (see Figure 14).






Figure 14: Select the Plug-in to be registered.

3. Click **Register**. The Configurator now appears in the **Pending** list.
4. Click **Finish** to complete the registration.




Figure 15: Select device templates for installation.

5. A dialog appears to optionally select the device templates to be installed. Deselect unneeded device templates to speed up registration. Click **OK** to continue.
6. The selected device templates are added automatically and XIF files are copied into the LNS import directory.

*Note:*

*If you are using multiple databases (projects) make sure you have registered the plug-in in each project.*

7. Under LonMaker → Network Properties → Plug-In Registration make sure that the LOYTEC LINX Configurator (Version X.Y) shows up under Already Registered.




Figure 16: Check that the LINX Configurator is properly registered.

### 4.1.3 CEA-709 Operating Modes

The Configurator can be used in on-line, off-line, and stand-alone mode. On-line and off-line mode refers to the 2 operating modes of your LNS network management software.

- **On-line Mode:** This is the preferred method to use the Configurator. The network management tool is attached to the network and all network changes are directly propagated into the network. This mode must be used to add the device, commission the device, extract the port interface definition, and download the configuration into the device.
- **Off-line Mode:** In off-line mode, the network management software is not attached to the network or the device is not attached to the network, respectively. This mode can be used to add the device using the device templates, create the port interface definition and to make the internal connections.
- **Stand-alone Mode:** The Configurator can also be executed as a stand-alone program. This mode is useful for the engineer who doesn't want to start the configuration software as a plug-in from within network management software (e.g., NL-220, LonMaker or Alex). Instead the engineer can work directly with the device when online or engineer it offline.

### 4.1.4 Language Setting

The language setting of the Configurator can be changed. To do so, open the preferences dialog using the menu **Settings → Preferences ...** as shown in Figure 17. Choose the desired **Language** entry in the drop-down box. Then click on **Ok** and restart the Configurator to let the change take effect.




Figure 17: Preferences dialog.

## 4.2 Data Point Manager

The Configurator uses a central concept to manage data points. The data point manager is located on the **Datapoints** tab as shown in Figure 18. It is used to select, create, edit and delete data points. The dialog is divided into three sections:

- The folder list (number 1 in Figure 18),
- The data point list (number 2 in Figure 18),
- And a property view (number 3 in Figure 18).




Figure 18: Data Point Manager Dialog.

### 4.2.1 Folder List

At the left is a list of folders which is used to sort the available data objects by their category. There are a number of predefined folders available:

- **Imported:** This folder has a number of sub-folders for different import methods:
  - **CEA-709 CSV File:** This folder is used to display data points imported from CSV files.
  - **CEA-709 LNS Scan:** This folder is used to hold data retrieved from a network database scan.

- **CEA-709 Network Scan:** This folder holds NVs scanned online from an attached CEA-709 network.
- **CEA-709 Devices from XIF:** This folder holds sub-folders and NVs created from XIF files.
- **BACnet Network Scan:** This folder is used to display data points retrieved by an online scan of the BACnet network.
- **BACnet EDE File:** This folder is used to display data points imported from an EDE file.

Data objects in the import folder are not stored on the device when the project is downloaded. They represent data objects which are available on remote devices and are shown here as templates to create suitable data objects for use on the device by selecting the **Use on Device** option.

- **Filter Templates:** This folder contains the created data point templates. They contain a set of properties, which are applied to data points, when they are created on the device. There is a sub-folder for filter templates specific to different technologies, e.g. CEA-709.
- **LINX-XXX:** This is the device folder of the L-INX (other device models are represented by a respective folder name). It contains all the necessary data points which constitute to the device's configuration. These data points are created on the device when the configuration is downloaded. The following subfolders may be present depending on the particular model:
  - **Favorites:** This folder contains freely configurable symbolic links to data points, which may reside anywhere in the folder structure. This folder represents a way to assemble an alternate logical view to the data point hierarchy. This folder is also available on the Web UI or the LCD UI.
  - **System Registers:** This folder contains system registers, which provide information on the device itself.
  - **User Registers:** This folder holds user-definable registers. These registers are not visible on the underlying network and are intended for internal usage.
  - **Scheduler:** This folder contains generic scheduler and calendar objects. These provide technology-independent scheduling functionality. Any data point can be alarmed using a generic scheduler object.
  - **Alarm:** This folder contains generic alarm servers. These provide technology-independent alarms. Any data point can be alarmed using a generic alarm server.
  - **Trend:** This folder contains generic trend log objects. These can record historical values for any data points.
  - **CEA-709 Port:** This folder contains data points, schedulers, calendars, trend logs, statistics, and remote data points of the CEA-709 network technology. See Section 4.2.2.
  - **BACnet Port:** This folder contains data points, schedulers, calendars, trend logs, statistics, and remote data points of the BACnet network technology. See Section 4.2.2.
- **Global Objects:** This top-level folder contains sub-folders that organize specific application objects that operate on data points.
  - **E-mail Configuration:** This folder contains e-mail templates. An e-mail template defines the destination address and text body of an e-mail, which is triggered by data points and may contain data point values or file attachments. To create an e-mail template, select the folder and use the context menu.
  - **Math Objects Configuration:** This folder contains math objects. Math objects are used to perform a predefined calculation on a number of input data points and write the result to a defined set of output data points. Each math object

contains one formula. To create a math object, select the folder and use the context menu.

- **Alarm Log Configuration:** This folder contains the alarm log objects. Each alarm log object creates a historical log of alarm transitions of one or more alarm objects (alarm server or client). To create an alarm log, select the folder and use the context menu.

Using the context menu on a folder, sub-folders may be created to organize the available objects. If new objects are created automatically, they are usually placed in the base folder and can then be moved by the user to any of his sub-folders. Note, that the folder structure described above cannot be changed by adding or deleting folders at that level.

The context menu also allows editing folder properties. Choose **Properties ...** from the context menu to open a property editor. Change name and description there.

## 4.2.2 Network Port Folders

Each network port folder on the device has the same structure of sub folders. These sub folders are:

- **Datapoints:** This folder holds all data points, which are allocated on the network port. To create a data point, select the folder and use the context menu.
- **Calendar:** This folder is used to hold a locally available calendar object with its calendar patterns (definitions of day classes like holiday, maintenance day, and so on). Current devices allow one local calendar object. To create a calendar, select the folder and use the context menu.
- **Scheduler:** This folder is used for local scheduler objects. Each of these objects will map to a local scheduler on the device's network port. Configuring schedules through these objects actually transfers *schedule configuration data* to the underlying scheduler objects on the network port. To create a scheduler, select the folder and use the context menu.
- **Alarm:** This folder is used for local alarm server objects. Each of these alarm server objects represent an alarm class, which other objects can report alarms to. Other devices can use the alarm server object to get notified about alarms. To create an alarm server object, select the folder and use the context menu.
- **Trend:** This folder is used for local trend log objects. Each of these objects will be able to trend data points over time and store a local trend log file. To create a trend log object, select the folder and use the context menu.
- **Statistics:** This folder contains registers, which provide communication statistics specific to the network port.
- **Remote Devices:** This folder is used to collect all remote calendars, schedulers, trend logs, and alarm client objects, which were created from network scan data. For each remote device, a subfolder will be created where the objects referencing this device are collected.

## 4.2.3 Data Point List

At the top right, a list of all data objects which are available in the selected folder is shown. From this list, objects may be selected (including multi-select) in order to modify some of their properties. Click on the **Include Subfolders** button to show all data points of the selected data point folder and all its sub-folders. This can be a convenient way for multi-select across folders.

To filter for data point names, enter a search text into the **Datapoint Name Filter** text box and hit *Enter*. A drop-down list holds the previously used filters available. Filters can also specify name patterns for sub-data points using a dot. Typing the first dot expands all filtered data points to the first sub-level. Continuing typing after the dot then filters on names of those



sub-data points. For example, typing “sw.val” selects all data points having “sw” in their name, then expanding to their first sub-level and filtering all sub-data points on that level having “val” in the name. For complex name filters, regular expressions may be used (see Section 3.9).

The list order can be changed manually by drag-and-drop. Select one or more data points and drag them to the desired position in the data point list. The data points will get a new order number.

The list can be sorted by clicking on one of the column headers. For example, clicking on the **Direction** column header will sort the list by direction. Other columns display **Datapoint Name**, **NV name**, **SNVT**, **Object Name**, object **Type** and **Instance** number, allocation (**Alloc**) of server object (SO) and/or client mapping (CM), number of attached **Client Maps**, and the data point unique **ID**. To apply the current sort order as the new data point order on the device, right-click on the column header and select **Renummer Datapoints**. Alternatively, select from the menu **Tools → Renummer Datapoints**.

The **OPC** column provides check boxes for each data point. If checked, the respective data point is exposed to OPC on the device. Deselect the check box, if a data points shall not be exposed to OPC. Note, that deselected data points do not add to the OPC tag limit.

The **Param** column provides check boxes for each data point. If checked, the respective data point is exposed to the parameter file. The **PLC in** and **PLC out** columns provide check-boxes, which define if data points are visible inside the IEC61131 PLC program as input and output variables.

New objects may be created in the selected folder by selecting **New Datapoint** command in the context menu of the data point list. A plus  sign in the list indicates that the data point contains sub-points. Clicking on the plus  sign expands the view.

If an entry in the data point list denotes a reference to another data point (e.g., a scheduled value reference beneath a scheduler object), right-click on that item and choose **Go to related data point** in the context menu. This will navigate your selection to the referenced data point.

For the alarming, scheduling, trending (AST) features, there are columns, which display icons for data points that are attached to an AST function. See Table 11 for details.









Icon	Data Point Usage
	Data point is scheduled
	Data point has an active alarm condition
	Data point has an inactive alarm condition.
	Data point has sub-data point with alarm condition.
	Data point is a trigger for e-mails.
	Data point used for trending.
	Data point is a link.
	Data point has sub-data points, which are links.

Table 11: Icons for used data points in the data point list view.

The data points in this list are color coded to make general information visible to the user at-a-glance. The color coding is described in Table 12.

Color	Coded Information
ao1 (yellow)	Data point is user-created and can be downloaded to the device.
MAC (blue)	Data point is fixed on the device and cannot be edited, e.g. system registers.
dark red	Data point is user-created and its technology object (e.g. dynamic NV) has been deleted. The data point, however, is still used in the configuration. It will not work on the device until the technology object is created again.

Table 12: Color coding used for data points in the data point list view.

The column arrangement in the data point list can be modified to increase oversight. Right-click on a folder or into the column header and choose **Configure Columns...** in the context menu. The dialog shown in Figure 19 allow modification of the column layout.




Figure 19: Configure the column layout.

Click on the plus button to add columns, or the minus button to remove selected columns. Use the up/down buttons to move the selected columns. It is also possible to drag them to another position. Finally, click **OK** to accept the new columns layout or **Cancel** to discard the changes. Click the button **Restore Defaults** to go back to the installation defaults.

#### 4.2.4 Property View



When one or multiple data points are selected, the available properties are displayed in the property view. Properties which are read-only are marked with a lock sign. When applying multi-select, only those properties common to all selected data points are displayed. According to the frequency of usage, different views for the properties are provided. **Basic Properties** list the most frequently used ones. **All Properties** is a list of all available properties for the data point. Depending on the network technology and data point class, different properties may exist. The **Name Filter** in the properties tab allows quick filtering of properties that have a matching text in their name. For example, type “OPC” to filter the OPC Tag property.

Data point properties common to all technologies:

- **Datapoint Name:** This is the technology-independent data point name. This name may be longer than and different to the name of the native communication object (i.e., network variable). Data point names must be unique within a given folder. The maximum length is limited to 64 ASCII characters.
- **Datapoint Path:** This informational property specifies the entire path of the data point within the data point hierarchy. The maximum length is limited to 64 ASCII characters.

- **Datapoint Description:** This is a human-readable description of the data point. There are no special restrictions for a description.
- **OPC Tag:** If enabled, the data point will be exposed to OPC. If not enabled, this data point does not contribute to the limit of OPC tags.
- **Parameter:** If enabled, the data point will be exposed to the parameter file. Those data points are visible to the LWEB-900 parameter view [5]. A parameter data point is also persistent. See Section 3.1.5.
- **PLC in - Logic Variable:** If enabled, the data point will be usable in the IEC61131 PLC program as an input variable. This is only available on the L-INX.
- **PLC out - Logic Variable:** If enabled, the data point will be usable in the IEC61131 PLC program as an output variable. This is only available on the L-INX.
- **Use Polycle value as:** For input data points, this property defines whether the input shall use a receive timeout or be constantly polling. See Section 3.1.2.
- **Poll on Startup:** For input data points this property defines, whether the data point shall be polled once at start-up. Poll-on-startup can be enabled independently of the poll cycle. See Section 3.1.2.
- **Polycle:** For input data points, this property defines the poll cycle in seconds. Set this property to 0 to disable polling. See Section 3.1.2.
- **Receive Timeout:** For input data points, this property defines the receive timeout in seconds. Set this property to 0 to disable polling. See Section 3.1.2.
- **Min Send:** For output data points, this property defines the min send time in seconds. See Section 3.1.2.
- **Max Send:** For output data points, this property defines the max send time in seconds. See Section 3.1.2.
- **Send-on-delta:** For output data points this property defines, if value updates shall be sent only once they meet the COV condition of the data point. For analog data points the analog COV increment is used. If not checked, updates are always transmitted according to min and max send times. See Section 3.1.7.
- **Use Linear Scaling:** If this property is enabled, the analog values are pre-scaled from the technology to the data point. This scaling is in addition to any technology-specific scaling factors. If enabled, the properties **Custom Scaling Factor** and **Custom Scaling Offset** accept the scaling factors. See Section 3.1.7.
- **Custom Scaling Factor, Custom Scaling Offset:** These properties only exist, if linear scaling is enabled. They apply to analog data points only. See Section 3.1.7.
- **Notify on any COV:** This property defines, if a data point shall trigger an update only when the value changes or on every write. If this is enabled, consecutive writes with the same value do not trigger an update. If you want to convey every write, disable COV on the data point. For analog data points, it will disable the **Analog Point COV Increment** and trigger an update on any change of value.
- **Persistent:** This property defines, if the last written value shall be stored as a persistent value. Persistent data points restore that value after a restart from the persistent storage. See Section 3.1.4.
- **Default Value:** This property defines a default value (see Section 3.1.3). Enter a default value to enable this feature in the data point. Delete the value entirely to remove the default value. If no default value is defined, this property reads "N/A". The default is no default value.
- **Historic Filter:** This property allows defining historic filters for the scalar data point. See Section 3.4.6.
- **Point Type:** This is the base data point type, e.g., "Analog Datapoint".



- **Direction:** This is the data point direction. Use input, output or value as directions.
- **Network Unit:** For analog data points this property contains the definition of an engineering unit of the scalar value as represented on the network, e.g., “°C”. A human-readable text for the engineering unit is displayed and can be entered. If the unit is known by the Configurator as a convertible unit, it is displayed with a green checkmark  (see Section 3.1.13).
- **Unit SI:** If the data point has a convertible unit, a unit representation in the metric (SI) system can be chosen. If the SI unit system is active, all values are converted to this unit, e.g. °C. For a non-convertible network unit this option is not available.
- **Unit U.S.:** If the data point has a convertible unit, a unit representation in the U.S. system can be chosen. If the U.S. unit system is active, all values are converted to this unit, e.g. °F. For a non-convertible network unit this option is not available.
- **Analog Datapoint Max Value:** For analog data points this property contains the upper limit of the supported value range. Note that this does not define an alarm limit.
- **Analog Datapoint Min Value:** For analog data points this property contains the lower limit of the supported value range. Note that this does not define an alarm limit.
- **Analog Datapoint Precision:** For analog data points this property defines the number of decimals. ‘0’ specifies an integer value. Display units may use this to format the floating point value accordingly.
- **Analog Datapoint Resolution:** For analog data points this property defines the smallest possible value increment.
- **Analog Point COV Increment:** This property is valid for analog input data points. It specifies by which amount the value needs to change, before an update is generated. If every write shall generate an update even when the value does not change, specify 0 as the COV increment. If any value change shall generate an update, set the **Notify on any COV** property.
- **Active Text:** For binary data points this property defines a human-readable text for the active state (true).
- **Inactive Text:** For binary data points this property defines a human-readable text for the inactive state (false).
- **Current State Map:** For multi-state data points this property defines the multi-state map. It must be set to a valid multi-state map or it points to User/UndefinedStates. Click on  to assign a state map.
- **State Count:** For multi-state data points this property defines the number of discrete states.
- **State Text:** For multi-state data points this property defines a human-readable state label for each state.
- **Energy Aware:** This option can be used to mark data points as EnPIs (energy performance indicators). This information may be evaluated by third-party software in order to filter data points. It does not affect data communication on the device in any way.

#### 4.2.5 Tracking Data Point Usage

Data points can be used by other objects, such as connections, schedulers, math objects and many more. To get an overview on data point usage, the data point list contains the column Use. This column provides a usage counter of the individual data points. If usage is ‘0’ the data point is not used by any other object.

If the usage count is larger than zero, choose the item **Show Usage ...** from the data point context menu. This opens up a report window showing the objects referring to the selected data point. An example is shown in Figure 20.






Figure 20: Data point usage report.

Each line reveals an object using the data point. Select a line and click on the **Go to data point** button . This will navigate your selection to the reported object.

## 4.2.6 Managing Multistate Maps

Multistate data points have a descriptive set of state texts for their state IDs. To manage those state IDs and state texts among many multistate data points, they refer to *multistate maps*. Some technologies have a fixed set of such multistate maps others have freely configurable multistate maps (e.g. user registers). Editing a multistate map affects all multistate data points, which are using that particular map. It is not necessary to edit each data point individually. For managing multistate maps go to the menu **Tools → Manage State Maps** ...

### To Edit a Multistate Map

1. Click on the **Configure** button  in the **Current State Map** property of a multistate data point. This opens the multistate map manager as shown in Figure 21.









Figure 21: Select multistate maps in the multistate map manager.

2. Select a **Category** and an existing state map in the **State Maps** list and click on **Select**. Maps that are fixed and cannot be changed are marked with a lock symbol .
3. Expand a state map line to see where this state map is used. Select the usage and click the **Go to Data Point** button . This navigates to the data point.



4. If a new multistate map shall be created, click the **Create State Map** button .
5. In the **Create New State Map** dialog enter a state map Name.



- Then enter the desired number of states and edit the state texts as needed and click into the list of states. Edit state IDs and texts to your needs. Pressing Enter goes to the next line. Finally click the **Save** button.

State Count

ID	State
1	One
2	Two
3	Three

- Select the newly created multistate map and click the **Select** button. The selected map is now assigned to the data point.

## 4.2.7 Organizing Favorites


There is a special **Favorites** top-level folder in the device data point folder hierarchy. This folder contains freely configurable symbolic links to data points, which may actually reside anywhere in the folder structure. This folder represents a way to assemble an alternate logical view to the data point hierarchy.

To configure favorites, select any data point from any location in the data point folder hierarchy and drag it onto the favorites folder. This will create a data point link, which is displayed in the data point list:

Favorites - Favorites				
Link Name	OPC	PLC	Link Path	ID
my_name_humid_link	<input checked="" type="checkbox"/>	<input type="checkbox"/>	LINX-120.CEA709 Port.Datapoints.abs_humid	10FE

The **link name** can be edited to something different than the original data point name. The contents of this folder are also available on the Web UI or the LCD UI. The link names are displayed there. The data point links can also be individually exposed to the OPC server or PLC program notwithstanding if their original source is exposed or not.

Furthermore, the user can create sub-folders in the favorites folder and beneath to build a hierarchy of data point links. Folder links are, however, not allowed.

For editing links of favorites for a large number of data points, the **Manage Favorites** tab in the property view area of the data point manager provides a fast solution. The data point tree is replicated in that tab as shown in Figure 22. Select a folder and optionally click on the button  to include favorites in sub-folders. Enter a filter expression to **Filter**, which applies to the favorite name. For example, enter 'room1' to display all favorites that contain this as a sub-string.





Figure 22: Manage favorites tab.

To link favorites to other data points using the manage favorites tab, navigate to the desired folder in the main folder tree of the data point manager and select the data point to be linked. Drag the data point onto the **Link Target** column. For detaching links, use multi-select on

the desired favorites and click the detach button . On linked favorites you may click on the button , which jumps to the linked data point in the data point list.

### 4.2.8 Managing Property Relations

Property relations can be linked to data points in various user dialogs (e.g. alarm condition dialog). For editing links of property relations for a large number of data points, the **Manage Relations** tab in the property view area of the data point manager provides a fast solution. The data point tree is replicated in that tab as shown in Figure 23. Select a folder and optionally click on the button  to include property relations of data points in sub-folders. Enter a filter expression to **Filter**, which applies to both the data point name and relation type. For example, enter ‘feedback’ to display all feedback value property relations.






Figure 23: Manage relations tab.

To link property relations to other data points using the manage relations tab, navigate to the desired folder in the main folder tree of the data point manager and select the data point to be linked. Drag the data point onto the **Is related To** column. For detaching links, use multi-select on the desired property relations and click the detach button . On linked property relations you may click on the button , which jumps to the linked data point in the data point list.

### 4.2.9 CEA-709 Properties

Apart from the common data point properties discussed in Section 4.2.4 the data points of the CEA-709 technology have additional properties. Depending on whether a NV is local or external (remote), the properties may vary.

- **NV Allocation:** This property defines how a data point shall be allocated on the device. Choices are “Static NV”, “Dynamic NV”, and “External NV”. If the allocation type cannot be changed, this property is locked.
- **SNVT:** This property defines the SNVT of the NV, e.g., “lux (79)”.
- **Invalid Value:** This property defines the “invalid value” for the NV. If set, this specific value will be interpreted as “invalid” in the data point. If known by the SNVT, the invalid value is filled in. Otherwise, the user can specify an invalid value.
- **CEA-709 Mapping Information:** This information is derived from the SNVT. It defines how the NV contents are mapped to the data point.
- **NV Scaling A, B, C:** These are the scaling factors known from the SNVT table. The scaling factors are applied to translate a raw NV value into the scalar representation of the data point.
- **Data Type:** This is the basic NV data type. This is usually filled in from the SNVT definition.
- **Local NV Member Index:** This property specifies the NV member index within a given functional block. This must be a unique index in the functional block, which identifies the NV after other NVs have been added or removed from the interface.

- **Local/Remote NV Index:** This property specifies the NV index. For local, static NVs this is the NV index of the static NV. For external NVs, this is the NV index of the NV on the remote device.
- **Local/Remote NV Name:** This property specifies the programmatic name of the NV. For local, static NVs this is the programmatic name of the static NV. For external NVs, this is the programmatic name of the NV on the remote device.
- **Local/Remote Functional Block:** This property specifies the programmatic name of the NV. For local, static NVs, one of the reserved functional blocks can be selected.
- **Local/Remote NV Flags:** This property specifies the NV flags. For local (static or dynamic) NVs, the flags can be configured. For external NVs, these flags are only informational.
- **Remove NV Information:** For external NVs, this property contains the information on the remote device and the NV selector on that device.
- **Remote Device ID:** For external NVs, this property contains information on the remote device by listing the program ID and location string.
- **Remote Device Address:** For external NVs, this property contains the CEA-709 network addressing information to access the node, i.e., subnet, node, and NID.
- **Retry Count:** For external NVs, this property defines the retry count. The default is 3.
- **Repeat Timer:** For external NVs, this property defines the repeat timer in milliseconds. The default is 96 ms.
- **Transmit Timer:** For external NVs, this property defines the transmit timer in milliseconds. The default is 768 ms.
- **LNS Network Path:** If available from an LNS scan, this property specifies the LNS network path of the device where the given NV exists.
- **LNS Channel Name:** If available from an LNS scan, this property specifies the LNS channel name of the device where the given NV exists.

#### 4.2.10 BACnet Properties

Apart from the common data point properties discussed in Section 4.2.4 the data points of the BACnet technology have additional properties. Depending on whether a server object and/or a client mapping exists, the properties may vary.

- **Engineering Units:** For analog BACnet server objects, this property defines the engineering units from the BACnet standard. One of those units can be chosen from a drop-down box, if this property is not locked. Depending on the active unit system, the BACnet engineering units property is either metric (SI) or U.S.
- **Server Object Type:** This property defines the BACnet object type of the underlying BACnet server object. It can be changed within the class, i.e., for an analog data point, the server object type analog input, analog output, or analog value can be chosen.
- **Commandable:** This property defines, if the underlying BACnet server object is commandable. For BACnet value objects (AV, BV, MSV) this property can be edited to create commandable or non-commandable BACnet value objects.
- **Relinquish to invalid value:** This property defines whether the data point maintains the Relinquish\_Default value, if the priority array is empty or assumes the invalid value. By default, this property is false and the Relinquish\_Default value is used. Setting this property to true can be beneficial when used in a connection to withdraw a value in another technology.
- **Server Object Name:** This property defines the object name of the underlying BACnet server object. It must be unique among all server objects. It can be up to 64 characters and is read-only on the BACnet network by default. If the option to keep OWS values is enabled in the BACnet project settings (See Section 6.1), this property is writeable and

the server object name is only initialized by this property. Any changes made by the OWS will be kept also after a new configuration has been downloaded.

- **Server Object Instance No:** This property defines the object instance number of the underlying BACnet server object.
- **Server Object Description:** This property defines the object description of the underlying BACnet server object. It can be left blank.
- **Server Object Device Type:** This property defines the object device type of the underlying BACnet server object. It can be left blank.
- **Server Accumulator Offset Correction:** This property is available for accumulator objects only. It is activated as a default. It ensures that the written data point value is corrected in the Present\_Value as soon as the Value\_Set property is written and requests a certain Present\_Value. That correction offset is then added to the written data point value, e.g., when received over a connection.
- **Get Active Priority:** Set this check box to let the data point reflect the active priority of the local or remote BACnet object. The priority is a number between 1 and 16. This property is only applicable for commandable BACnet objects.
- **Allocate Server Object:** This Boolean property defines, if a server object shall be allocated for the data point. This option is useful, when a local server object shall be allocated for a client mapping.
- **Allocate Client Mapping:** This Boolean property defines, if a client mapping shall be allocated for the data point. This option is always set, if at least on client mapping is attached.
- **Client Map Count:** This property defines the number of client mappings attached to a data point. A data point can have one read client map or  $n$  write client mappings.
- **Client Map [n]:** This is a list of client mappings. The property shows a summary of the client mapping parameters.
- **Client Confirmed COV:** This Boolean property defines, if a client map subscribes with the confirmed COV service. If not enabled, the unconfirmed COV is used.
- **Client Map Type:** This property determines the type. It can be one of the following: Poll, COV, Auto, Write, or Value (see Section 3.7.1).
- **Client Write Priority:** For a write or value client map, this property defines which priority is used for writing.
- **Remote Instance Number:** This property specifies the object instance number of the remote server object. The object type cannot be edited.
- **Value Read Mode:** For value client mappings, this property defines the read mode: Poll, COV, or Auto.
- **BACnet Notify Type:** When set to 'default' the Notify\_Type property is to be written by the OWS. Change this to 'Event' or 'Alarm' to set the property via the data point configuration.
- **BACnet Notification Class:** If notify type is non-default, this property is enabled. It sets the Notification\_Class via the data point configuration.
- **BACnet Event Enable (To-XXX):** If notify type is non-default, this property is enabled. It sets the Event\_Enable property via the data point configuration.

---

## 4.3 Project Settings

The project settings allow defining certain default behavior and default settings used throughout the project. To access the project settings go to the menu **Settings → Project**

**Settings....** This opens the project settings dialog, which provides several tabs as described in the following sections.

### 4.3.1 General

The general tab of the project settings as shown in Figure 24 contains settings independent of the technology port. The settings are:



- **Project Name:** This setting allows entering a descriptive name for the project.
- **Parameters managed by:** This setting defines, which instance is managing data point parameters. As a default, parameters are assumed to be managed by LWEB-900 and the Configurator does not download parameter values to the device. If changed to parameters managed by Configurator, the Configurator downloads parameter values and merges parameter changes back into the configuration. This setting does not affect L-IOB parameters, which are always managed by the Configurator. For more information on data point parameters refer to Section 3.1.5.
- **L-IOB: Always ignore L-IOB manual/auto differences:** Set this check box to ignore differences in the manual mode parameter of L-IOB I/Os.
- **Device Configuration Download Default:** This group of settings defines, how the download of device configuration parameters shall proceed. If **Download only data point configuration** is selected, the configuration download does not download anything else than the data point configuration. If **Ask** is selected, the download will pop up a dialog in which the user can choose what to download. If **Download specific** is selected, the project settings of this dialog determine what is downloaded onto the device. The individual items to download are selected by individual checkboxes below the download option. As a default, the configuration download includes the schedules and calendar patterns as well as L-WEB projects.
- **Background polling:** Activate this option to permanently poll data points, even if they have no pollcycle assigned. The data points are polled one-by-one. The poll rate can be configured. This setting is not active by default. For more information on background polling refer to Section 3.1.2.

Figure 24: General Project Settings.

- **Data Point Units:** This setting defines which unit system is active in the Configurator. Depending on the active unit system, SI units are displayed or U.S. units, as defined per data point. This setting, however, influences only the display in the Configurator. If the device shall be configured to run on this same unit system, set the check box **This unit system will be set on device on download**. In this case each configuration download will ensure the device runs on the selected unit system.

**Important!**

*If this effectively changes the unit system on the device, all persistent values are reset to their default values converted to the respective unit system.*

- **Auto snapshot:** This setting is off by default. It can be enabled in the drop-down box by selecting a time interval, which is used by the Configurator to produce configuration snapshots. The user can jump back and forth between those snapshots. Snapshots can also be made explicitly by clicking the snapshot button  in the tool bar.
- **Value Data Points:** Select this option to create data points in the old style with “\_Read” (input) and “\_Write” (output) data points. Old configurations will have this option set to continue creating data points using the same style. Newly created configurations should not use this setting.
- **Project ID:** This button opens the project ID dialog as shown in Figure 25. The project ID uniquely identifies a data point configuration. If the project ID changes, all persistent values on the device are discarded and replaced by the new data point configuration. To force a new project ID open the dialog and click on the button  to generate a new ID. Then click **Ok** to accept the new project ID.






Figure 25: Change the project ID.

### 4.3.2 Data Point Naming Rules

The data point naming rules tab allows specifying how data point names are automatically derived from imported or scanned objects on the network. For each technology a rule can be defined, how individual components shall assemble the desired data point name. The technology is chosen in the tree view. The name components are added by clicking on . Then click on the name component and choose which content shall be assigned from a drop-down menu. To remove a component, click on it and choose **Remove** from the drop-down menu. An example rule is shown in Figure 26.




Figure 26: Adding components to naming rules

A **Separator** character can be defined, which is inserted between the data point name components. As a default the underline ‘\_’ is configured. The Preview shows how names would look like with the chosen separator and name components.

The CEA-709 data point naming rules (see Figure 27) work on scanned network variables. The preview shows how names would look like, when the check marks are modified. Note, that changing the name components does not change already scanned NVs; this setting affects only new scan results.

- **Use programmatic name, Use display name:** This option decides how the data point name is extracted from the NV. The programmatic name is the NV name from the XIF file and is limited to 16 characters. The display name may be extracted from LNS, which allows displaying a different, longer name than the programmatic name.
- **Add Subsystem Name via Filter:** This line can be edited by adding LNS sub-system components to the data point name. Click on to add another component. The first subsystem1 is the one containing the device, the second subsystem2 the one containing subsystem1, and so on. Click on the arrow symbol for editing a filter expression, which defines how the sub-system text is transformed to the name component, e.g. copy the last three characters. Examples for regular expressions can be inserted by clicking the question mark symbol and selecting a transformation. In the preview section the filter expression can be tested against an example text. For more information on using regular expressions please refer to Section 3.9.




Figure 27: Data Point Naming Rules Project Settings.

### 4.3.3 System Settings

This tab is shown in Figure 28. It is available only with the newest firmware version and can be used to configure the device through the Configurator. In the configuration tree on the left-hand side the user can select certain groups of settings, e.g. Web server settings. The dialog displays the settings of the selected group in the dialog area. The structure is similar to the menu structure on the Web UI.

Under the port configuration tree, the user can enable or disable communication protocols on the device's ports. Enabled protocols are marked with a checkmark. Click on the checkmark and toggle it. Note, that depending on the device model communication protocols on other ports may be disabled.

The IP address settings cannot be changed in this dialog. The FTP server can not be disabled in this dialog, either. This ensures that the Configurator can maintain connection to the device.




Figure 28: Device Configuration Settings

The **Upload** button can be used to get the current device settings from the device and display them in this dialog. The **Download** button can be used to explicitly transfer the settings from this dialog onto the device. Those changes will be visible immediately on the Web UI but take effect only after a reboot of the device.

**Important!**

*After downloading the device settings from this dialog the changes will be visible immediately on the Web UI but the device needs to be rebooted to let the changes take effect.*

The **Date/Time** section allows defining automatic time zone configuration on the device using the PC's time zone database. Select the **Enable automatic Time Zone and DST** check box and choose the appropriate setting from the drop-down list below as shown in Figure 29. The timezone offset, start and end of DST are then configured accordingly on the device.




Figure 29: Choose time zone information in system settings.


### 4.3.4 OPC

This tab is shown in Figure 30. It provides fields to configure OPC server tag naming and poll timings.

- **Automatically structure imported data points for faster OPC browsing:** This option enables the automatic generation of sub-folders when using data points on the device. A

sub-folder is created for each scanned or imported device. This allows OPC clients to browse the OPC tags in a hierarchical way.

- **Use delayed response:** Devices with OPC clients can be configured to use delayed response subscriptions. This is activated as a default.
- **OPC Polycle:** If no delayed response is configured, this setting specifies the OPC polycle.
- **Wait Time:** If delayed response is configured, this setting defines the requested time to wait for a change until a poll response is received. It effectively implements a heart beat.
- **Hold Time:** If delayed response is configured, this setting defines the requested time to hold back with poll responses. It effectively limits the traffic.



General System Settings Datapoint Naming Rules CEA709 CEA709 AST BACnet KNX **OPC**

OPC XML-DA

☒ Automatically structure imported data points for faster OPC browsing

☒ Use delayed response

OPC Polycle  sec


Wait Time  sec

Hold Time  msec

Figure 30: OPC project settings.

### 4.3.5 Project Information

This tab is shown in Figure 31. It provides fields to enter additional information about the project such as author name and a reference field. The comments text area allows entering free text describing the project. For instance it can be used to document a revision history. The fields **Last Saved** and **Configurator Version** are filled in when saving the project. When creating a new project without having it saved for the first time, those fields are empty.



General System Settings Datapoint Naming Rules CEA709 CEA709 AST BACnet KNX **Info**

Author  Last Saved

Reference  Created by Configurator Version

Comments

Figure 31: Info tab in project setting.

## 4.4 Using the LINX Configurator

### 4.4.1 Starting Stand-Alone

Go to the Windows **Start** menu, select **Programs, LOYTEC LINX Configurator** and then click on **LOYTEC LINX Configurator**. This starts the Configurator and the main window with the data point tab is displayed.

If the LOYTEC device is not yet connected to the network, go to the **Model** menu and select the device model to be configured. If the device is already connected to the network it is recommended to connect the Configurator online to the device.

### To Connect to a Device Stand-Alone

1. Select the direct connection method by clicking on the **Connect to device** button



in the tool bar of the main window. The connect dialog as shown in Figure 32 opens containing the managed device connection templates.






Figure 32: Connection dialog.


2. To add a new device connection, click on the **New Device Connection** button  or select an existing connection in the tree on the left-hand side and click on the **Duplicate** button .
3. Enter a name for the connection.
4. Enter the admin password. The default password is 'loytec4u' (older firmware versions used 'admin').
5. Choose a **Connection Type**. Possible options are:
  - a. **Web service** (recommended): Firewall-friendly connection using HTTP or HTTPS.
  - b. **TCP/IP**: This uses the IP protocols FTP and Telnet or SSH to connect to the device.
  - c. **CEA-709 (NIC)**: Connection via a LOYTEC CEA-709 network interface.
6. For IP-based connection methods enter the host name or IP address of the device. Optionally, click on **Use secure connection** to enable encrypted SSH or HTTPS access to the device.
7. If your device is located behind a NAT router or firewall, you may change the FTP, Telnet, SSH, HTTP and HTTPS ports to your needs for accessing the device.
8. If the CEA-709 connection method is used, enter the CEA-709 address information and choose a network interface.

- Click on **Save** to store that connection.

---

*Note:* If you connect without having the connection settings saved, a dialog asks whether to use the changed settings temporarily for this connection only. In this case the existing connection is not altered.

---

- Organize device connections into folders. To add a new folder, click on the **New Folder** button  and enter a folder name. Drag the new device connection onto the new folder.
- Click on **Connect**. This establishes the connection to the device.

#### 4.4.2 Uploading the Configuration

To get the current data point configuration of the device, the configuration needs to be uploaded. This will upload the entire configuration from the device, including data points, NVs, registers, client mappings, schedules, etc.

##### To Upload a Configuration

- Click on the **Upload Configuration** button



in the tool bar. The configuration upload dialog opens up as shown in Figure 33.

- If the check box **Automatically sync local dynamic NVs** is enabled on a CEA-709 device, the Configurator uploads any manually created dynamic NVs and merges them into the data point configuration.
- Click on the button **Start** to start the transfer. This will upload the configuration of all ports.




Figure 33: Configuration upload dialog.

- When the project settings of the configuration being uploaded specify to ask, which specific parameters shall be uploaded, check the needed information and proceed.


5. If parameters are selected to be uploaded and their values have changed on the device, the parameter merge dialog appears. For resolving the reported conflicts refer to Section 3.1.5.
6. If dynamic NVs were synchronized, click on **Finish**.

### 4.4.3 Create User Registers

User registers are data points on the device that do not have a representation on the network. Thus, they are not accessible over a specific technology. A register merely serves as a container for intermediate data (e.g., results of math objects). Since a register has no network direction, it can be written and read. Therefore, it is created as a value data point. For backward compatibility, it is still possible to generate two data points for each register, one for writing the register (output) and one for reading the register (input).

#### To Create a User Register

1. Select the **User Registers** folder under the device folder.



2. Right-click in the data point list and select **New Datapoint...** in the context menu. This opens the register creation dialog as shown in Figure 34.






Figure 34: Create a user register.

3. Enter a **Datapoint Name** for the register. You may leave the **Register Name** blank to give the underlying register the same name as the data point.
4. For analog registers choose appropriate units for the metric (SI) and U.S. unit systems. To specify a non-convertible unit type in the desired unit as a free text.
5. The standard setting is a value data point for read/write. Optionally, deselect the value option and select the read data point or write data point check box. This is necessary when configuring for an older firmware version.
6. Select **Create as Parameter** if needed. In this case, the register will be a persistent parameter. It can be done later in the data point properties also.
7. Select a **Type**. Available are “Analog”, “Binary”, “Multistate”, “String”, “Variant” or “User”.

8. When selecting **User**, a register with a user-defined structure is going to be created. Click on  next to **Custom Type** in order to select a structure type.
9. In the dialog **Select Custom Type** choose the type **Category** in the drop-down list and the desired user type. Then click the button **Select**.



10. Click Create Register.
11. If needed create additional registers from the dialog. Finally, click **Cancel** to exit the dialog.

#### 4.4.4 Configuration Download

After the data points have been configured, the configuration needs to be downloaded to the device. For doing so, the device must be online. If the device is not yet connected to the network, the configuration can be saved to a project file on the local hard drive.


##### To Download a Configuration

1. Click on the **Download Configuration** speed button



in the tool bar of the main window. This will open the configuration download dialog as shown in Figure 35.

2. If the project settings specify to ask (see Section 4.3.1), which specific parameters shall be downloaded, check all that apply and click **Ok**.



3. Click **Start** to start the download. Each of the actions is displayed in the **Task List** section of the dialog. The current progress is indicated by the progress bar below.
4. If parameters are selected to be downloaded and their values have changed on the device, the parameter merge dialog appears. For resolving the reported conflicts refer to Section 3.1.5.
5. When the download process has finished, a notification window appears, which has to be acknowledged by clicking **OK**.






Figure 35: Configuration Download Dialog.

#### 4.4.5 Upload the System Log

The system log on the device contains important log messages. Log messages are generated for important operational states (e.g., last boot time, last shutdown reason) or errors at run-time. This file is important for trouble-shooting and is also available on the Web. The file can also be uploaded from the device with the Configurator.

##### To Upload the System Log

1. Connect to the device (see Section 4.4.1).
2. Click on the **Upload system log** button



in the tool bar. The upload system log dialog as shown in Figure 36 opens showing the upload progress.





Figure 36: Upload system log dialog.

- When the upload is finished, click on **Show System Log**. The system log window appears as shown in Figure 37.



Time	Level	Type	Text
2011-06-16 11:13:14.586	NOTE	Application	Log initialized - LINX-100 V4.1.0 Build Thu May 19 16:03:13 2011
2011-06-16 11:13:14.597	NOTE	Application	Serial# 011514-80000010EA21
2011-06-16 11:13:24.244	NOTE	Application	Device IP address 192.168.1.254, hostname 'new'
2011-06-16 11:13:27.334	NOTE	Application	Boot process finished

Figure 37: System log window.


- Click on **Save** to store the system log into a file on your local hard drive.

#### 4.4.6 Backup and Restore

The Configurator provides a backup and restore function for the connected device. It is highly recommended to create a device backup once the device configuration has been completed. This backup can be used in the case a device needs to be replaced in the network.

##### To Create a Backup

- Connect to the device (see Section 4.4.1).
- Choose the menu Tools → Backup Device Configuration ....
- A file requestor opens. Choose a location to store the ZIP file of the device backup. The suggested file name contains device IP address and creation date.
- Click on **Save**. The backup is being uploaded.



##### To Restore a Backup

- Choose the menu Tools → Restore Device Configuration ....
- In the file requestor choose a backup ZIP file and click **Open**.
- The Configurator restores and reboots the device. The process is complete when the device has finished rebooting.

#### 4.4.7 Create Projects for SI and U.S. Units

Project engineering in the Configurator can be started using the unit system of choice, either metric (SI) or U.S. From that point on, all values in the Configurator are displayed in the chosen unit system.


For analog data points with a convertible network unit, the Configurator provides two unit representations, one to be used in the metric (SI) system, and one used in the U.S. system. The value is converted from the network unit to the unit of the chosen unit system. When creating analog data points, both unit representations are chosen from the network unit as appropriate. One can adapt these settings to the project's needs.

Since both unit representations can be specified, a project can be engineered to run in a metric (SI) and U.S. environment. Even when using a fixed data point configuration on the device, it can be switched to the desired unit system. All values on the device are processed in that

chosen unit system, including Web UI, OPC server, parameter file, global connections, and programmable logic.

### To Start a Project In U.S. Units

1. In the Configurator menu go to **Settings → Project settings ...**
2. Click on the tab **General**.
3. Under **Unit setting** choose **U.S.** in the drop-down box. The check box **This unit system will be set on device on download** is set as a default. This ensures the device will run on the chosen unit system.




Unit settings

Data point units: U.S. ☒ This unit system will be set on device on download

4. Click **OK**.

### To Create Data Points in U.S. Units

1. Create a data point and choose the appropriate U.S. unit.
2. On existing analog data points, choose the appropriate U.S. unit in the data point properties. Compatible units to the network unit are shown first. The active unit system is indicated.



Network unit	✓	°C
Unit SI	✓	°C
Unit U.S. (active)	✓	°F

3. Enter all analog values such as default, min/max values, etc. in U.S. units. The unit is indicated next to the data point property.



Default Value [°F] ☒ 68

### To Create Projects For Both SI and U.S. Units

1. On the **General** tab of the **Project Settings** dialog, deselect the check box **This unit system will be set on device on download**. Choose your unit system of preference to be used in the Configurator for the project design.
2. Create data points and choose both appropriate units for metric (SI) and U.S. unit systems.
3. In program logic evaluate the system register **Unit System** in order to select appropriate sets of coefficients for regulators.
4. Download the data point configuration to the device. The device can be switched to the desired unit system using the Web UI or the system register **Unit System Set**.

---

**Important!**

*When changing the unit system, the device needs to be rebooted and will reset all persistent values to their default values converted to the chosen unit system.*

---

## 4.5 Connections

### 4.5.1 Create a New Connection


After having configured the device's network ports with data points, internal connections between those data points can be created. Usually, the manual method to create a connection is used to create connections between different named data points.

A connection is an internal mapping in the device between input and output data points. A connection always consists of one or more data points. A value update from an input data point (sender) is distributed to all output data points (receivers). A status change of a receiver data point is propagated back to all sender data points. All data points in the connection must be of a compatible type or use an adaptor.

By adding data points as sender and receiver to the same connection, they transfer values in both directions. Doing so with connected data points, bi-directional connections can be built.

#### To manually create a new connection

1. Click on the **Local Connections** tab



2. in the main window and press the speed button **Create new Connection**. In the menu choose **Standard Connection**. A new connection is added to the connection list. Rename the connection if you want to do so.

ID	Name	Members
1000	New Connection	0

3. Over the list **Datapoints in connection** on the right-hand side click on **Attach Data Point** to add data points for this connection. This opens a list of all available data points. Select one and press **OK**. You may use multi-select to select more than one data point at a time.

*Note:*

*By default only compatible data points are displayed. Sometimes compatible data points are available as member points (e.g., a SNVT structure member). Click on to expand the data point and select the desired member point.*

4. Now the connection tab contains the new connection and below the list of data points in that connection as shown in Figure 38.







Figure 38: Connection tab with a connection and data points.

5. Change the direction by modifying **Send** or **Receive**. For changing multiple data points use multi-select. Optionally, select **Disable** to temporarily exclude this data point from communication in the connection.
6. For receive items you may optionally define a forward **Delay** in seconds (see Section 3.3.5).
7. If the attached data point needs a conversion, the item displays a yellow exclamation mark  and the default conversion (e.g. 'Analog to CEA-709/motor\_state\_t'). By clicking on the button  to view the current conversion.
8. To add a new conversion to this item, click on the  button. A dialog opens, which displays the matching adaptors already available in the library as shown in Figure 39.






Figure 39: Choose a custom conversion.

9. Select an existing conversion, click the plus button  to create a new conversion, or click the edit button  to modify an existing conversion.
10. An example for editing an analog to multi-state value conversion is shown in Figure 40. Enter a **Conversion name**, then edit the **Value range from** column and select the desired **Target state** mapping.





Figure 40: Edit an analog to multi-state conversion.

11. Click **Save** and then choose the newly created conversion by clicking **Select**.
12. The items with an assigned value conversion appears with a green checkmark .

### To Create a Connection via Drag-and-Drop

1. Change to the **Datapoints** tab of the main window and navigate to the data point that shall be put into the new connection.
2. In the properties view below the data point list click on the **Local Connections** tab as shown in Figure 41.
3. Then simply drag a data point from the data point list and drop it onto an empty area in the connections list as shown in Figure 41.




Figure 41: Create a connection with drag-and-drop.

4. To add data point to that connection, drop the new data point into the empty area in the connected data points list below.

### To Create a Bi-Directional Connection

1. Start the connection by adding a data point. A value data point is added as **Send** to a new connection.
2. Then add the same data point a second time and do not create a multi-slot connection. This time it is added as **Receive**. This makes the data point send to and receive values from the connection.
3. Continue by adding the data point, which shall be connected. A value data point is added as **Receive** to an existing connection.
4. Then add the same data point a second time to that connection. This time it is added as **Send**.
5. Now both data points send values to and receive values from the connection. This synchronizes value changes back and forth between the involved data points. Update loops are suppressed by the connection. It is not necessary to set a COV on any of the involved data points. An example is shown in Figure 42.

Datapoints in connection 'Local Connections/reg1'

Datapoint	Dir	Slot	Slot Name	Type	Conversion	Location
AV1	Receive	1	reg1	Analog Datapoint	ff0	BACnet Port.Data...
AV1	Send	1	reg1	Analog Datapoint	ff0	BACnet Port.Data...
reg1	Receive	1	reg1	Analog Datapoint	ff0	User Registers
reg1	Send	1	reg1	Analog Datapoint	ff0	User Registers

Figure 42: Bi-directional connection.

## 4.5.2 Create Connections from a CSV File

A quick way to perform batch edit on connections is to export and import connections from the connections CSV file. Each line in the connections CSV file identifies a connection. The first column is the connection name. The second column specifies the hub data point. The full path to the data point must be specified using the dot '.' as the folder separator. The third and following columns specify the target data points.


### To Create Connection from a CSV File

1. Select the menu Tools → Export Local Connections ...
2. Select an appropriate file name and export.
3. Edit the connections CSV file. An example is shown in Figure 43.

```
#connection_csv_ver,1
#ConnectionName,HubDPName,TargetDPName
Ai0,LINX-200.BACnet Port.ai0,LINX-200.User Registers.abs_humid1
Ai1,LINX-200.BACnet Port.ai1,LINX-200.User Registers.abs_humid2
Ai2,LINX-200.BACnet Port.ai2,LINX-200.User Registers.abs_humid3
Ai3,LINX-200.BACnet Port.ai3,LINX-200.User Registers.abs_humid4
```

Figure 43: Example Connection CSV File.

4. Select the menu Tools → Import Local Connections ...
5. If connections that are not part of the connection CSV file shall be deleted, click **Yes** when prompted. Click **No** if the other connections shall be left as is.





6. Choose the file to import and click **Ok**.
7. When the import has completed, optionally view the log to check, which connections have been added, modified, and deleted.

## 4.5.3 Modify Connections

Connections can be edited and deleted. This is also done in the **Connections** tab of the main window. Editing connections does not influence the data point configuration. This means, when deleting a connection or adding/removing data points to/from a connection, the data points are not deleted.

### To Edit a Connection

1. Change to the **Local Connections** tab of the main window.
2. Select the connection to edit. Then follow the steps as applied when creating a connection.
3. To detach a data point from the selected connection, select the data point and click on the button  **Detach selected data points** over the connection member list.



4. Change the direction of a data point in the connection by choosing one from the **Dir** drop-down. You may select **Disable** to temporarily exclude this data point from the connection altogether.

#### To Add Data Points via Drag-and-Drop

1. Change to the **Datapoints** tab of the main window and navigate to the data point for being added.
2. In the properties view below the data point list click on the **Connections** tab as shown in Figure 44.
3. Select an existing connection.
4. Drag the selected data point and drop it into the empty area of the **Datapoints in connection** list as shown in Figure 44. This adds the data point to the selected connection.






Figure 44: Modify connections in the properties view.

5. To replace a data point in a connection drop the new data point right onto an existing data point in the connection that shall be replaced.

#### To Delete a Connection

1. Change to the **Local Connections** tab of the main window.
2. Select the connection for removal. Use multi-select to select more than one connection.
3. Click on the button  **Delete Connection** over the connections list.



### 4.5.4 Create a Multi-Slot Connection

A multi-slot connection can be used to connect a number of different data points together under one umbrella. It can be considered as a cable with many wires, each wire represented by a slot with a label. For example, one can create a multi-slot connection for a structured data point, connecting each sub-data point to another technology. All those slots appear under the same connection. But data point only exchange data, if they are added to the same slot.

#### To Create a Multi-Slot Connection

1. Change to the **Datapoints** tab of the main window and navigate to the data point to be connected.



2. Select a structured data point and drag it into the connections list to create a new connection.
3. A dialog prompts the user, whether to create a multi-slot connection or use the user data point as a single entity in the connection. Choose **Yes** to create a multi-slot connection.
4. A multi-slot connection is created as shown in Figure 45. The multi-slot connection can be collapsed or expanded. In the expanded view it shows all slots. Select the top-level multi-slot connection to view all data points in the connection. Select a single slot beneath to view only those data points in that slot.

Connections in 'multislot' Name Filter

ID	Name	Type	Unit/Map
1003	setting1	-	-
	setting1.function	Multistate	CEA-709/setting_t
	setting1.setting	Analog	%
	setting1.rotation	Analog	*

Datapoints in connection 'multislot/setting1'

Datapoint	Dir	Slot	Slot Name	Type	Conversion
setting1.function	Receive	1	setting1.function	Multistate Datapoint	
setting1.setting	Receive	2	setting1.setting	Analog Datapoint	f <sub>0</sub>
setting1.rotation	Receive	3	setting1.rotation	Analog Datapoint	f <sub>0</sub>

Figure 45: Multi-slot connection.

5. Add more slots by dropping data points onto the top-level multi-slot connection 'setting1'.
6. Connect other data points to the slots by dropping them onto the slots. For example connect the register 'regRotation' by dropping it onto 'setting1.rotation' as depicted in Figure 46.

Connections in 'multislot' Name Filter

ID	Name	Type	Unit/Map
1003	setting1	-	-
	setting1.function	Multistate	CEA-709/setting_t
	setting1.setting	Analog	%
	setting1.rotation	Analog	*

Datapoints in connection 'multislot/setting1/setting1.rotation'

Datapoint	Dir	Slot	Slot Name	Type	Conversion
regRotation	Send	3	setting1.rotation	Analog Datapoint	f <sub>0</sub>
setting1.rotation	Receive	3	setting1.rotation	Analog Datapoint	f <sub>0</sub>

Figure 46: Add data point to connection slot.

#### 4.5.5 Create a Math Block Adaptor

When connecting structured data points the multi-slot connection can be used. If a simple mapping of the sub-data points is not possible and a more advanced mathematical conversion is required, a math block adaptor can be created. This math block is based on a multi-slot connection with  $n$  inputs and  $m$  outputs (see Section 3.3.2).

##### To Create a Math Block Adaptor

1. Create a multi-slot connection from a structured data point, e.g., the input data point.

2. Add output slots to the multi-slot connection, e.g. by adding a structured output data point. An example is shown in Figure 47.


Connections in 'math'

ID	Name	Type	Unit/Map
1121	dim_ctrl_Read	-	-
	dim_ctrl_Read.c	Binary	
	dim_ctrl_Read.StepCode	Analog	
	setting1.function	Multistate	CEA-709/setting_t
	setting1.setting	Analog	%
	setting1.rotation	Analog	°

Datapoints in connection 'math/dim\_ctrl\_Read'

Datapoint	Dir	Slot	Slot Name	Type	Conversion
dim_ctrl_Read.c	Send	1	dim_ctrl_Read.c	Binary Datapo...	
dim_ctrl_Read.Step	Send	2	dim_ctrl_Read.StepCode	Analog Datapo...	f <sub>0</sub>
setting1.function	Receive	3	setting1.function	Multistate Da...	
setting1.setting	Receive	4	setting1.setting	Analog Datapo...	f <sub>0</sub>
setting1.rotation	Receive	5	setting1.rotation	Analog Datapo...	f <sub>0</sub>

Figure 47: Multi-slot connection for math block adaptor.

3. Click on the **Create math adaptor from connection**  button. The dialog **Edit Multi-Slot Math Adaptor** opens as shown in Figure 48.

**Edit Multi-Slot Math Adaptor**

Conversion name: DPT\_DimmingControl->setting

Description:

Input Slots


Slot	Slot Name	Dir	Var	COV delta	Triggers Calculation
1	knx_dim_control_Read.c	In	v1	0.0	<input checked="" type="checkbox"/>
2	knx_dim_control_Read.StepCode	In	v2	0.0	<input checked="" type="checkbox"/>

Output Slots

Slot	Slot Name	Dir	Output Value Formula	Write Output if Formula en > 0
3	setting1.function	Out	slot3 = if((v2 = 0), 4, (v1 + 2))	f <sub>0</sub> en = 1
4	setting1.setting	Out	slot4 = if((v2 = 0), 0, (100/exp2((v2 - 1))))	f <sub>0</sub> en = 1
5	setting1.rotation	Out	slot5 = 0	f <sub>0</sub> en = 1


Save Cancel

Figure 48: Edit a math block adaptor.

4. Enter a **name** and **description** for the adaptor.
5. For each output enter an **Output Value Formula**. This can be done by directly typing the formula or by clicking the edit button .
6. Optionally, enter an enable formula into **Write Output if Formula en > 0**. As a default enable is '1'.
7. When finished with the math block click **Save**.

### To Use an Existing Math Block Adaptor

1. Click on the **Local Connections** tab



2. in the main window and press the speed button **Create new Connection**. In the menu choose **Connection with Math Adaptor**.
3. In the dialog **Select Multi-Slot Math Adaptor** select an existing adaptor and click **Select**. A new multi-slot connection is added to the connection list with empty slots as depicted in Figure 49.




Figure 49: Created new multi-slot connection from math adaptor.

4. Now connect data points by dragging and dropping them onto the empty slots in the data point list below.
5. To view the math conversion click the magnifier button .

### 4.5.6 Connection Overview

Select the **Connection Summary** tab to get a graphical representation of all connections. It represents the two connected data points, their technology they are based on and the direction of the connection. An example for the overview is shown in Figure 50.

Datapoints	Connections	Connection Overview		Statistics	L-Web Projects		
Datapoint		△	Tech	Dir	Tech	Datapoint	Connection
LINX-201.User Registers.reg0_Read			Reg	➡	BACnet	LINX-201.BACnet Port.Datapoints.ai0	ai0 (10CB)
LINX-201.BACnet Port.Datapoints.ai0			BACnet	⬅	Reg	LINX-201.User Registers.reg0_Read	ai0 (10CB)
LINX-201.User Registers.reg1_Read			Reg	➡	BACnet	LINX-201.BACnet Port.Datapoints.ai1	ai1 (10CC)
LINX-201.BACnet Port.Datapoints.ai1			BACnet	⬅	Reg	LINX-201.User Registers.reg1_Read	ai1 (10CC)
LINX-201.User Registers.reg2_Read			Reg	➡	BACnet	LINX-201.BACnet Port.Datapoints.ai2	ai2 (10CD)
LINX-201.BACnet Port.Datapoints.ai2			BACnet	⬅	Reg	LINX-201.User Registers.reg2_Read	ai2 (10CD)
LINX-201.User Registers.reg3_Read			Reg	➡	BACnet	LINX-201.BACnet Port.Datapoints.ai3	ai3 (10CE)
LINX-201.BACnet Port.Datapoints.ai3			BACnet	⬅	Reg	LINX-201.User Registers.reg3_Read	ai3 (10CE)

Figure 50: Connections Summary.


### 4.5.7 Create a Global Connection

Global connections are an easy way to publish or subscribe to global data, which is distributed among devices. To configure such communication, a device needs to be member of a CEA-852 channel. Once it is member of that channel, global connections need to be configured in the data point configuration. This is similar to creating local connections and most of the configuration steps apply also for global connections. In addition, also network timing parameters can be configured for global connections. For a description see Section 3.3.4.

If other devices already have global connections configured that publish data on the network, their definition can be exported and imported into the new configuration. That will make all the global connection names available. When creating manually, the connection names can be edited.

#### To Create a Global Connection

1. Click on the Global Connections tab



2. in the main window and press the speed button **Create new Connection**. A new connection is added to the connection list.
3. Define a name for the global connection. This name is required to be unique on the network. Data will be published or subscribed to under this name.

ID	Name	Members
1000	outdoorTemp	1

4. Add data points to the global connection as described in Section 4.5.3. As a default, output data points will be added as sending, input data point as receiving data under the global connection.
5. Change the direction by modifying **send** or **receive**. For changing multiple data points use multi-select.

Datapoint	Dir	Type
temp_Write	Send	Analog Datapoint

6. Define timing parameters for a global connection that is sending out data. On the global connections tab of the main window the connection properties are listed below the data point member list. In the tab of the property area click the button .




Properties of connection		
Name	Value	Description
Connection Name	outdoorTemp	Name of the c
Max. Send [s]	0	Send to netw
Min. Send [s]	0	Limit network

7. To export the definitions of the created global connections, click the button **Export connections to disk** and choose the XML format.
8. To use those definitions, click the button **Import connections from disk** and choose an exported connections XML file. This creates the global connections structure with connection names but without any data points. Data points can then be added, for example, via drag-and-drop.

### 4.5.8 Automatic Generation of Connections

The *smart auto-connect* feature of the Configurator provides a quick way to automatically generate target data points out of a source data point selection and generate connections to them. Using this feature a gateway interface is generated with a few mouse clicks.

#### To Auto-generate Data Points and Connections

1. Go to the **Datapoints** tab.
2. Select those data points of a given port folder that shall be mapped to another technology. The methods include sub-folders, data point name filter and multi-select may be used for doing this.
3. Click on the speed button  **Generate and connect selected** in the tool bar.
4. Alternatively, you can select the port folder or any sub-folder and click the speed button  **Folder-wide Generate points and auto-connect** in the tool bar. This generates target data points and connections for all data points in the folder.
5. The auto-generate preview dialog opens as shown in Figure 51. Choose the target technology. The preview results show a list for each source type found how it will be created as a target type. The **Type Name** column provides a drop-down to modify the result. This choice is remembered and will be applied the next time again. You may click the **Restore defaults** button  to revert all custom settings.





Figure 51: Auto-generate and connect preview.

*Note:* The respective port may have to be enabled first in the project settings to have the target technology available in this dialog.

6. If the selected target technology offers choices on the direction to create, choose one of the offered directions.

From	Class	Direction	Type Name	Unit/Map	To	Class	Direction	Type Name
BACnet	Binary	Value	Binary Output		CEA-709	User	nvi + nvo	SNVT_switch

7. Structured data points will be flattened in some target technologies. To prevent this from happening, click the **Don't expand structured data points** button . Note, that this may require an auto-generate template, which defines how to map this structured data point.
8. Select an auto-generate template in the drop-down box of the **Template** column as shown in Figure 52.




Figure 52: Auto-generate and connect with auto-generate template.

- After having reviewed all types, click the **Generate** button.


Note, when auto-creating the target data points, the Configurator initializes their properties with default values derived from the properties of the source data points. In particular, the data point name, description, minimum and maximum value, and engineering units are generated. If the default properties do not have the desired values, the user can edit them in the target folder. The user can also craft an auto-generate template where those properties are pre-set.


To auto-generate target data points into multiple technologies from the same source data points, execute the auto-generate and connect function multiple times on the source data points. Select different target technologies in sub-sequent auto-generate actions. The new data points are added to existing connections. This makes it easier to keep track of auto-generated local connections involving multiple technologies.

#### 4.5.9 Create an Auto-Generate Template

If the implicit options for generating target types are not sufficient for the envisioned task, a specialized auto-generate template can be crafted. This template contains copies of the source data points as a starting point. The user can then create instances of the desired target data points and use one or more connections (e.g., a multi-slot connection for sub-data points of a structured source). The target data point name and description can contain variable placeholders, which expand to the name and description of the actual sources, which the auto-generate template will be applied on. If required, one can add conversion adaptors including math blocks. The entire configuration serves as a template on how to generate the target data points and apply the appropriate connections. Once saved in the template library, it will be available for selection in the preview dialog.

##### To Create an Auto-Generate Template

- Select the source data points and invoke auto-generation as described in Section 4.5.8.
- In the preview dialog select the source type for which a new template shall be created and click the **Create template for selected source**  button.



- The auto-generate template editor opens as shown in Figure 53. It contains two data point lists. The left-hand (denoted '1') list is pre-filled and contains the selected source data points. They are locked and cannot be modified. The right-hand list (denoted '2') is intended for creating the desired target data points.




Figure 53: Auto-generate template editor.

4. Enter Name and Description, which is used later to select the auto-generate template.
  5. Right-click in the target data point list and select **Create Data Point ...**. The creation dialog of the respective target technology opens. Create the desired target data points, e.g., a BACnet 'MO' data point with a custom multi-state map.
  6. Edit the target data point name to use a variable placeholder for the target data point name such as `%{name}`. Insert the placeholder by selecting the desired entry of the **add var** drop-down list. When applying the auto-generate template, the placeholder is expanded to the name of the actual source data point. Choose `%{path}%{name}` to flatten the folder tree of the source data point and include the path in the target data point name.
- Datapoint Name    `%{name}`    add var ▼
7. Drag and drop the source and target data points into the **Connections** tab below to create the needed connections. Add custom conversions to the connection items as needed.
  8. Click **OK** to store the auto-generate template.
  9. From now on it can be selected in the **Template** column and applied to the source.



From	Class	Direction	Type Name	Unit/Map	To	Class	Type Name	Template	Unit/Map
CEA-709	Multistate	Output	SNVT_motor_state	motor_state_t	BACnet	Multistate	Multistate Output	SNVT_Motor->MO	bac_fan_sta


#### 4.5.10 Create a Complex Auto-Generate Template

Simple auto-generate templates as described in Section 4.5.9 are based on single data point sources. These can be scalar or structured data points. In any case the decision, which auto-generate template applies, is based on that single data point. If a given set of source data points shall generate another specific set of target data points, so-called *complex* auto-generate templates can be used. These are based on folders that contain the described data points (i.e., name and types must match). With a complex auto-generate template the entire folder is used as a source and an entire target folder will be generated with the target data points defined by the complex auto-generate template.


For example, there are device folders of similar devices on the BACnet port. These shall serve as the connection source. One such device folder contains three analog data points named 'TempComfort', 'TempNight', 'RoomTemp' that have '°C' as engineering units. These shall generate two target data points, one a structured data point with the setpoints 'TempComfort' and 'TempNight' connected (e.g. a SNVT\_temp\_setpts) and one data point with the 'RoomTemp' connected (e.g., a SNVT\_temp). A complex auto-generate template is created based on one of the device folders.

### To Create a Complex Auto-Generate Template

1. Select the source folder and invoke auto-generation as described in Section 4.5.8 using the button  **Folder-wide Generate points and auto-connect** in the tool bar.
2. In the preview dialog choose generation based on **folder templates only**. The list will then be empty as no such template yet applies. Then click the **Create template for selected source**  button.



3. The auto-generate template editor opens as shown in Figure 53. It contains two data point lists. The left-hand (denoted '1') list is pre-filled and contains the selected source data points. They are locked and cannot be modified. The right-hand list (denoted '2') is intended for creating the desired target data points.
4. Enter **Name** and **Description**, which is used later to select the auto-generate template.
5. Right-click in the target data point list and select **Create Data Point ...**. The creation dialog of the respective target technology opens. Create the desired target data points, e.g., a SNVT\_temp\_setpts and a SNVT\_temp.
6. Edit the target data point name and local NV name. Since the source data point names will be equal for all source folders, an additional component may be added to the target data point name. Use the variable placeholder `%{path}` in the name to make it unique. Insert the placeholder by selecting the desired entry of the **add var** drop-down list. When applying the auto-generate template, the path placeholder is expanded to the actual folder path relative to the **Datapoints** folder.



7. Drag and drop the source and target data points into the **Connections** tab below to create the needed connections. Add custom conversions to the connection items as needed.
8. Click **OK** to store the auto-generate template.
9. From now on it can be selected in the **Template** column and applied to matching source folders.

	Matching Folder	Template Name
1	Datapoints.Device1	BACnet FanCoil -> SNVTs

## 4.5.11 Managing Connection Resources

All described resources for connections, including connection adaptors and auto-generate templates are part of the configuration project. When opening the project file on another PC, all project resources will be merged into the local resource repository. After opening a project file, all its resources are therefore available to new projects.



The Configurator provides a resource manager, that can be used to view, edit, import and export connection resources. Select the menu **Tools → Manage Connection Adaptors ...** or **Tools → Manage Auto-Generate Templates ...** to open the resource manager dialogs.

## 4.6 E-mail Templates

### 4.6.1 Create an E-mail Template

E-mail templates are used to assemble and transmit e-mails when certain trigger conditions occur. The e-mail template contains the destination e-mail address, the subject, and text. Variable parameters can be added to the text by using data point sources. The transmission of an e-mail is triggered by one or more trigger data points. For setting up e-mails, the e-mail account information has to be configured on the device, e.g., on the Web UI (see Section E-Mail configuration in the LOYTEC Device User Manual [1]).

#### To Create an E-mail Template

1. Under the **Global Objects** folder, select the **E-mail Configuration** sub-folder.
2. Right-click and select **New E-mail Template ...** from the context menu.
3. In the **Configure E-mail Template** dialog, which is shown in Figure 54 enter the **To** address and the **Subject**. Optionally, **Cc** and **Bcc** addresses can be specified.





Figure 54: Configure E-Mail Template Dialog.

4. Enter text in the **E-mail Text** multi-line field.
5. If the e-mail text shall contain values of data points, add data points to the **Data Sources** list by clicking the **Add...** button.
6. A data point selector dialog opens. Select one or more data points and click **OK**. The selected data point appears in the **Data Sources** list.



7. If necessary, edit the **Format** string. The default ‘%.2f’ will format the value as a floating point with 2 decimals. You may choose a different format string from a drop-down list of pre-defined formats, including date/time formats.
8. Select the data point in the **Data Sources** list. In the drop-down box underneath select **Selected Data Source Value**, in the next drop-down select **to text** click the **Paste** button. Variables can also be pasted to the subject line or any of the address lines.



9. A place holder `%{v1}` for the data point value appears now in the e-mail text (see Table 5 in Section 3.4.5).
10. To replace an existing data source select the data point in the **Data Sources** list and click the **Replace...** button. This opens a data point selector dialog for choosing the replacement data point.


## 4.6.2 Trigger E-mails

E-mail templates are used to assemble and transmit e-mails when certain trigger conditions occur. For an e-mail template, one or more trigger conditions can be defined. The e-mail will be sent, when one of the trigger conditions is activated. Depending of the trigger data point type, the trigger conditions can be refined.

Note, that the behavior of the trigger data point is influenced by the COV properties of the data point. If the **Only notify on COV** property is checked, the data point triggers only if its value changes to the value of the trigger condition. If that property is not checked, the data point triggers on every write with a value that matches the trigger condition.

The trigger for sending an e-mail can be enabled or disabled altogether by using an *enable* data point. This data point must be of type *binary*. If the value of that enable data point is TRUE, the trigger conditions are evaluated. If the value of the enable is FALSE, no e-mails are be triggered.

### To Create an E-mail Trigger


1. Under the **Global Objects** folder, select the **E-mail Configuration** sub-folder.
- 
2. Right-click and select **Configure E-mail Template ...** from the context menu.
  3. Change to the **Mail Triggers** tab.

---

*Note:* Of course, you can also change directly to the **Mail Triggers** tab when creating an e-mail template.

---

4. Click the **Add...** button. A data point selection dialog opens.
5. Select one or more data points and click **OK**.

6. The triggers appear now in the **E-Mail Triggers** list. The data points that serve as e-mail triggers also appear with the e-mail icon  in the data point list.

E-Mail Triggers			Add...	Remove
Datapoint	Type	Condition		
Critical	Alarm Server			

7. In the **Manage Trigger Conditions** you can setup the trigger condition depending on the trigger data point class.
8. If the trigger condition is depending on the value of an enabling data point, you can add an enable data point by clicking on the ... button.

Select datapoint to enable/disable E-Mail template (currently enabled)

	...
--	-----


9. To remove such a trigger enable, click the **Remove Enable Trigger** button.

### 4.6.3 Attachments

E-mail templates can be configured to have file attachments. Basically, any file of the device can be specified as an attachment.

#### To Configure Attachments

1. Under the **Global Objects** folder, select the **E-mail Configuration** sub-folder.



2. Right-click and select **Configure E-mail Template ...** from the context menu.
3. Change to the **Attachments** tab.

---

*Note:* Of course, you can also change directly to the **Attachments** tab when creating an e-mail template.

---

4. Select an available file from the **Attach File** drop-down box.

Attach File	system.log	▼	Add
-------------	------------	---	-----

5. Click the **Add** button. The file appears in the **Attachments** list.

Attachment	Device File Path
system.log	/var/log/system.log

6. To remove an attachment, select the attachment file in the **Attachments** list and click the button **Remove**.

### 4.6.4 Limit E-mail Send Rate

The transmission of e-mails is triggered by the configured trigger conditions. It is not predictable, how often the trigger condition will cause the transmission of an e-mail. The e-mail template can be configured to limit the number of transmitted e-mails. This is done in the Configure E-mail Template dialog.

To configure an E-mail Rate Limit, configure the settings:

- **Max. E-mails per day:** This setting defines how many e-mails can be sent on average per day. The actual number of transmitted e-mails on a specific day may be slightly

higher than this setting, depending on burst rates. The default is 100 e-mails per day. This results in an average interval of one e-mail per 14 minutes.

- **Send burst count:** This setting defines how many e-mails may be transmitted shortly after each other not limited by the above average interval. After the burst count, the average mails per day limit takes effect. The default is a maximum of 20 e-mails in a row.


## 4.7 Local Schedule and Calendar

### 4.7.1 Create Calendar Patterns

When working with global definitions for calendar-based exception days such as “Holidays” a local calendar is used and needs to be configured with calendar patterns. A calendar pattern represents a class of days such as “Holidays”. The calendar patterns can then be used in a schedule to define daily schedules for exception days. The available calendar patterns should be created when the system configuration is engineered. The actually dates in the calendar patterns can be modified later at run-time.

#### To Create a Calendar Pattern

1. Locate the calendar object. When using a generic scheduler the corresponding generic calendar already exists in the **Scheduler** folder under the device folder. For a technology calendar, select the **Calendar** sub-folder of the respective port.



2. Select the calendar data point.

No.	Direction	Calendar Name
1	In	calendar

3. Right-click and select **Create Calendar Pattern...**
4. Enter a Pattern Name in the **Create Calendar Pattern** dialog



5. Click **Create Pattern**. The dialog closes and the calendar pattern appears beneath the calendar data point.


Local calendar objects							
	No.	Direction	Calendar Name	Index	Func. Block	Use	ID
☐	1	In	calendar			0	1030
	1.1		Holidays				1032

### 4.7.2 Create a Local Scheduler

For scheduling data points, a scheduler object must be created. Under each port folder, multiple local scheduler objects can be created. These local schedulers can then be configured to schedule data points.

#### To Create a Local Scheduler

1. Under the device folder, select the **Scheduler** sub-folder to create a generic scheduler. For a technology scheduler, select the **Scheduler** sub-folder of the respective port.



2. Right-click in the data point list view and select **New Local Scheduler ...**.
3. Enter a name for the schedule and a description. Note, that the schedule automatically detects a calendar, if it has previously been created.

4. Click **Create Schedule**. The new schedule appears in the data point list of the Scheduler sub-folder.

### 4.7.3 Configure Scheduled Data Points

When a local scheduler has been created, it needs to be configured, which data points it shall schedule. This is done by attaching data points to the scheduler. Note, that there may be limits, how many and which data points may be attached (see Section 3.7.3).

This configuration must be done as an initial setup. The scheduled data points and daily schedules can be changed later in the Web UI or over the network.

#### To Attach Data Points to a Scheduler

1. Select the scheduler data point in the Scheduler sub-folder.
2. Right-click and select **Configure Schedule** from the context menu. The same dialog which appears when a new scheduler is created is shown and allows configuring the scheduler. Of course, this step can also be done directly when the data point is created.
3. Select the tab Scheduled Datapoints.


Datapoint	Description	Location	Group	Default
-----------	-------------	----------	-------	---------

4. Click the button **Attach ...**. This opens another data point selector window.
5. Select the data points to attach and click **OK**. For each of the attached data points, one or more lines appear in the list below the attach button. If the attached point is a structure, there will be one line for each element of the structure.

#### Tip!

*Data points can also be attached to a scheduler by selecting a data point in the data point manager, drag it onto a scheduler data point and drop it on the scheduler data point.*

6. Enter a short text in the **Description** field in the second column of each line. This text will serve as a label, which will be shown on the device's UI to identify the data point.



7. Add new value presets by entering a name and pressing the **Create** button next to the input field.

New Preset Name

---

**Tip!**

To generate presets automatically for multi-state data points, click the **Auto-Create** button. This button is available, if no other presets have been defined yet.

---

8. For each new preset, a new column will appear in the list. In this column, enter the desired value for each of the attached points, which will be set when this value template is scheduled. The user may later edit the values for each preset on the device but cannot add new value presets unless there is only one line (one value) in the list.

Datapoint	Description	Group	Default	day	night
NV_bac_IonCtrlInvo12_temp	temp	1	0.00	21.00	16.00

9. If there are multiple output values which belong together, they can be grouped in order to save space on the device. For each group, the entered value is stored only once, even if there are more data points in the same group.

Datapoint	Description	Group	Default	day	night
NV_bac_IonCtrlInvo12_temp	temp	1	0.00	21.00	16.00
NV_bac_IonCtrlInvo13_temp	temp	1	0.00	21.00	16.00

10. When done with the point and value setup, switch back to the **Configuration** tab or click **Save Changes** to leave the dialog.

---

**Tip!**

A shortcut to creating a scheduler object and attaching a data point is to select a data point in the data point manager, right-click on it and choose **Schedule Datapoint** from the context menu. This generates a scheduler and links that data point to it.

---

#### 4.7.4 Configure Scheduled Events


Once a scheduler is configured with attached data points and value presets, the schedule events can be defined. This can be done on the device or over the network at run-time, or also in the configuration software. A schedule consists of a number of scheduled events, each event starts at a defined time, has a scheduled value and ends at a defined within the same 24-hour period (starting at 00:00 and ending at 23:59 hours). The event can be configured to occur at a given date, for each weekday, or for a number of recurring dates.


In addition, scheduled events can be configured to occur on exception days from a calendar, such as "Holidays". An exception day always overrides a normal weekday. If more than one exception day is used, a priority must be assigned. This is necessary so that the system knows which schedule to follow on a day which matches more than one calendar pattern. Considering the priorities the calendar preview shows the effective schedule on a given day.

##### To Configure a Scheduled Event

1. Open the **Configure Schedule** dialog and click on the **Configuration** tab (see Section 4.7.3).

- In the calendar view select the day for which to configure the scheduled event. Then select the event duration by clicking into the daily planner and dragging the mouse to the desired duration.



- Then click on the button **Create new scheduled event**  and enter a **Name** for the scheduled event (note, in BACnet there is no name to be specified). Choose the scheduled **value** or enter a scheduled value. Modify the **Start** and **End** time to your needs. Optionally you should set a priority, if scheduled events overlap in the preview.

Event

Name

Value

Start  End

Priority

Duration

- Choose an **Event type**, which defines how the event is recurring.

Event type

☐ One-time


☒ Daily


☐ Weekly


Start

End

- The click **OK**. The new event appears in the daily planner.




- For viewing more details on overlapping events you can change to the **day view** . In all views events can be extended or shrunk using the upper or lower boundary handles or moved by clicking and dragging.
- Right-click on an event in order to edit it. You can choose to modify it, change its color, or delete it.
- To set a default value, right-click onto the grey area right above the day planner. In the context menu choose a default value.



### To Use Exception Days from a Calendar

1. For letting a scheduled event occur on exception days from a calendar, create a new scheduled event.
2. Select the event type **Calendar**, and choose one of the defined **calendar date entries**.



3. Note, that if the scheduled event may overlap with other events. In this case edit the priorities of the scheduled events. For example, if a given calendar day falls in both categories, “Holidays” and “Maintenance”, the scheduled event with the higher priority becomes effective. The highest available priority is marked **highest**. Note that the actual priority values depend on the technology (see Section 3.6.4).

---

**Important!**

*Choose different priorities for different scheduled event. If two scheduled events overlap and their priorities are equal, it is not determined, which value is in effect.*

---

## 4.7.5 Configure Exception Days

When a local calendar is used, its calendar patterns need to be configured with exception days (pattern entries). The calendar patterns can be configured in the Configurator software, modified at run-time over the Web UI or over the network. When configuring in the software, the current exception days should be uploaded from the device, to work on the current configuration.

### To Configure Exception Days in a Calendar Pattern

1. Click on the Upload calendar/scheduler configuration button



in the tool bar of the main connections window. Click **OK** when the upload is finished.

2. Select the **Calendar** sub-folder and select the calendar pattern, which shall be configured

	No.	Direction	Calendar Name	Index	Func. Block	Use	ID
⊞	1	In	calendar			1	1030
	1.1		Holidays				1032

3. Right-click and select **Configure Pattern ...** in the context menu.
4. The **Configure Pattern** dialog appears as shown in Figure 55. Add dates to the calendar pattern by entering a Date Configuration. Then click **Add Entry**. The date appears in the Pattern Entries list on the right-hand side.
5. Edit an exception by selecting the pattern entry in the **Pattern Entries** list. Then modify the date configuration in the **Date Configuration** group box.



Figure 55: Configure Calendar Pattern Dialog.

6. Click **Save Changes** when all exception days have been entered.

**Tip!**


*If not sure, how a date configuration affects the calendar days, click on a pattern in the **Pattern Entries** list and the affected days will be highlighted in the **Preview**.*

#### 4.7.6 Configure Control Data Points

A scheduler object can be configured to use special control data points. These data points can control the scheduler and expose additional state information of the scheduler on the network. The following control data points are available:

- **Scheduler Enable/Disable Datapoint:** This data point can be configured, which enables or disables the scheduler depending on its Boolean value.
- **Enable/Disable Feedback Datapoint:** This data point is updated with the current enabled state of the scheduler. This also reflects and an enable from the network.
- **Scheduled Preset Name:** This data point can be attached to be updated with the name of the currently active preset. Only string data points can be attached.

##### To Configure Control Data Points

1. Open the **Configure Schedule** dialog to configure daily schedules as described in Section 4.7.3.
2. Go to the **Scheduled Datapoints** tab.
3. In the **Control Datapoints** group box, click the  button to add the desired control data point. A data point selection dialog opens.

4. Select a matching data point and click **OK**. For the preset name a string data point must be selected.
5. To remove an undesired control data point, click on the **Remove** button.

#### 4.7.7 Using the SNVT\_tod\_event

On LOYTEC devices with the CEA-709 technology the SNVT\_tod\_event can be used in a schedule for implementing the next-state feature. The parts of this network variable contain:

- Current state: This is the currently scheduled occupancy state.
- Next state: This is the next, future occupancy state in the schedule.
- Time to next state: This part reflects the time in minutes until the next state becomes active.

##### To Use a SNVT\_tod\_event

1. Create a SNVT\_tod\_event in the data point configuration.
2. Add the SNVT\_tod\_event to the scheduled data points of a scheduler as described in Section 4.7.3.
3. All three parts of the SNVT\_tod\_event are scheduled.

No.	OPC	Direction		Datapoint Name
1	<input checked="" type="checkbox"/>	Out		nvoTodEvent
1.1	<input checked="" type="checkbox"/>	Out		current_state
1.2	<input checked="" type="checkbox"/>	Out		next_state
1.3	<input checked="" type="checkbox"/>	Out		time_to_next_state

#### 4.7.8 Using the Local Scheduler

Once the setup of the local scheduler is done, it is basically operational. It will immediately start working based on the configuration data downloaded through the configuration software. You can verify the daily schedules and values of scheduled data points on the Web interface. The local schedule can be altered over the Web UI or over the network using the underlying networking protocol.


## 4.8 Local Alarming

### 4.8.1 Create an Alarm Server

To generate local alarms, an alarm server needs to be created at first. The local alarm sources will report alarms to that alarm server. The alarm server is the interface to access local alarms. This can be done over the network or the Web UI.

##### To Create an Alarm Server

1. Under the device folder, select the **Alarm** sub-folder to create a generic alarm server. For a technology alarm server, select the **Alarm** sub-folder of the respective port.



2. Right-click in the data point list view and select **New Alarm Server ....**

3. In the **Create New Alarm Server** dialog box (as shown in Figure 56) enter **Name** and **Description** of the alarm server.





Figure 56: Create New Alarm Server dialog box.

4. For alarm transitions you may define, which require acknowledgement and at which priority they are reported.
5. You may attach data points for storing alarm counters. These will be linked using the respective property relations (see Section 3.1.12).
6. When you create a generic alarm server, you may add technology alarm servers, that shall be reported to. Click on and choose one alarm server of each technology. If they don't exist, you need to create them under the technology port folders.
7. Click **Create**. The alarm server appears now in the data point list view.
8. For a BACnet technology alarm server, edit the instance number of the Notification Class object to your needs.

#### 4.8.2 Create an Alarm Condition

To generate alarms from data points, intrinsic reporting is used. For each data point an alarm condition must be defined. This condition employs an intrinsic algorithm to generate alarms based on the data point's value or by evaluating a feedback value. Depending on the data point type (analog, binary, multi-state), different conditions are defined. The alarm is reported to the attached alarm server.

### To Create an Intrinsic Alarm Condition

1. Select a data point.
2. Right-click and select **Create Alarm Condition...** from the context menu.
3. For the alarm condition edit the following definitions, which apply to all condition types as shown in Figure 57. Select the **Alarm Server** which the alarm shall be reported to. Typically, you will choose a generic alarm server.
4. Enter an **Alarm Message**. This is shown when the alarm becomes active. You may add variable placeholders to this message by selecting one from the drop-down box **add var** on the right-hand side. A detailed description of available placeholders can be found in Table 3 of Section 3.4.1. Enter a **Clear Message**. This is shown when the alarm clears. For analog alarms, the alarm message is split into a low-limit (LO) message and a high-limit (HI) message, respectively. By clicking  you may attach a data point, which then holds the respective alarm message. This can also be done by editing the property relations 'msgXXX' (see Section 4.2.8). Detach the data point by clicking .
5. Check the option **Enable Fault Alarms**, if fault conditions (offline, unreliable) shall generate fault alarms. If enabled, enter a **Fault Message**, which is displayed along with the fault alarm when it occurs.
6. Optionally, enter a **Time Delay**, for which the condition must persist before the alarm becomes active or is cleared again. The delay is entered in seconds.
7. By clicking  you may attach a data point, which is evaluated for enabling the alarm. This can also be done by editing the property relation 'enableAlarm' (see Section 4.2.8). Detach the data point by clicking .
8. Choose the option **value is different from** to define a feedback alarm. In this case the setpoint value of the alarmed data point is compared against the feedback value. A feedback data point can be attached for this purpose. This can also be done by editing the property relation 'feedbackRelation' (see Section 4.2.8).
9. Choose the option **value has condition** to define a value alarm. In this case the data point value is compared against the condition. Edit the condition in the box below this option.




Figure 57: Common settings for an alarm condition.

10. For an analog feedback condition fill in the alarm condition as shown in Figure 58. A feedback alarm is generated, if the setpoint **differs by** – and **differs by** + value from the feedback value. Enter a **Deadband** to account for hysteresis. Attach or detach data points

for those limits. This can also be done by editing the property relations 'lowLimit', 'highLimit', and 'deadband', respectively (see Section 4.2.8).

Figure 58: Condition for an Analog Feedback Alarm.

11. For an analog value condition fill in the alarm condition as shown in Figure 59. Select **Low Limit** and **High Limit** and put check marks, if they shall be employed. Enter a **Deadband** to account for hysteresis. Attach or detach data points for those limits. This can also be done by editing the property relations 'lowLimit', 'highLimit', and 'deadband', respectively (see Section 4.2.8).

Figure 59: Alarm Condition for an Analog Value Condition.

12. For a binary data point define an alarm value in the alarm condition as shown in Figure 60. Select the **Alarm Value** which triggers the alarm.

Figure 60: Alarm Condition for a Binary Data Point.

13. For a multi-state data point define the alarm values in the alarm condition as shown in Figure 61. Select the states in the list **Not Alarmed** and move them to **Alarm on States** by clicking the arrow buttons.

Figure 61: Alarm Condition for a Multi-State Data Point.

14. Click on **Create**. In the alarm column, the alarm sign 🚨 will be added for those data points that have an alarm condition. If a sub-data point has been alarmed, the top-level data point will indicate this with the sign 🚨.

### 4.8.3 Deliver Alarms via E-mail

Updates in the alarm summary of an alarm object can be used as a trigger to send e-mail. For setting up e-mails, the account information has to be configured on the device, e.g., on the Web UI (see Section “E-Mail” of the LOYTEC Device User Manual [1]). Then an e-mail template can be created and the alarm point attached as a trigger. The e-mail template can be configured to contain certain alarm information in the text or subject field.

#### To Create an E-mail Template for Alarms

1. Create or configure an e-mail template as described in Section 4.6.1.
2. Change to the **Mail Triggers** tab.
3. Click the **Add...** button and select an alarm data point.
4. In the Mail Triggers list select the added trigger data point.

Mail Triggers		
Datapoint	Type	Condition
Critical	Alarm	-

5. In the **Manage Trigger Conditions** list put a check mark on alarm conditions that shall invoke the transmission of the e-mail. See Table 13 below for different combinations of alarm state trigger conditions.

Manage Trigger Conditions	
Enabled Conditions	
<input checked="" type="checkbox"/>	State to Active
<input type="checkbox"/>	State to Ackd-Active
<input type="checkbox"/>	State to Ack-Pending
<input type="checkbox"/>	State to Ackd
<input type="checkbox"/>	State to Inactive
<input checked="" type="checkbox"/>	Offnormal-Alarms
<input checked="" type="checkbox"/>	Lowlimit-Alarms
<input checked="" type="checkbox"/>	Highlimit-Alarms
<input checked="" type="checkbox"/>	Fault-Alarms
<input checked="" type="checkbox"/>	Buffer-Alarms

6. Change to the Common E-Mail Properties tab.
7. Add the alarm data point as a data source as described in Section 4.6.1.
8. Choose the desired alarm information from the fields in the drop-down **Selected Data Source Value** and paste a place holder into the e-mail text or subject field.

Data Sources	
Datapoint	Var.
LINX-120.CEA709 Port.Alarm.Critical	v1
<div> <div>Alarm value</div> <div>to subject</div> <div>Paste</div> </div>	

Action	State to
Alarm	Active
Acknowledge	Ackd-Active + Ackd
Clear	Ack-Pending + Inactive

Table 13: Alarm state triggers


#### 4.8.4 Create an Alarm Log

The alarm objects on the device contain an alarm summary (live list) of currently active and acknowledge-pending alarms. As soon as an alarm becomes inactive and has been acknowledged, it disappears from the alarm summary. To store a historical log of alarm transitions an *alarm log* needs to be created.


An alarm log can log transitions of one or more alarm objects. Its size is configurable. The alarm log can be operated as ring or as linear buffer. When operated as ring buffer, the oldest alarm log records are overwritten by new alarm transitions, as soon as its size limit is reached. When operated as linear buffer no more alarms are logged once the log is full.

##### To Create an Alarm Log

1. Under the Global Objects folder, select the Alarm Log Object Configuration sub-folder.




2. In the data point list right-click and select **New Alarm Log ...** from the context menu.



3. In the **New Alarm Log** dialog enter a **Name** for the alarm log. Optionally enter a **Description**.
4. Enter a **Log Size**, which defines how many transitions are resident in the alarm log.
5. Select the desired **Fill Mode**. The default is **Ring Buffer**, which lets the log overwrite old records once it reaches its capacity. Select **Linear Buffer**, if recording shall be stopped in this case. The user has to purge the log before it continues recording.
6. Define a percentage for **Fill Level Notification**, which can be used to trigger the transmission of E-Mails.




7. Click on the button **Add...** on top of the **Logged Alarm Objects** list.



8. A data point selector dialog opens. Select one or more alarm objects that shall be logged and click **OK**. The alarm objects appear in the list.
9. Click **Create** to create the alarm log object.

## 4.8.5 Multi-Edit Alarm Conditions

For editing a large number of alarm conditions, some multi-edit features are available to assist in this task. On a multi-selection of data points, the user can execute two options from the context menu:

- **Configure Alarm Conditions:** Use this option from the context menu on a multi-selection of data points. The alarm condition of all selected data points can be edited. If all selected data points are of the same class (e.g., all analog data points) the alarm condition can be fully specified. Note that these settings will be applied to all data points. In alarm messages use variable place holders. For assigning different limit and enable data points use the manage relations tab (see Section 4.2.8).
- **Configure Alarm Messages:** Use this option from the context menu for editing alarm messages (alarm, clear, fault) for all data points in the selection. A dialog with a spreadsheet view appears as shown in Figure 62. Edit the messages directly in the spreadsheet. Alternatively, click on the export button  to export the spreadsheet as a CSV file for editing in Excel. Import a CSV file with alarm messages in the menu **Tools** → **Import alarm messages**.

---

*Note:* Use the feature to include data points from sub-folders and filter expressions to expand the ability to perform a multi-select.

---




Figure 62: Spreadsheet for multi-edit of alarm messages.

## 4.9 Local Trending

### 4.9.1 Create a Local Trend

The value of a data point can be logged over time. This is referred to as trend data. To generate trend data a trend object has to be created. The trend data is stored in a data logger file. This file can be downloaded via FTP in binary or CSV format (see the LOYTEC Device User Manual [1]).


Trend objects can generate trend logs for single and multiple data points and can be operated in one of the following modes:

- **Interval Mode:** In this mode a snapshot of all trended data points is logged into the data logger file. Aligned log intervals can be configured.
- **COV Mode:** In this mode, each of the trended data points is logged separately, if and only if its value changes. For analog data points, a specific COV increment can be configured in the data point configuration properties of the trended data point.
- **Trigger Mode:** In this mode a snapshot of all trended data points is logged each time a trigger condition fires. The trigger condition is applied to a trigger data point.

#### To Create a Trend Object

1. Select the **Trend** folder of the device.





2. In the data point list right-click and select **New Trend ...** from the context menu.
3. In the **Create New Trend Object** dialog (shown in Figure 63) enter a name and optionally a description for the trend log object.




Figure 63: Basic Trend Object Configuration.

4. Select the desired **Trend Mode**.
5. On devices with SD cards or USB memory, select **External trend storage**, if this trend log shall be backed up to an SD card or USB memory. If doing so, also set the **Fill Level Notification**, which triggers when a backup is written to the external storage. The storage device can be mounted and enabled on the removable media Web interface of the device.
6. Select the **Log Size**. The display in the dialog will adapt the estimations for needed data logger file size in KB and duration of the trend log. Alternatively, for interval trends, the estimated log duration and log interval can be edited.
7. In the interval trend mode the **Align interval** option can be activated. Depending on the selected interval, the beginning of the interval is aligned to the wall time (e.g. every 15 minutes aligned to the top of the hour). An additional offset in seconds to that alignment can be specified (e.g. 5 seconds after those 15 minutes).
8. Select a **Fill Level Notification** percentage. This will decide at which fill-level trigger will fire. A fill-level trigger can be used to trigger the transmission of an e-mail (see Section 4.9.5) or a backup of log data to the external storage.
9. Click **Save changes** to store the basic configuration of the trend object. The new trend log object appears in the data point list of the Trend folder.

## 4.9.2 Configure Trended Data Points

When a local trend object has been created, it needs to be configured, which data points it shall log. This is done by attaching data points to the trend object. Only simple data points can be attached for trending, i.e., of class analog, binary, or multi-state. Generic trend logs also support string data points. For trend log objects in the BACnet technology, single data points can be attached only.

The trending can be enabled/disabled on behalf of an *enable* data point. This data point should be of type *binary*. If the value of that enable data point is TRUE, the trend object logs data as defined by the trend mode. If the value of the enable is FALSE, trending is disabled. If no enable data point is configured, the trend log is always enabled.


### To Attach Data Points for Trending

1. Select the trend object in the **Trend** sub-folder.

No.	Direction	Trend Name	Use	ID
1	Out	TestTrend	0	1014

2. Right-click and select **Configure Trend** from the context menu. The same dialog which appears when a new trend object is created is shown and allows configuring the trend object. Of course, this step can also be done directly when the object is created.
3. Add data points to be trended. Click on **Add ...** which opens a data point selector window.

Logged Datapoints			Add...	Remove
Datapoint	COV delta	Type		
abs_humid1	0.0	Value		

4. Select the data points and click **OK**. For each of the attached data points, a line appears in the list below the add button. The trended data points will also appear with the trend icon  in the data point manager.

---

**Tip!**

*Data points can also be attached to a trend by selecting a data point in the data point manager, drag it onto a trend object and drop it on the trend object.*

---


5. Data points can be removed from the trend by clicking **Remove**.
6. If COV mode was selected, the COV increment is displayed in the **COV delta** column. This value can be increased to produce less trend data. Note, that it cannot be lowered under the trended data point's own COV increment. Go to the data point configuration to change the COV increment in this case.
7. If the trended value of the data point shall be aggregated over the log interval, select the desired aggregation in the **Type** column. Available options are **Min**, **Max**, **Avg**.


---

**Tip!**

*For creating multiple curves with min, average, and maximum values, add the same data point three times and select the different aggregation types.*

---

8. In addition, a special **Trend Enable** data point can be selected. If configured, the trend log will only log data, if the value of this data point evaluates **true**, i.e., is not zero. Click the  button to select a data point.



9. To remove the enable data point, click the **Remove** button.

10. When done with the data point setup, click **Save Changes** to leave the dialog.

---

**Tip!** *A shortcut to creating a trend log object and attaching a data point is to select a data point in the data point manager, right-click on it and choose **Trend Datapoint** from the context menu. This generates a trend log and links that data point to it.*

---

### 4.9.3 Trend Triggers

Local trend objects in CEA-709 can be operated in *trigger mode*. In this mode, one or more trigger data points cause the generation of a snapshot containing the values of the trended data points at the time instant the trigger is activated. For a trend object, one or more trigger conditions can be defined. Depending on the trigger data point type, the trigger conditions can be refined.

Note, that the behavior of the trigger data point is influenced by the COV properties of the data point. If the **Only notify on COV** property is checked, the data point triggers only if its value changes to the value of the trigger condition. If that property is not checked, the data point triggers on every write with a value that matches the trigger condition.

#### To Configure Trigger Data Points for Trending

1. Select the trend object in the **Trend** sub-folder.



No.	Direction	Trend Name	Use	ID
1	Out	TestTrend	0	1014


2. Right-click and select **Configure Trend** from the context menu.
3. Change to the **Triggers** tab.

---

*Note:* *Of course, you can also change directly to the **Triggers** tab when creating a trend object.*

---

4. Click the **Add...** button. A data point selection dialog opens.
5. Select one or more data points and click **OK**.
6. The triggers appear now in the **Trend Triggers** list.



Datapoint	Type	Condition
state	Value Update	-

7. In the **Manage Trigger Conditions** you can refine the trigger condition depending on the trigger data point class.
8. When done with the data point setup, click **Save Changes** to leave the dialog.

### 4.9.4 Download Trend Data in CSV Format

Trend logs can be downloaded from the device via FTP in CSV format (see LOYTEC Device User Manual [1]). The CSV contents are generated on-the-fly from the internal binary storage when accessing the file. Each trend log point has one CSV file. The files are located in

`/data/trend/TrendLogName_UID.csv`

Where *TrendLogName* is the data point name of the trend (Trend Name). The *UID* is the unique ID of the trend log object. The UID can be obtained from the ID column in the data point list of trend log data points as shown in Figure 64. This would result in the trend CSV file `'/data/trend/out_temp_107C.csv'`.

No.△	Direction	Trend Name	Object Name	Obj Type	Instance	Alloc	Use	ID
1	Out	out_temp	out_temp	Trend Object	26	50	0	107C

Figure 64: UID of data points.

Because the contents are generated on-the-fly, the file size in the FTP client will appear as 0 Bytes. The decimal point and CSV column separator can be configured in the system configuration of the Web UI. Note, that for a comma “,” as the separator, the decimal point is a point. This is useful for English/U.S. applications. For countries that use the comma as the decimal point, select the semicolon as the CSV separator.

#### 4.9.5 Deliver Trend Data via E-mail

Trend logs can be downloaded from the device via FTP. This requires an active action by the user. Alternatively, trend data can be sent as an e-mail attachment. For doing that, an e-mail template has to be setup for the trend log to be transmitted. The fill-level condition in the trend object can be used as a trigger to send an e-mail with the trend’s data logger CSV file as an attachment.

For setting up e-mails, the account information has to be configured on the device, e.g., on the Web UI. Then an e-mail template can be created and the trend object attached as a trigger.

##### To Create an E-mail Template for Trends

1. Create or configure an e-mail template as described in Section 4.6.1.
2. Change to the **Mail Triggers** tab.
3. Click the **Add...** button and select a trend object.
4. In the **Mail Triggers** list, the added trigger data point appears with the **Fill Level** condition.

E-Mail Triggers		
Datapoint	Type	Condition
TestTrend		Fill Level

5. Change to the **Attachments** tab.
6. Select the trend log CSV file of the trend object in the **Attach File** drop-down box and click **Add**.

---

*Note:* ZIP versions of the CSV files are also available. Select those to save transmission bandwidth and mailbox space.

---

Attachments		Attach File	TestTrend_1014.csv	<input type="button" value="Add"/>
Attachment	Device File Path	Add Datetime		<input type="button" value="Remove"/>
TestTrend_1014.csv	/tmp/uid/trend/1014.csv	<input checked="" type="checkbox"/>		

7. Click **OK** to complete the e-mail template configuration.

#### 4.9.6 Technology Trends

In the BACnet technology, trend logs can be exposed on the BACnet port via special BACnet Trend Log objects. To create a technology trend select the port folder (e.g., **BACnet Port**) and then the **Trend** folder underneath. Follow the same instructions as described in Section 4.9.1. Please note, that certain restrictions apply to BACnet trends (see Section 3.7.4).


## 4.10 Remote AST Objects


### 4.10.1 Remote Scheduler and Calendar


Adding remote access to the configuration of a scheduler and calendar, which is located on another device, is done by creating remote scheduler and calendar objects. These objects can be created from data obtained by a network scan. With a CEA-709 device an LNS scan can also be used. Remote scheduler and calendars are supported by CEA-709 and BACnet technologies.

#### To Create a Remote Scheduler

1. Execute a network scan, as described earlier in this document. The scan folder is filled with available schedulers.



2. From the data points in the import folder, select the scheduler objects you are interested in and click the  **Use on Device** speed button. This creates suitable remote schedulers and the corresponding calendar objects in the **Remote Devices** folder.



3. Adjust the basic settings for the newly created objects, such as the object name and description. The object name will be used as the name for the scheduler, as seen on the Web UI.

---

*Note:* Due to the static input NV, which is required for a remote CEA-709 scheduler object, adding remote scheduler points will change the static interface of the device.

---

The new static input NV representing the remote calendar on the local device (this NV is normally called *nviCalLink*) needs to be bound to the output NV called *nvoCalLink* located in the Calendar functional block of the remote device and the new static *nviSchedLink* NVs which were created for each remote scheduler point need to be bound to the respective *nvoSchedLink* variable located in the Scheduler functional block of the remote device. The binding between the *nvoSchedLink* variable on the remote device to the *nviSchedLink* variable on the local device defines which of the scheduler data points on the local device connect to which scheduler unit on the remote device. All required information is transmitted over the link NVs, so it is possible to later change the binding to any other remote scheduler without rescanning the network.

---

*Note:* If connected via LNS, the bindings to the *nvoCalLink* and *nvoSchedLink* NVs are made automatically by the configuration software in the download process.


---


### 4.10.2 Alarm Clients


Accessing alarm server objects on remote devices is done by creating remote alarm data points. These points may be created from data obtained by a network scan. The local device is configured as an alarm client and subscribes to alarm updates from the remote alarm server. The alarm client can also be used to acknowledge alarms on the remote alarm server. Any updates are synchronized back to the alarm client. Remote alarm servers are supported by CEA-709 and BACnet technologies.

### To Create an Alarm Client

1. Execute a network scan, as described earlier in this document. The scan folder is filled with available remote alarm servers.



2. From the points in the import folder, select the alarm server points you are interested in and click the  **Use on Device** speed button. This creates the corresponding alarm client points in your project.



3. In the CEA-709 technology select the new alarm client point and adjust the name of the local NV (default name is *nviAlarm\_2*). This NV is located in the Clients functional block.
4. In the CEA 709 technology a static NV is created to receive information from the remote device about changes to the scheduler configuration, so that the local device does not need to poll the remote device. Set a name for this NV (default is *nviSchedLink<number>*) and assign it to a suitable function block.

---

*Note:* Due to the static input NV which is required for a CEA-709 alarm client point, adding alarm clients will change the static interface of the device.

---

The new static input NVs representing the alarm clients on the local device need to be bound to the alarm outputs of the remote device. A CEA-709 device normally delivers alarms through an output NV of type *SNVT\_alarm\_2* located in the node object of the device, therefore the new input NV on the local device must be bound to the alarm output NV of the remote devices node object. All required information is transmitted over the alarm input NV, so it is possible to later bind the alarm client to any other alarm server without rescanning the network.

---

*Note:* If connected via LNS, the binding to the *nvoAlarm2* NV is made automatically by the configuration software in the download process.


---


### 4.10.3 Remote Trend Logs

A remote trend log provides access to trend log data, which is actually generated and stored on another device. The remote trend log can load trend data from that device and supply it to L-WEB or a CSV file. Please note, that currently only the BACnet technology supports remote trend logs.


#### To Create a Remote Trend Log

1. Execute a network scan, as described earlier in this document. The scan folder is filled with available trend logs.



2. From the data points in the import folder, select the trend log objects you are interested in and click the  **Use on Device** speed button. This creates suitable remote trend logs

in the **Remote Devices** folder.




## 4.11 Math Objects

### 4.11.1 Create a Math Object


Math objects are advanced application objects that can execute mathematical operations on data points. A math object takes a number of input data points (variables  $v_1, v_2, \dots, v_n$ ) and calculates a result value according to a specified formula. When configuring a math object, the input data points, output data points and the formula must be configured by the user. Input data points can be configured with a change-of-value condition, to trigger the math calculation only if the value changes more than a certain delta.

#### To Create a Math Object


1. Under the **Global Objects** folder, select the **Math Object** sub-folder.



2. Right-click and select **New Math Object ...** from the context menu.
3. In the Create New Math Object dialog, enter a name and optionally a description for the math object.



4. Attach input data points by clicking the **Add Input DP** button.




5. In the data point selector dialog, select the input data points and click **OK**. The data points appear as  $v_1, v_2$ , etc.


#### Tip!

A math object can also be created by multi-selecting data points in the data point manager and right-clicking on them. Then choose **Create Math Object ...** from the context menu. This opens the dialog and attaches the selected data points as input variables.

6. If the data point shall trigger the math calculation only after a certain change-of-value, enter a value into the **COV delta** column. If the data point shall never trigger the math calculation, de-select the **Triggers Calculation** check box.
7. Select the input data point and click **Add Variable** to push the variable on the evaluation stack.



8. Select a function to be applied on the variables and click the **Add Function** button.



9. The resulting formula is displayed at the bottom of the dialog. Alternatively, the formula can be entered there.





---

*Note:* When the formula entered at the bottom is still incomplete and does not yield a meaningful command sequence, the list showing the RPN equivalent will be empty. This allows the user to immediately see if the current input is valid or not.

---

10. Add output data points by clicking the **Add Output DP** button.



11. In the data point selector dialog select the output data points and click **OK**.
12. To create the math object click **Create**.

#### 4.11.2 Editing a Math Object


Math objects can be edited once created. The formula can be changed, new variables added, or additional output data points added.

##### To Edit a Math Object

1. Under the **Global Objects** folder, select the **Math Object** sub-folder.



2. Select the math object in the data point list.



3. Right-click and select **Configure Math Object ...** from the context menu.
4. Edit the math object as described in Section 4.11.1.
5. To replace an input data point by another input data point without re-writing the entire formula, click the **Replace Input DP ...** button. This opens a data point selector dialog. Select the replacement data point there.
6. To detach an input data point, click the **Detach Input DP** button. This leaves the respective variable slot empty.
7. To finalize the edit click on **Save Changes**.






## 4.12 Historic Filters

### 4.12.1 Create and Remove Historic Filters


Historic filters are used to work with historic values of a base data point. These historic values are derived by defining historic filter functions. An historic filter template is a collection of such filter functions and can be assigned to any analog, binary, or multi-state base data point. For more general information on historic filters refer to Section 3.4.6.








#### To Create Historic Filters

1. Select one or more data points that shall serve as the base data points.
2. Right-click and select the **Configure Historic Filters ...** item in the context menu. As an alternative, click on  of the **Historic Filter** data point property.
3. The dialog **Select Historic Filter** opens. Click on  to create a new one.
4. In the **Create Historic Filter** dialog enter a name and optionally a description.




The dialog box titled "Create Historic Filter" has two input fields: "Name" with the text "Daily Consumption" and "Description" which is currently empty.

5. To add a new filter function to the list click on the add button . Enter a filter entry **Name** and choose the desired period **Type**. The name will appear with the historic filter relation and helps identifying it. Depending on the type define the arguments **Day** and **Time**. Select how many **samples ago** the filter goes back. The most current sample is '0', the previous one is '1'.

Filter Entries       

No.	Name	Type	Day	Time	samples ago	Delta to current
0	midnight_today	Value at hh:mm:ss of the day	N/A	00:00:00 h	0	<input type="checkbox"/>





6. To duplicate an entry click on the duplicate button . On the duplicate modify the settings accordingly.

No.	Name	Type	Day	Time	samples ago	Delta to current
0	midnight_today	Value at hh:mm:ss of the day	N/A	00:00:00 h	0	<input type="checkbox"/>
1	midnight_yesterday	Value at hh:mm:ss of the day	N/A	00:00:00 h	1	<input type="checkbox"/>

7. For getting the difference of an historic value to the current value check the box **Delta to current**.


No.	Name	Type	Day	Time	samples ago	Delta to current
0	midnight_to_now	Value at hh:mm:ss of the day	N/A	00:00:00 h	0	<input checked="" type="checkbox"/>

8. Click on **Save Changes** and select the created filter template. For each filter entry defined, a historicFilter property relation is created under the base data point(s).

energyCount	1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Value	
historicFilter (midnight_to_now)	1.1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	
historicFilter (midnight_today)	1.2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	
historicFilter (midnight_yesterday)	1.3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	

#### To Remove Historic Filters

1. Select one or more data points with historic filters that shall be removed.

2. On the data point property **Historic Filter of Data Point** click on the remove  button.

### 4.12.2 Managing Historic Filter Resources

Historic filters are stored as template types in the project resources. The Configurator provides a resource manager, that can be used to view, edit, import and export historic filter resources. When modifying an historic filter template, all instances that use it are updated.

Select the menu **Tools → Manage Historic Filters ...** to open the resource manager dialog. Select a filter type and click the edit button  for modifying it. Use the plus button to add new filters and the minus button to delete selected filters. Click the duplicate button  to create a duplicate of the selected filter. Click the import button  to load historic filters from disk. When importing, filter definitions of the same name are overwritten. Click the export button  to store current filters to disk.

---

## 4.13 Automated Data Point Handling

### 4.13.1 Data Point Modification by Export/Import

The Configurator provides a data point export/import interface, which can be used to perform batch edits in an external tool, such as Excel. The data point export feature allows exporting a CSV file of a data point selection (multi-select or by folder selection), which contains a set of data point properties in its columns. The export also allows a flexible selection of exported properties. A matching import will then take the property values from the CSV file and paste them onto the existing data points.

Data points are identified by a key column, which can be the data point's unique ID (UID) or full path (IdPath). If a matching data point is found for a line in the CSV file, the columns are applied to its properties. If none of the key columns are present in an imported CSV file, data points are created using the specified properties. For a batch edit, the key columns have to be left in the CSV file, and only columns should be modified. For a full reference of the CSV file format refer to Section 17.1.

#### To Export a Data Point CSV

1. Select one or more data points, or select one or more folders.
2. Right-click and choose **Export Data Point CSV ...** from the context menu.
3. The Data Point CSV Export dialog opens as shown in Figure 65.






Figure 65: Data point CSV export dialog.

4. Select a pre-defined set of data point properties that shall be exported as columns of the CSV file.
5. If this set does not reflect the desired properties, edit the property set. Select one or more properties in the **Property** list and click on minus to remove them from the list, or click on plus to add more properties.
6. When finished modifying the property set, click on the save button  to store the property set for later use. To open a stored property set, click on the load button . This property set is then available in the drop-down list.
7. Choose an **encoding**, e.g. 'UTF-8'.
8. Select **Write values of child data points** if the exported CSV shall also contain all child data points of structures.
9. Finally click the button **Write CSV** to generate the CSV file. This file is now ready to be edited in an external tool.

### To Modify Data Point Properties from a CSV

1. Select a data point folder.
2. Right-click and choose **Import Data Point CSV ...** from the context menu.
3. Choose a CSV file to be imported. The Configurator opens that file and applies the properties to the existing data points. When finished a report is shown as depicted in Figure 66.




Figure 66: Report on an imported data point CSV.

### 4.13.2 Data Point Creation from CSV

The data point CSV format allows for creating data points from information in the CSV columns. By omitting the identification columns (UID, IdPath) from the data point CSV the create mode is active when importing the data point CSV. Data points are then created relative to the folder on which the import was started. The 'Path' column specifies that relative path and the 'Name' column defines the data point name. For a full specification of the data point CSV format refer to Section 17.1.

To create data points from the CSV, remove the key columns from the exported CSV file or export the CSV without these columns. Then follow the import steps of Section 4.13.1. Data points from a certain #target section are filtered, if the selected source path does not match the specified target technology. When importing from the device folder, all technologies are imported, respectively.

### 4.13.3 Data Point Templates

The Configurator provides an import interface to automatically create a data point configuration from a list of data point templates. This interface can be used by an external tool, which generates such a list from its own project planning data.

Creating data points from data point template works like copy/paste of data points from an existing configuration to a new one. The “copied” data point is just stored in a data point template file (.dptmpl), which can be later “pasted”. For a given set of frequently used data points of a given technology, the user can build a library of such template files.

Data point templates include the following properties of their original data point:

- Generic and technology-specific properties,
- Sub-data points of structures,
- Property relations (without referenced objects),
- Favorites (without referenced objects),
- Alarm conditions (including required alarm servers).

#### To Create a Data Point Template

1. Select an existing data point in the data point list.
2. Right-click and select **Create Data Point Template ...** from the context menu.
3. Enter a file name and store the ‘.dptmpl’ file.

#### To Apply a Data Point Template

1. Select one or more data points in the data point list.
2. Right-click and select **Apply Data Point Template ...** from the context menu.
3. Choose a ‘.dptmpl’ file. This will re-model the data points to the selected template.

### 4.13.4 Creation from Data Point Template CSV

In order to create a batch of data points from those template files, a list can be specified in a data point template CSV file (.dpcsv). For each line in this CSV file a data point will be created under the specified path and name according to a data point template file. Optionally, the description, PLC and OPC settings of the data point template can be overridden by the CSV file. The format of the CSV file is specified in Section 17.1. An example CSV ‘dp\_template.csv’ file can be found in the Configurator install directory under ‘examples\Data Point Templates’.

#### To Create Data Points from a Template CSV File

1. Create a data point template CSV file. An example is shown in Figure 43. The referenced ‘.dptmpl’ files must be located in the same directory as the CSV file. The path to the data point must be specified using the dot ‘.’ as the folder separator.

	A	B	C	D	E	F	G	H	I
1	#Path	Name	Description	PlcIn	PlcOut	Opc	Trend	Schedule	TemplateFile
2	Floor1.Room101	RoomTemp	Temperature in Room 101	1	0	1	1	0	Temp_Reg.dptmpl
3	Floor1.Room101	Setpt	Setpoint in Room 101	1	0	1	1	0	Temp_Reg.dptmpl
4	Floor1.Room101	Window1	Window 1 alarm contact	0	0	1	0	0	Alarm_Reg.dptmpl
5	Floor1.Room101	Window2	Window 2 alarm contact	0	0	1	0	0	Alarm_Reg.dptmpl

Figure 67: Example Data Point Template CSV File.

2. Select the menu **Tools → Import Data Point Template CSV ...** and choose the created CSV file.
3. The temperature registers in the example are specified as trended. If the device model supports different trend technologies, the import will prompt to choose one.
4. The import creates two temperature analog registers and two binary registers with alarm conditions. The data point templates refer to an alarm server, which is also created, if none exists with the same name.

LINX-151 ▶ User Registers ▶ Floor1 ▶ Room101

Datapoint Name	No.	OPC	Param	PLC in	PLC out	Direction	Description
RoomTemp	1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value	Temperature in Room 101
Setpt	2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value	Setpoint in Room 101
Window1	3	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Value	Window 1 alarm contact
Window2	4	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Value	Window 2 alarm contact

## 4.14 Using L-WEB

The L-WEB is a Web-based visualization software that comes free with the device. It uses the standard Web technologies to visualize and control data provided by one or more LOYTEC devices on a Windows PC.

The L-WEB software uses the standardized OPC XML-DA Web service to communicate between L-WEB and remote LOYTEC devices, which makes it extremely firewall-friendly and easy to setup.

The graphical design of the L-WEB user interface consists of pages, which can simply be created by using the L-VIS/L-WEB Configurator software without any know-how in HTML, Java, etc. Dynamic information is shown in the form of numeric values, text, changing icons, bar graphs, trend logs, alarm and event lists, or schedule controls.

The complete set of automation functions of the data server is fully supported by L-WEB. The automation services are residing in the embedded devices and are distributed over the network to build up a dependable system with L-WEB only accessing these services. Furthermore, any kind of calculations, data point connections, etc., are implemented on the embedded Automation Server, which makes the application on the Automation Server completely independent from the connection to the L-WEB application.


Starting from the data point configuration, the user can create an L-WEB project. The L-WEB project contains the data point configuration of the Web service interface and a graphical design for the L-WEB user interface. For more information on creating graphical designs using the L-VIS/L-WEB Configurator software refer to the L-VIS User Manual [6].

### 4.14.1 Create a new L-WEB Project

The Configurator provides the data point configuration, which is downloaded to the device. On top of that configuration, an L-WEB design can be created for visualization.

### To Create an L-WEB Project

1. Start the Configurator software and change to the **L-WEB Projects** tab.



2. The L-WEB project tab appears as in Figure 68.





Figure 68: L-WEB Projects Tab.

3. Click on **Add New ...**
4. Enter a new **Project Name**.



5. Click on **Create**. The new project appears in the projects list.

L-Web Project Name	In LINX Project	On Device	L-Web Project RAM Size (Project)
New Project	No	No	0.00 kB

#### 4.14.2 Start a Graphical L-WEB Design


The L-WEB graphical design tool is started from within the L-WEB projects tab. The graphical design for the L-WEB project is created in the L-VIS design tool (L-VIS/L-WEB Configurator). The data point configuration created in the Configurator project is available for the L-WEB project and its graphical design.

### To Start a Graphical Design

1. Select the **L-WEB Projects** tab.
2. Select an L-WEB project.
3. Click **Edit**.



4. This opens the L-VIS graphical design tool. Complete the graphical design in the tool and click the **Write Project to Device** speed button



5. The graphical design is now part of the project.

L-Web Project Name	In LINX Project	On Device	L-Web Project RAM Size (Project)
New Project	Yes, 28.02.2010 17:01 (5.32 kB)	No	57.17 kB

*Note:*

*If the Configurator had been connected to the device, the graphical design would have been added to the device in the same step.*

### 4.14.3 Organize L-WEB Projects

L-WEB projects can be organized within the L-INX configuration project. L-WEB projects can be part of the configuration project and/or stored on the device. For instance, the configuration project may contain a number of L-WEB projects, but for saving space on the device, only one of them is downloaded on the device. The **L-WEB projects** tab provides a number of tools to organize a set of L-WEB projects.

#### To Organize L-WEB Projects

1. Connect to the device as described in Section 4.4.1.
2. Select the **L-WEB Projects** tab.
3. Click **Detect Projects on Device**. This scans for all projects found on the device.

L-Web Project Name	In LINX Project	On Device	L-Web Project RAM Size (Project)
New Project	Yes, 28.02.2010 17:01 (5.32 kB)	No	57.17 kB
Second Project	Yes, 28.02.2010 17:03 (5.31 kB)	Yes, 28.02.2010 16:03 (5.31 kB)	57.18 kB

Projects marked as a green **Yes** in the **In LINX Project** column are L-WEB projects, which are part of the current L-INX configuration project. Projects marked as a green **Yes** in the **On Device** column are L-WEB projects, which are also stored on the device. A red **No** identifies the L-WEB project to be missing in the project or on the device, respectively.

4. If you want to download an L-WEB project to the device, which is missing there, select the project and click **Download**. After the download the project appears with a green **Yes** in **On Device**.

L-Web Project Name	In LINX Project	On Device	L-Web Project RAM Size (Project)
New Project	Yes, 28.02.2010 17:06 (5.32 kB)	Yes, 28.02.2010 16:06 (5.32 kB)	57.17 kB
Second Project	Yes, 28.02.2010 17:07 (5.31 kB)	Yes, 28.02.2010 16:07 (5.31 kB)	57.18 kB

- If you want to remove a project from the device, click **Remove** in the **LINX Device box**.

L-Web Project Name	In LINX Project	On Device	L-Web Project RAM Size (Project)
New Project	Yes, 28.02.2010 17:06 (5.32 kB)	Yes, 28.02.2010 16:06 (5.32 kB)	57.17 kB
Second Project	Yes, 28.02.2010 17:03 (5.31 kB)	No	57.18 kB

- If you want to remove the project from the current L-INX project file, click **Remove** in the **L-WEB Projects on PC box**.

L-Web Project Name	In LINX Project	On Device	L-Web Project RAM Size (Project)
New Project	Yes, 28.02.2010 17:06 (5.32 kB)	Yes, 28.02.2010 16:06 (5.32 kB)	57.17 kB
Second Project	No	No	0.00 kB

- If you want to export the L-WEB project into a separate L-WEB project file, click **Export...** and select a file name in the file requestor dialog.
- If you want to import an L-WEB project from a separate L-WEB project file, click **Import...** and select the file in the file requestor dialog. The L-WEB project appears in the project but not on the device.

## 4.15 I/Os

The L-IOB and LROC-40x models are equipped with local Inputs and Outputs to directly connect to sensors and actuators. Additionally, a LIOB-48x/58x device can be extended with the I/Os of one LIOB-45x/55x device. The following sections describe how to configure these I/Os.

### 4.15.1 Add L-IOB Modules

L-IOB modules are added to the L-IOB host configuration in the Configurator. This configuration determines, which L-IOB modules are connected to the L-IOB host in which I/O configuration.

#### To Add a L-IOB Module

- In the Configurator change to the **L-IOB** tab.





Figure 69: L-IOB tab in the Configurator

- In the LIOB Configuration tree on the left, select the **LIOB** (LIOB-Connect), **LIOB-FT**, or **LIOB-IP** bus.
- Click the **Add Device(s)** button .
- In the file requestor, select a LIOB device template for your L-IOB model, e.g., liob100.xml. The L-IOB device appears in the **LIOB Devices** list.

LIOB Devices							
Station	Product Code	Device name	Daisy Chain	Minimum firmware vers...	Enabled	PIN	NID
1	LI0B-100	LI0B-100	<input checked="" type="checkbox"/>	2.2	<input checked="" type="checkbox"/>		00:00:00:00:00:00



- Optionally, double-click on the **Device name** and enter a descriptive device name, e.g. 'MyLIOB'.





Station	Product Code	Device name
1	LIOB-100	MyLIOB

- To add more L-IOB devices repeat the add device step. Use the **Up** and **Down** button to organize the L-IOB devices in the order as they are connected to the L-IOB host. Station 1 is the first L-IOB, station 2 the second, and so on.
- Observe that the **Device parameters** table (below the LIOB device table) lists all device configuration properties and also life values that can be exposed as L-IOB data points. These L-IOB data points in turn can be exposed as OPC data points as well as input and/or output data points in the logic program. By default, no device data points are created. Using the checkboxes in the **DP Create** column of the **Device parameters** table, device configuration properties and life values can be exposed as L-IOB data points. Using the checkboxes in the **OPC**, **PLC In**, and **PLC Out** columns, it is possible to select which of the created data points shall be exposed as OPC data points, logic program input data points, and logic program output data points.

Device Parameters

Nr.	DP Create	OPC	PLC In	PLC Out	Parameter value	Parameter name	Description
0	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	LIOB-100	ProductCode	Product code of L-IOB device
1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	LIOB-100	DeviceName	Device name
2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	0000000000000000	NID	Node ID
3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	1	StationID	Station ID for device enumeration
4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		PinCode	PLN code (empty or 0 to disable)
5	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		FMWVersion	Firmware version
6	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		FMWTimestamp	Firmware timestamp
7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		Serial	Serial number
8	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>		Enabled	Enabled flag

### To Duplicate/Remove L-IOB Modules

- In the **LIOB Devices** list, select a configured L-IOB device or use multi-select to select multiple devices at a time.
- Click on the **Duplicate Device(s)** button . This duplicates the selected L-IOB devices and all I/O configurations.
- Unneeded devices may be deleted again by clicking the **Delete Device(s)** button .
- To export a new template for a L-IOB configuration click the **Export device template** button . No multi-select is possible for this operation. In the file save dialog, enter a new L-IOB template file name and store it. This file can then be used in a different project using the **Add Device(s)** button .



### 4.15.2 L-IOB Device Settings

The LIOB-15x/45x model is chosen either automatically after connecting to the L-IOB device or manually after starting the Configurator in the menu **Model**. The Configurator will show the **L-IOB Device** tab as depicted in Figure 70. In the **Device Parameters** table, the device specific configuration properties can be set.

L-IOB Device			
L-IOB I/Os			
Device Parameters			
Nr	Parameter name	Parameter value	Description
0	ProductCode	LI0B-150	Product code of L-IOB device
1	DeviceName	LI0B-OG3	Device name
2	PinCode		PIN code (empty or 0 to disable)
3	AlternativeUnit	<input type="checkbox"/>	SI/US unit setting
4	Language	English	Language setting for LCD display
5	GroupInMinSendTime	0	Minimum wait time between updates of digital group input NV (rate limitation)
6	GroupInMaxSendTime	0	Maximum time between updates of digital group input NV (heart beat)
7	GroupOutFBMinSendTime	0	Minimum wait time between updates of digital group output feedback NV (rate limitation)
8	GroupOutFBMaxSendTime	0	Maximum time between updates of digital group output feedback NV (heart beat)

Figure 70: LIOB Device Tab

### 4.15.3 Configure I/Os

At first the I/Os have a default configuration. To adapt the I/Os to the specific needs in a project they can be freely configured. Note that certain changes to the I/O configuration must be committed before proceeding with other tasks. This can be done explicitly by clicking **Commit member changes** . Otherwise, the user will be requested to commit by the Configurator. Changes can be canceled by clicking **Cancel member changes** .

#### To Configure I/Os

1. Select a L-IOB device in the LIOB Configuration tree.
2. The **L-IOB** tab displays the I/Os available on the device in the **Inputs / Outputs** list.

Inputs / Outputs					
Nr	TerminalNr	Terminal	Name	Hardware type	DP count
1	1	UI1	UI1	IN Analog/Digital 10V	22
2	2	GND12	GND UI1-UI2	IN Analog/Digital 10V	
3	3	UI2	UI2	IN Analog/Digital 10V	22
4	4	UI3	UI3	IN Analog/Digital 10V	22

3. To adapt the I/O name, double-click the name in the **Name** column and edit it, e.g., 'RoomTemp'.

Nr	TerminalNr	Terminal	Name	Hardware type
1	1	UI1	RoomTemp	IN Analog/Digital

4. Select (or multi-select) an I/O in the **Inputs/Outputs** list and observe the **Object parameters** list below. These parameters can be used to configure the I/O.




Object parameters									
Nr	DP Create	OPC	PLC In	PLC Out	Parameter name	Parameter value	Unit	Range	Description
0	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Name	RoomTemp			Terminal name
1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	HardwareType	IN Analog/Digital			Terminal type
2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	SignalType	Voltage 0-10V			Type of the input/output signal

5. For example, change the **SignalType** of the input UI1 to 'Resistance'.
6. Note that the object configuration properties may change when changing the signal type or interpretation. For detailed information on available configuration properties and their dependencies refer to Section 3.5. In this example you may now edit the **Interpretation** to 'NTC10K', which will allow connecting an NTC temperature sensor to the input.

SignalType	Resistance
Interpretation	NTC10K

7. Observe that the **Object parameters** table lists all I/O configuration properties and also life values that can be exposed as L-IOB data points. These L-IOB data points in turn can be exposed as OPC data points (LIOB-48x/58x) as well as input and/or output data points in the logic program. Only the basic data points of each I/O (input, output, feedback) are created by default. Using the checkboxes in the **DP Create** column of the **Objects parameters** table, additional configuration properties and life values can be exposed as L-IOB data points. Using the checkboxes in the **OPC**, **PLC In**, and **PLC**








**Out** columns, it is possible to select which of the created data points shall be exposed as OPC data points, logic program input data points, and logic program output data points.


8. Analog inputs can be configured to be interpreted as digital by setting the check box **Digital Input**. When using this option, configure the parameters **OnValue** and **OffValue**. These define a hysteresis when tracking the analog value: If the digital value is off, the analog value needs to go over **OnValue** to turn it on. If the digital value is on, the analog value needs to drop below **OffValue** to turn it off.
9. For LIOB-58x devices, native BACnet objects (see Section 3.7.7) can be created using the **BACnet Object** checkbox. For inputs with interpretation “Pulse Count”, it is possible to choose between the **BACnet Object Type** “Analog Input” and “Accumulator”. The corresponding data points will appear in the **LIOB-58X / BACnet Port / Datapoints** folder of the **Datapoints** tab. The BACnet server object names and descriptions will initially receive unique I/O names as described in Section 3.7.7. They can be set to the current I/O names and descriptions by using the button **Set BACnet Names** .
10. I/Os of the same hardware type can be copied using the **Copy selected object**  and **Paste to selected object(s)**  buttons.

#### 4.15.4 Manage I/O Configurations

I/O configurations can be managed by the user. E.g. a new template may be generated from the I/O configuration, which can be re-used in other projects.

##### To Manage I/O Configurations

1. Select the **L-IOB** tab.
2. To export a new template for a L-IOB configuration click the **Export device template** button . In the file save dialog, enter a new L-IOB template file name and store it. This file can then be used in a different project using the **Import Template** button .
3. Existing configurations can be updated with new L-IOB templates by using the **Upgrade Template** button . This can be used e.g. to migrate new functions which were not yet available in earlier template versions. It is highly recommended to backup the original project before upgrading templates. After upgrading the template, a log is displayed, which shows all information about the upgrade process. Please carefully review this log before using the updated configuration.
4. Another way of managing I/O configurations is using terminal configurations. A terminal configuration can be created from an I/O object in the **Inputs / Outputs** list by using the **Export object to disc** button  next to the list. In this case, only the configuration of this I/O is stored in an XML file. Terminal configurations can be imported (to one or multiple I/Os of the same hardware type) by using the **Import object from disc** button .
5. These terminal configurations can also be used to configure all I/Os of the L-IOB device using a CSV file (see Section 17.3). The CSV file can finally be imported using the **Import terminal configuration** button .
6. It is also possible to export such a terminal configuration from an existing project using the **Export terminal configuration** button . After choosing a file location and name, the user will be asked if only customized objects shall be exported. If this option is enabled, only L-IOB devices with custom I/Os (where changes have been made) will be exported.

7. To setup translation tables for certain I/O interpretation modes, click the **Edit translation tables** button .




Figure 71: L-IOB Translation Tables

8. You can add and delete tables using the buttons **Add table** and **Delete table**. The data types for the **xin** and **xout** columns of the table can be setup in **Type In** and **Type Out**. In the **Translation table entries** list, you can enter the **xin** and **xout** values. The translation is done (with linear interpolation) from measured **xin** values to **yout** values which are used for the L-IOB data points. Further, the table values can be exported and imported (CSV files) with **Import Values** and **Export Values**. Entire tables (including table name and type) can be exported and imported with **Import Table** and **Export Table**. Tables of some standard temperature sensors are installed with the Configurator in the subfolder “LIOB\tables”.

#### 4.15.5 Using I/O Data Points

The I/Os are exposed to data points on the device. These data points comprise the present value of the I/O as well as status and configuration data. The corresponding folders in the data point manager tab of the Configurator are named **Local IO** and **LIOB-IP**, see Figure 72.




Figure 72: IO folder in the data point manager

Under this folder there exist sub-folders for each I/O on the controller. When selecting any of the folders, the data point list shows all data points in the scope of that folder. The data points on the **Local IO** / **LIOB-IP** folders provide general I/O data. The data points of the



2. Enable the native BACnet object.
3. Go to the BACnet object on the data points tab in the according LIOB folder of the BACnet port.

LINX-153 ▶ BACnet Port ▶ Datapoints ▶ LIOB ▶ LIOB-100\_1

Datapoint Name	Path	No.	OPC
▶ L1_1_DI1	BACnet Port.Datapoints.LIO...	1	<input type="checkbox"/>

4. In the context menu select **Add/Remove BACnet Properties...** and set the check box in the **Read** column of the Elapsed\_Active\_Time property. If required expose the created data point to OPC.

Datapoint Name	Path	No.	OPC
▶ L1_1_DI1	BACnet Port.Datapoints.LIO...	1	<input type="checkbox"/>
▶ Elapsed_Active_Time	BACnet Port.Datapoints.LIO...	1.1	<input checked="" type="checkbox"/>

# 5 CEA-709

## 5.1 Project Settings

### 5.1.1 CEA-709 Settings

The CEA-709 configuration tab as shown in Figure 74 allows configuring properties of the device's CEA-709 port. The options in the **Data Point Settings** section are:

- **Default Polycle for External NVs:** When using external NVs, this poll cycle is set as a default for input data points. The poll cycle can be edited individually in the properties view of the data point manager.
- **Use state-member of SNVT\_switch as:** This setting defines how the state member of the SNVT\_switch shall be mapped to a data point. Depending on how the data point shall be used, it can be binary or multi-state. The multi-state setting allows setting the UNSET state explicitly. As a binary point the UNSET state is implicitly chosen, if the value is invalid.
- **Omit unused child data points of UNVT/UCPT structures:** This setting defines, that if set, also unsued sub-data points of user-defined structure types are not downloaded onto the device. This option can reduce the total amount of data points in the configuration. As a default it is not enabled to allow full structure information after an upload to the PC even if the user does not have the original resource files installed.
- **Prefer floating point SNVTs when auto-generating:** If enabled, this setting defines, that auto-generated static NVs prefer flaoting point SNVTs over fixed-point types, e.g. a SNVT\_temp\_f will be generated instead of a SNVT\_temp.
- **Default Binding Template:** When automatically creating bindings, this LNS binding template will be used. It can be changed, if the default does not satisfy the project requirements (e.g., if unacknowledged repeated service shall be used).




Figure 74: CEA-709 Project Settings – Data Point Settings.

Figure 75 shows the settings of the NV Interface section:

- **Max NV count:** On models that support it, the maximum number of NVs in the static interface can be increased from the default number. Note that doing so changes the static interface of the device (see Section 3.6.3).
- **Unique NV names:** In the default setting the programmatic names of static NVs must be unique on the interface. When removing this check box, this restriction is relaxed to

be unique per function block. Note, that once disabling this option, it cannot be enabled anymore.

- **Enable Legacy Network Management Mode:** This group box contains check boxes for each CEA-709 port of the device. Put a check mark on the port, if this port shall be operated in the legacy network management mode. In that mode, the port does not use the extended command set (ECS) of network management commands. This can be necessary to operate the device with some network management tools that do not support the ECS.




Figure 75: CEA-709 Project Settings – NV Interface

- **Configure Domain:** This section box contains self-configuration settings for the CEA-709 ports, one for each channel. This is necessary if the device shall be used without being commissioned by a network management tool. Set the check mark and enter the CEA-709 domain and subnet/node information. If operated in self-configured mode, the CEA-709 network can be scanned using the network scan (see Section 5.3.4) and external NVs can be used on the device. Note, that the domain must match the nodes' domain on the network and the subnet/node address must not be used by another device.




Figure 76: CEA-709 Project Settings – Configure Domain

### 5.1.2 CEA-709 Settings for L-DALI Models

The CEA-709 configuration tab as shown in Figure 77 allows configuring properties of the device's CEA-709 port. The **NV Interface** section allows changing the static LONMARK interface of the CEA-709 nodes. On the one hand parts of the interface, which are not required for a specific project (e.g. Constant Light Controller, Sunblind Controller, etc.) can be disabled. On the other hand additional functionality can be enabled (e.g. for emergency light applications, DALI buttons support or User NVs). When enabling Button objects a template for the LONMARK Button objects created can be selected in the drop down box below. For more information on the LONMARK interface see the L-DALI User Manual [3].

#### **Important!**

*Downloading the data point configuration after changing the interface, will result in a new static interface! Thus, it is highly recommended to change this option only if connected via LNS to allow the Configurator to update the LNS database accordingly!*

If using a non-standard interface a XIF-File must be created to be able to add the device in a network management tool (e.g. LonMaker) in case of an offline workflow (see Section 5.3.11).






Figure 77: CEA-709 Project Settings for L-DALI models.

The **Constant Light Controller** section (see Figure 78) allows enabling and disabling the automatic bindings feature for each channel. See the L-DALI User Manual [3] for details on the automatic internal binding algorithm.




Figure 78: CEA-709 Project Settings– Constant Light Controllers.

### 5.1.3 AST Settings

For CEA-709 devices, the use of alarming, scheduling, and trending (AST) features requires additional resources (functional objects and NVs). This changes the static interface. Since the number of used resources also influences the performance, the AST section on the CEA-709 tab allows configuring those resources for the project. In this tab, the required number of scheduler units that may be instantiated and their capacity may be configured (how many time/value entries, value templates, bytes per value template, etc.). It contains the following options and settings, which are relevant to calendar and scheduler functionality of the device:

- **Enable Calendar Object:** This checkbox enables a LONMARK compliant calendar object on the device. It is automatically enabled together with local schedulers, since the two are always used together.
- **Enable Scheduler Objects:** This checkbox enables local LONMARK compliant scheduler objects on the device. Checking this box will automatically enable the calendar as well.
- **Enable Remote AST Objects:** This checkbox enables the functional object for NVs, which are used to access remote AST objects. If this box is checked, the *Clients* functional block is included in the static interface.
- **Enable AST v2:** This checkbox enables the AST interface version 2 for local CEA-709 schedulers on the device. This interface is not compatible with older devices. The new interface provides access to the value label descriptions in schedule presets for remote schedulers.
- **Number of calendar patterns:** Specifies the maximum number of different exception schedules (day classes like holiday, maintenance day) supported by this calendar object.

- **Total number of date entries:** Specifies the maximum number of date definitions which may be stored by the calendar. This is the sum of all date definitions from all calendar entries. A date definition is for example a single date, a date range, or a week and day pattern.
- **Number of local schedulers:** This is the number of local scheduler objects which should be available on the device. Each local scheduler data point created in the data point manager will connect to one of these scheduler objects. There may be more scheduler objects available on the device than are actually used at a certain time. It is a good idea to have some spare scheduler objects ready, in case another scheduler is needed.
- **Number of daily schedules:** This is the maximum number of schedules supported by each scheduler object. This number must at least be 7, since a scheduler always needs to provide one schedule for each day of the week (default weekly schedule). For each special day defined by the calendar or embedded exception day, an additional daily schedule is required to support it.
- **Entries in Time/Value table:** This is the total number of entries in each scheduler defining a value template that should apply on a specific day starting at a specific time (the time table).
- **Number of value templates:** This is the maximum number of value templates supported by each scheduler.
- **Data size per value template:** This specifies the buffer size reserved to hold the data for each value template. More data points or bigger data structures require a bigger value buffer.
- **Max. number of data point maps:** Specifies the maximum number of individual data points that this scheduler is able to control.
- **AST Configuration Size:** This number in Bytes is calculated from the scheduler settings above and represents the total size of the LONMARK configuration properties file stored on the device. While certain settings can be freely edited within the given limits, the resulting configuration size is also limited.

The screenshot shows the 'AST' configuration window for a CEA709 project. The left sidebar has 'AST' selected, with 'Configure Domain' and 'Channel 1' visible. The main area is divided into two columns. The left column, titled 'Resources required by the current project', lists various parameters and their current values: Alarm server (Yes), Local calendar (Yes), Calendar patterns (0), Total date entries (0), Local schedulers (0), Daily schedules (0), Time/Value entries (0), Value templates (0), Total value size (0 bytes), Datapoint maps (0), and Remote AST Objects (No). Below this list are 'Auto-Set' and 'Set Defaults' buttons. The right column contains several checkboxes for enabling features: 'Enable Calendar Object', 'Enable Scheduler Objects', 'Enable Remote AST Objects', 'Enable AST v2', and 'Enable Alarm Server'. Below these are two sections: 'Calendar Configuration' with 'Number of calendar patterns' (5, max 25) and 'Total number of date entries' (100, max 500); and 'Scheduler Configuration' with 'Number of local schedulers' (10, max 100), 'Number of daily schedules' (62, max 256), 'Entries in Time/Value table' (128, max 500), 'Number of value templates' (8, max 500), 'Data size per value template' (8, max 32), 'Max. number of data point maps' (16, max 64), and a final line showing 'AST Configuration Size: 33610 Byte (max. 393216 Byte)'.

Figure 79: CEA-709 AST Project Settings.

As can be seen from the above list, it is not easy to configure a LONMARK scheduler object. There are many technical parameters which need to be set and which require some knowledge

of how these scheduler objects work internally. Therefore, the configuration software provides the following mechanisms to help in choosing the right settings:

- **Resources required by the current project:** The absolute minimum settings required by the current project are shown in a table at the left side of the window. This data may be used to fill in the values at the right side, but some additional resources should be planned to allow for configuration changes which need more resources.
- **Auto-Set:** This button may be used to let the configuration software decide on the best settings to use, based on the current project. Since the current projects resource usage is taken as a starting point, all schedulers and calendar patterns in the project should first be configured before this button is used.
- **Set Defaults:** This button will choose standard values for all settings. In most cases, these settings will provide more resources than necessary.

---

*Note:* On some models the CEA-709 AST resources are fixed and cannot be configured (e.g. L-DALI models).

---

## 5.2 CEA-709 Workflow

### 5.2.1 Replace a Device

A device can be replaced in the network by another unit. This might be necessary if a hardware defect occurs. First of all, the replacement device needs to be configured with the appropriate IP settings. The remainder of this section focuses on restoring the device configuration from a backup file. The work flow is depicted in Figure 80.




Figure 80: Basic work flow to configure a replacement device.

Start the Configurator software stand-alone and connect via the FTP method (see Section 4.4.1). Then restore the device configuration from the backup file, which has been created when the original device has been configured or modified (see Section 4.4.6). After the restore all data points, dynamic NVs and bindings, BACnet server objects and client mappings are restored. The device is again configured online and fully functional in the network.

If using an LNS-based tool, the device needs to be replaced in that tool at some later point in time (see Section 5.2.3) as the NID has changed. If you are not using LNS, then refer to your network management tool's reference manual on how to replace a device.

### 5.2.2 Adding the Device to LNS

To configure a device in your LonMaker drawing, the device needs to be added to the LNS database and commissioned. This Section refers to LonMaker TE and describes how to add a device to your database. The example discusses a LINX-10X but it is general to all CEA-709 L-INX and L-GATE models

### To Add a Device to LonMaker TE

1. In your LonMaker drawing, drag a device stencil into the drawing. Enter an appropriate name as shown in Figure 81.




Figure 81: Create a new device in the drawing.

2. Select **Commission Device** if the LINX-10X is already connected to the network.
3. In the **Device Template** group box select a matching device template. For example select “LINX-xxx\_FT-10”, if a L-INX is configured to use the FT-10 interface, or “LINX-xxx\_IP-10L”, if a L-INX is configured to be on the IP channel. For information on how to configure which port to use, refer to the Section “Port Configuration” of the LOYTEC Device User Manual [1]. Note that for the LINX-15x the LINX-12x XIF has to be used.
4. Select the channel, which the device is connected to and click **Next**.
5. The following dialog shown in Figure 82 appears, click **Next**.




Figure 82: Leave defaults for Location.

6. Check Service Pin as the device identification method as shown in Figure 83 and click **Next**.




Figure 83: Use Service Pin.

7. Click **Next** in the following screens until you get to the final dialog shown in Figure 84.
8. If the device is already on-net, select **Online**.





Figure 84: Final dialog.

9. Click **Finish**. A dialog will prompt to press the service pin.



10. Finally, you should get the device added to your drawing as depicted in Figure 85.




Figure 85: The L-INX has been added to the drawing.

### 5.2.3 Replace a Device in LNS

This Section describes how to replace a device in your LNS database. The example discusses a LINX-10X but is general to all LOYTEC CEA-709 device models. The description refers to LonMaker TE. Let's assume there is a device 'linx' in the LNS database as shown in Figure 86.




Figure 86: LonMaker drawing with one L-INX.

### To Replace a Device in LonMaker TE

1. Select the device and right-click on the device shape.
2. Select **Commissioning** → **Replace....** This opens the LonMaker Replace Device Wizard as shown in Figure 87.




Figure 87: LonMaker replace device wizard.

3. Choose the existing device template and click **Next**.
4. In the following window shown in Figure 88 click **Next**.




Figure 88: Click Next without loading an application image.

5. Then select **Online** as shown in Figure 89 and click **Next**.




Figure 89: Select online state.

6. Select the **Service pin** method and click on **Finish** as shown in Figure 90.






Figure 90: Select Service Pin and click Finish.

7. Then the service pin requestor opens as shown in Figure 91. Press the service pin on the replacement device on the correct port. You can also send the service pin from the device information page on the Web interface.




Figure 91: Wait for the service pin from the device.

8. After the service pin has been received, LonMaker commissions the replacement device, creates the dynamic NVs again (if any), and installs the bindings.

## 5.2.4 Workflows for CEA-709

This section discusses a number of work flows for configuring a CEA-709 device model in different use cases in addition to the simple use case in the quick-start scenario (see Chapter 0). The description is intended to be high-level and is depicted in flow diagrams. The individual steps refer to later sections, which describe each step in more detail. In principle, the LINX Configurator supports the following use cases:

- Network Management Tool based on LNS 3.x (see Section 5.2.4.2)
- Non-LNS 3.x network management tool with polling (see Section 5.2.4.3)
- Non-LNS 3.x network management tool with bindings (see Section 5.2.4.4)

### 5.2.4.1 Involved Configuration Files

In the configuration process, there are a number of files involved:

- XIF file: This is the standard file format to exchange the static interface of a device. This file can be used to create a device in the database without having the device on-line. There exists a standard XIF file for the FT port (e.g., LINX-10x\_FT-10.xif) and one for

the IP-852 port (e.g., LINX-10x\_IP-10L.xif). For the LINX-15x model use the LINX-12x XIF files.

- LINX Configurator project file: This file contains all ports, data points, and connections of a project. These files end with “.linx”, “.liob”, “.ldali”, or “.gtw”. It stores all relevant configuration data and is intended to be saved on a PC to backup the device’s data point configuration.

#### 5.2.4.2 Configure with LNS

The flow diagram in Figure 92 shows the steps that need to be followed in order to configure a CEA-709 device in a network with LNS 3.x. In this scenario, the device will use dynamic NVs and bindings.

First, the device must be added to LNS (see Section 5.2.2). Then the LINX Configurator must be started in plug-in mode to configure the device (see Section 5.3.1). In the Configurator, scan for the data points in the LNS database (see Section 5.3.2). Select the data points that the device shall expose (see Section 5.3.5). Finally, the configuration needs to be downloaded to the device via LNS (see Section 5.3.9). It is recommended to backup the device configuration to a file for being able to replace the device in the network (see Section 4.4.6).




Figure 92: Basic design-flow with LNS.

To add more NVs when all bindings are in place and the device is already being used, simply repeat the steps described above. The Configurator software will back up the bindings, create or delete the dynamic NVs, and re-create the bindings again.

#### 5.2.4.3 Configure without LNS

The flow diagram in Figure 93 shows the steps that need to be followed in order to configure the device without LNS 3.x. In this scenario the device will use external NVs and polling. The advantage of this solution is that no bindings in the non-LNS tool (or self-binding nodes) need to be changed. This comes at the cost of a constant network load caused by polling.

Start the Configurator in stand-alone mode and connect to the device via the FTP method (see Section 4.4.1). If changing an existing configuration, upload the current configuration from the device (see Section 4.4.2). In the Configurator, import data points from a CSV import file (see Section 5.3.3) or from an XIF file (see Section 5.4.1). If the other devices are already connected to the network you may also scan them online (see Section 5.3.4). Select the data points that the device shall expose (see Section 5.3.5). Alternatively, you can create

external NVs manually (see Section 5.3.8). Finally, the configuration needs to be downloaded to the device (see Section 4.4.4). It is recommended to backup the device configuration to a file for being able to replace the device in the network (see Section 4.4.6).




Figure 93: Basic design-flow without LNS.

#### 5.2.4.4 Configure without LNS Using Bindings

The flow diagram in Figure 94 shows the steps that need to be followed in order to configure the device without LNS 3.x. In this scenario the device will use static NVs and bindings. The advantage of this solution is that the network load is minimized. However, the non-LNS management tool must create bindings for the device and update an existing network.

Start the Configurator in stand-alone mode and connect to the device via the FTP method (see Section 4.4.1). In the Configurator import data points from a CSV import file (see Section 5.3.3) or from an XIF file (see Section 5.4.1). If the other devices are already connected to the network you may also scan them (see Section 5.3.4). Select the data points that the device shall expose (see Section 5.3.5). For the NVs used on the device select the “static NV” allocation type (see Section 5.3.6). Alternatively, you can create static NVs manually (see Section 5.3.7).

For network management tools, which do not support the ECS (enhanced command set) network management commands, the legacy network management mode must be configured (see Section 5.3.10). Please contact the tool’s vendor for information whether ECS is supported or not.

Download the configuration onto the device (see Section 4.4.4). Finally, export a XIF file (see Section 5.3.11). It is recommended to backup the device configuration to a file for being able to replace the device in the network (see Section 4.4.6).




Figure 94: Basic design-flow without LNS using bindings.

To use the device in the non-LNS management tool, commission the device using the exported XIF file and create the bindings.

When changing a running device configuration with existing bindings, it is recommended to create additional data points as external NVs with polling as described in Section 5.2.4.3. Otherwise, depending on the third-party tool, a new XIF file may be required to be exported for replacing the device in the non-LNS tool. In this case the user would need to create all bindings again from scratch (see Section 3.6.3).

## 5.3 CEA-709 Configuration

### 5.3.1 Starting as an LNS Plug-In

In LonMaker the plug-in is started by right-clicking on the LOYTEC device shape or the Gateway/PLC functional block and selecting **Configure...** from the pop-up window.

In NL220, the Plug-in is started by right clicking on the device node, then selecting the Option **LOYTEC LINX Configurator** in the **PlugIns** sub menu.

In Alex, the Plug-in is started by right clicking on the device and selecting the **LOYTEC LINX Configurator** in the **Starte PlugIn** sub menu.

A window similar to what is shown in Figure 95 should appear.




Figure 95: LINX Configurator main window.


*Note:*

*It is recommended to start the LINX Configurator as LNS-Plug-In, whenever using a LDALI-10X with an LNS based network management tool (LonMaker, NL220, etc.)! This allows the Plug-In to keep the device configuration in-sync with the LNS database.*

### 5.3.2 Scanning for Network Variables

When the LINX Configurator is connected to an LNS database, network variables can be scanned from that data base.

#### To scan network variables from the LNS database

1. Click on the **Datapoints** tab of the main window.
2. Click on the button  **Scan channel**. This scans in all NVs on all devices connected to the CEA-709 channel of the device.
3. After the scan has completed, the folder **LNS Database Scan** is populated with the found NVs. Data point names for those NVs are automatically generated, following the data point naming rules defined in the project settings (see Section 4.3.2). By default the name is generated from node name, object name, and NV name. These names are ensured to be unique by adding a counter for multiple occurrences of the same name.




Figure 96: Scanned NVs in the LNS Database Scan Folder.

Figure 96 shows an example result of the database scan. The list can be sorted by each column. Selecting a line will display a number of associated properties in the property view below. Multiple items can be selected by using the <Ctrl> key and clicking with the mouse. All items can be selected by pressing <Ctrl-A>.

### 5.3.3 Importing Network Variables

Without LNS, the tool cannot connect to an LNS database, where it scans for network variables (NVs). Therefore, the list of NVs to be used on the device has to be available in a CSV file. This file can be produced by external software or created by hand. The CSV format for importing NVs is defined in Section 17.2.

#### To Import NVs from a File

1. Click on the **Datapoints** tab of the main window.
2. Select the import folder **CEA709 CSV File**.



3. Right-click and select **Import File**. In the following file selector dialog, choose the CSV import file and click **OK**.




Figure 97: Imported NVs.

- Now the CSV File folder is populated with the imported NVs as shown in Figure 97.

The list can be sorted by each column. Selecting a line will display a number of associated properties in the property view below. Multiple items can be selected by using the <Ctrl> key and clicking with the mouse. All items can be selected by pressing <Ctrl-A>.

### 5.3.4 Scanning NVs online from the Network

LOYTEC devices also support an online network scan on the CEA-709 network. In this scan, the device searches for other devices on the CEA-709 network and pulls in NV information of these devices. These NVs can then be used instead of importing them from a CSV file.

#### To scan NVs online off the CEA-709 network

- Click on the **Datapoints** tab of the main window.
- Select the folder **CEA709 Network Scan**.



- Right-click on that folder and select **Scan CEA709/852 Network....** This opens the **CEA709 Management** dialog as shown in Figure 98.




Figure 98: CEA-709 network scan dialog.

4. If the device has not been installed with a network management tool (e.g. LNS-based tool), press the **Configure CEA709 Port** button. This opens the device install dialog as shown in Figure 99.




Figure 99: Configure CEA-709 port dialog.

5. Select the **Manually set domain** check-box and click the **Set** button. This sets the device configured, online to start the scan. Then click **Close**.

---

*Note:* You need to set the same domain as the devices to be scanned. Click **Get Domain from Network** and press a service pin on some other, already installed device to retrieve the domain information before setting the device online.

---

6. Click on the button **Discover Devices**. This starts a network scan. The results are put in the device list box.
7. Alternatively, click the button **Discover on Service Pin**. Then press the service pin of a particular device on the network. This device will be added to the device list.



8. Select a device in the device list. To give the device a usable name, enter the name in the **Device Name** field and click on the **Update Selected** button.
9. Then click the button **Scan**. This scans the NVs on the selected device and adds them to the CEA709/852 Network Scan folder as a separate sub-folder for the device as shown in Figure 100.

**Tip!**

*If you are not sure which device you have selected, click on **Wink**. The selected device will execute its wink sequence.*





Figure 100: CEA-709 network scan results.

10. Click **Close** when all devices needed have been scanned.

### 5.3.5 Select and Use Network Variables

Data points in the **CEA709 LNS Scan** folder, the **CEA709 Network Scan** folder, the **CEA709 CSV File** folder, or in the **CEA709 Devices from XIF** folder can be selected for use on the device. Select those NVs, which shall be used on the device.

#### To Use NVs on the Device

1. Go to any of the CEA709 LNS Scan, CEA709 Network Scan, CEA709 CSV File, or the CEA709 Devices from XIF folder.
2. Use the multi-select feature by holding the *Shift* or *Ctrl* keys pressed.
3. Click on the button  **Use on Device** in the tool bar.
4. This creates data points in the CEA709 Port folder of the device. All data points in that folder will actually be created on the device after downloading the configuration.

---

**Tip!** Data points can be edited by selecting a single point or using multi-select. The available properties to be edited are displayed in the property view below.

---

### 5.3.6 Change the NV Allocation

After selecting the **Use on device** action on scanned or imported NVs, they are assigned a default NV allocation in the CEA709 port folder. This default allocation can be changed, e.g., for imported NVs when they shall be allocated as static NVs on the device.

#### To Change the NV Allocation Type

1. In the data point view, select the NVs in the CEA709 port folder, for which the NV allocation shall be changed.

---

**Tip!** By using *Ctrl-A* all NVs can be selected.

---

2. Select the **NV allocation** property as indicated by the red rectangle in Figure 101.
3. To make the data points static NVs on the device, select **Static NV** in the **Basic Properties** section.





Figure 101: Change the NV allocation type.

### 5.3.7 Create Static NVs

The LOYTEC device can be configured to change its static interface and boot with a new one. Apart from creating static NVs from scanned or imported data points, static NVs can also be created manually in the CEA709 port folder.

#### To Create Static NVs Manually

1. Select the **Datapoints** folder under the CEA-709 port folder.



2. Right-click in the data point list and select **New Datapoint...** in the context menu. This opens the NV creation dialog as shown in Figure 102.

Figure 102: Create a static NV manually.

3. Enter a data point name and a programmatic name. The programmatic name is the name of the static NV which is being created.
4. Select a resource file. To create a SNVT, let the STANDARD resource file be selected.
5. Select a SNVT and a direction. If a non-standard resource file has been selected, choose from one of the UNVTs.

---

**Tip!** Recently created SNVTs are available in the **Recent NV Types** list. Click on one to set the NV type without scrolling through the drop-down box.

---


6. The chosen SNVT implies a specific network unit. Compatible units for the metric (SI) and U.S. systems are chosen. Adapt these to your needs.
7. Choose a functional block, where this static NV shall be located in.
8. Click **Create Static NV**. The static NV is created and appears in the data point list.
9. Note, that the static interface of the device will change as soon as static NVs are added or modified in the data point manager. This change is reflected in a new model number, which the device will receive after the configuration download (see Section 3.6.3). Also note that the manually created static NVs are not bound automatically by the Configurator. They simply appear on the device and need to be bound in the network management tool.
10. Click **Close**.

### 5.3.8 Create External NVs

External NVs are not actually allocated NVs on the device as NVs. Instead, the device uses polling to read data from and explicit updates to write data to external NVs. Since external NVs do not affect the static NV interface of the device, they can be used to extend the interface configuration at run-time, when no LNS with dynamic NVs is available.

#### To Create an External NV manually

1. Select the **Datapoints** folder under the CEA-709 port folder.



2. Right-click in the data point list and select **New Datapoint...** in the context menu. This opens the NV creation dialog.
3. Click on the tab **External** as shown in Figure 103.




Figure 103: Create a new external NV.

4. Select the device in the box **Select a Device** on the left-hand side.
5. Enter the properties of the external NV on that device, starting with the local data point name, the remote programmatic NV name, the NV type (SNVT) and direction. Note, that the direction is the direction of the external NV on the device. Therefore, the remote output NV nvo00\_temp becomes an input on the device. Also enter the NV index in decimal notation. This is the index under which the NV is found on the remote device. Choose the preferred addressing mode, e.g., Subnet/Node.
6. Click **Create External NV** to add this NV to the data point list.
7. The external NV now appears in the data point list. For external NVs, which are inputs to the device, adapt the poll cycle property to your needs.

### 5.3.9 Configuration Download over LNS

After the data points have been configured, the configuration needs to be downloaded to the device. For doing so, the device must be online. If the device is not yet connected to the network, the configuration can be saved to a project file on the local hard drive.

If the Configurator is connected to a CEA-709 device via LNS and the device uses static or dynamic NVs, it can automatically generate Bindings in the LNS database. This behavior can be influenced in the download dialog. The download process can also manage the device template upgrade automatically in LNS, if the static interface changes (see Section 3.6.3).

#### To Download a Configuration

1. In the main connections window, click on the **Download Configuration** speed button



in the tool bar of the main connections window. This will open the configuration download dialog as shown in Figure 35.

2. If no bindings shall be generated, deselect the **Automatically create bindings** checkbox indicated by the red circle in Figure 104.
3. If the static NV interface has been changed, a new model number for the device needs to be selected. This is necessary, as the static network interface of the device changes on the CEA-709 network. The Configurator automatically selects a usable value, which can be overridden in the field **Model Number** marked by the blue rectangle in Figure 35.
4. Click **Start** to start the download. Each of the actions is displayed in the **Task List** section of the dialog. The current progress is indicated by the progress bar below.
5. When the download process has finished, a notification window appears, which has to be acknowledged by clicking **OK**.




Figure 104: Configuration Download Dialog via LNS.

Note, that after the download is complete, the interface changes become active on the device (i.e., the static NV interface has changed). Refresh the network management tool to synchronize the tool with the changes to the LNS database made by the Configurator (e.g., use the menu “LonMaker|Refresh” in LonMaker or hit *F5* in NL-220).

Normally, the Configurator software optimizes the download process by not executing certain LNS operations, if not necessary. For example, only those bindings and dynamic NVs


are deleted and re-created, which correspond to real changes in the interface. The user can check the **Force Full Upgrade** option to clean and re-do all steps.

### 5.3.10 Enable Legacy NM Mode

For network management tools, which do not support the ECS (enhanced command set) network management commands, the legacy network management mode must be configured. Please contact the tool's vendor for information whether ECS is supported or not. Note, that changing to legacy network management mode changes the static interface of the device.

#### To Enable Legacy NM Mode

1. In the Configurator menu go to **Settings → Project settings ...**
2. Click on the tab **CEA709**.
3. Put a check mark in **Enable Legacy Network Management Mode**.




4. Click **OK**.
5. Download the configuration to activate the change.

### 5.3.11 Build XIF for Port Interface


When using static NVs on the device, the Configurator can export a new XIF file for the changed static interface. Before exporting the XIF for the interface it is recommended to download the configuration into the device. In this case, the Configurator can verify that the model number of the port is correct.

#### To Create a XIF File

1. Make sure the **Model No** will match the final model number of the port. If not, enter an appropriate model number in the toolbar of the **Datapoints** tab.



2. Select the **CEA-709 Port** folder




3. Right-click on that folder and in the context menu select **Build XIF ....**
4. This opens a file requestor where the XIF file name needs to be entered. Select a useful name to identify the device, e.g., as "LINX-10X\_1.xif".

### 5.3.12 Upload Dynamic NVs from Device

In LNS-based tools it is possible to create dynamic NVs on the device manually. This is a possible workflow to engineer the NV interface of the device in the LNS database. To use those manually created dynamic NVs, the Configurator must synchronize its dynamic NV information with the CEA-709 port.

### To Upload Dynamic NVs

1. Select the **CEA709 Port** folder.



2. Right-click and select **Sync Dynamic NVs** in the context menu. The Configurator then loads any new dynamic NVs, which have been created but are not yet represented by data points on the CEA-709 port. The process completes when the dialog shown in Figure 105 appears.



Figure 105: Synchronizing dynamic NVs from the device.

3. Click on **Finish**. The new dynamic NVs now appear in the data point list and can be edited and used on the device.

---

## 5.4 Advanced CEA-709 Configuration

### 5.4.1 Import Devices from XIF Templates

When working entirely without LNS, nodes on the network can be engineered via importing device templates from a XIF file. The Configurator provides a XIF device template import feature. Having devices imported from a XIF file is similar to have devices scanned online from the CEA-709 network, only their actual node IDs are unknown.

#### To Import from a XIF Template

1. Select the folder **CEA709 Devices from XIF**.



2. Right-click on the folder and select **Create device(s) from XIF file...** from the context menu.
3. In the file open dialog select a XIF file to import and click **Ok**.
4. The imported data points appear as a device sub-folder of the **CEA709 Devices from XIF** folder named after the XIF file name.



5. In that folder select those data points, which shall be used on the device and use them on the device as described in Section 5.3.5.
6. Repeat the import of XIF files for as many nodes as needed. The same XIF can be imported more than one time, resulting in multiple nodes of the same type in the **CEA709 Devices from XIF** folder.

### 5.4.2 Install Unconfigured Devices

CEA-709 devices must be installed by a network management tool (e.g., LNS-based tool) to be available for communication. Devices can be imported from a CEA-709 network scan or from a XIF file. If no network management tool is available, the CEA-709 device manager must be used to install the unconfigured devices. To install a device the following steps need to be done:

- The imported devices must be assigned to actual devices on the network. This is done by setting a node ID that corresponds to a node on the network.
- The domain information must be written to the device and it must be set configured, online to be ready for data communication.

#### To Install Devices

1. Open the CEA-709 management dialog by clicking on the **Manage CEA-709 Devices** speed button.



2. If devices have been imported via a XIF file, they do not have a node ID (all zero). To assign the physical node to the device, select the imported device.

Node	tn50	8000000582BA	9000D70532000032	1	26	50
Node		FE611378BCB9	9000010103800000	3	127	00
LINX-100 (FT-10)	TC1309_legacy...	00000000000000	9000D746168A0401	0	0	01

3. Click the **Update NodeID** button and press the service button on the network node. The node ID will be filled in to the selected device. Alternatively the node ID can also be entered manually.
4. After node IDs have been assigned to all unassigned devices, select the device(s) to install in the **Device List** of the CEA-709 management dialog. Multi-select of devices is possible.
5. Click the **Install** button. This opens the **Install Devices** dialog as shown in Figure 106.




Figure 106: Install devices dialog.

6. Select the device to be installed.
7. Enter the domain information or click **Get Domain from Network** and press a service pin.



8. Enter a subnet and node address and click **Install**.
9. Some nodes won't be operable on the new settings until they are reset. Click the **Reset** button to reset the selected node.
10. Repeat this step for other unconfigured devices on the network.

### 5.4.3 Using Feedback Data Points

Feedback data points allow reading back the value written out over an output data point. In LONMARK systems getting a feedback value is normally accomplished by creating a dedicated feedback NV on the device, which can be bound back to the devices that are interested in the currently active value on an output.

Some nodes, however, do not possess such feedback NVs for certain functions. To support getting feedback values on such nodes, the Configurator can create feedback data points based on existing output data points. This is especially interesting for bound output NVs (static and dynamic alike). The corresponding feedback data point is an input, which uses the original output NV for polling the target NV. Once the binding is changed the new target is polled. No additional input NV needs to be created for the feedback value, if the feedback data point feature is used. Alternatively, the output data point can be switched to a value data point with an integrated feedback function without the need for an extra feedback data point.

#### To Create a Feedback Data Point

1. Select an output data point in the data point list of the **CEA-709 Port** folder, e.g. 'nvoHumid101'.
2. Right-click and choose **Create Feedback-Point** from the context menu.
3. A new input data point is created, having '\_fb' appended to the original name, e.g., 'nvoHumid101\_fb'. Note, that the feedback data point maps to the same NV index as the original output data point.
4. Choose an appropriate poll cycle in the data point properties for the feedback data point.

#### To Create an Integrated Feedback

1. Select an output network variable in the data point list of the **CEA-709 Port** folder, e.g. 'nvoHumid101'.
2. In the data point properties tab change the direction from 'output' to 'value'.
3. Choose an appropriate poll cycle in the data point properties for the value data point.

### 5.4.4 Working with Configuration Properties

Configuration properties (CPs) are supported by the LNS network scan and the online network scan. They can be selected and used on the device in a similar way as NVs. There is a notable difference to NVs: CPs are part of files on the remote nodes. Reading and writing CPs on the device results in a file transfer.

The device supports both, the LONMARK file transfer and the simpler direct memory read/write method. In both cases however, one has to keep in mind that a file transfer incurs more overhead than a simple NV read/write. Therefore, polling CPs should be done at a much slower rate than polling NVs (e.g., every 10 minutes).

Another aspect is how CPs are handled by network management tools. Formerly, those tools were the only instance that could modify CPs in devices. Therefore, most tools do not automatically read back CPs from the devices when browsing them. This can result in inconsistencies between the actual CP contents on the device and their copy in the network

management tool. It is recommended to synchronize the CPs from the device into the LNS database before editing and writing them back.

---

**Important!**      *For L-DALI devices it is highly recommended to start the Configurator as LNS Plug-In when modifying and downloading parameters! In this case the Configurator will automatically synchronize the CP values to the LNS database.*

---

---

**Note:**      *Always choose **Current device values** or **New Device Values** for “Source of CP Values” when commissioning or replacing a LOYTEC device!*

---

### To Synchronize CPs in NL220

1. Double-click on the device object in the device tree
2. Press the **Upload** button on the Configuration tab of the device properties (see Figure 107).




Figure 107: Configuration Tab for Configuration Properties in NL220.

### To Synchronize CPs in LonMaker TE

1. Right-click on a device object and select **Commissioning → Resync CPs...** from the context menu.
2. This opens the dialog shown in Figure 108.




Figure 108: Set Configuration Properties in LonMaker TE.

3. In this dialog select the radio button **Upload values from device** in the **Operation** group box. To use the current settings of the device as default values for new devices, select **Set device template defaults from device**.
4. Execute the operation by clicking the **OK** button.


#### 5.4.5 Working with UNVTs, UCPTs

This device supports user-defined type, including user-defined network variable types (UNVTs) and user-defined configuration property types (UCPTs). In order to interpret the contents of user-defined types, the *device resource files* supplied by the vendor must be added to the resource catalog on your PC.

Once the resource files are installed, the CEA-709 network scan and the LNS scan will display the user-defined types from the resource files. Those data points can be used on the device like regular, standard-type data points. Also manual creation of UNVTs can be performed.

##### To Manually Create a Static UNVT

1. Perform the steps to manually create a static NV as described in Section 5.3.7.
2. When the **Create New NV** dialog appears, change the resource file from 'STANDARD' in the **Resource File** drop-down box to the desired, user-defined resource file



3. Then select the desired UNVT from the **Type** drop-down list below. This list will display the types of the selected resource file only.
4. Click **Create Static NV** to create the UNVT on the device.

#### 5.4.6 Configure User-Defined Function Blocks

As a default the device comes with 8 LONMARK function blocks in which the user can create NVs. They have a pre-defined name ('Gateway' or 'PLC' depending on the device model). For complex applications it may, however, be desirable to change those function blocks to more meaningful names in order to group NVs in a better way. Note, that this change will also change the static interface of the device. This makes a new model number necessary (see Section 3.6.3).

##### To Configure Function Blocks

1. Select the menu **Tools → Manage LonMark Objects ...**. The dialog **Manage LonMark Objects** as shown in Figure 109 appears.




Figure 109: Manage LONMARK Objects.

2. Edit the field **Configurable Function Blocks** to the number of needed function blocks.
3. Select a **Type** from the drop-down box for your function block. This drop-down box is available at the top of a function block array. A change applies to the entire array.
4. To break up the pre-defined array, double-click on a name in the **Name** column and edit it to something different. Typing the same name for consecutive function blocks will create a new array.
5. To use an object type outside the scope of standard types, just type in the number instead of choosing from the drop-down.

### 5.4.7 Incremental Scans

The data point scanning engine of the Configurator is able to mark data points already used on the device and data points found in new scans. This feature can be used, if an existing data point configuration loaded from disk shall be updated to incremental changes in the network devices. The last two columns of the network variable scan (LNS or online) **Used on Device** and **Last Scan** provide this information.

The example shown in Figure 110 illustrates such an incremental change. The first 9 NVs stem from an older scan (already scanned) where the first 5 have actually been used on the device (used check mark). The last scan resulted in the new items 10 to 12. When sorting the **Last Scan** column it can be easily decided, which of the new NVs shall be used in the data point configuration.

Datapoint Name	No.	Dir...	Remote NV	Type	Remote Device	Func. Block	Used...	Last Scan
← nvo00temp	1	In	nvo00temp	SNVT_temp	tn50	Ctrl	<input checked="" type="checkbox"/>	Already scanned
→ nvi01temp	2	Out	nvi01temp	SNVT_temp	tn50	Ctrl	<input checked="" type="checkbox"/>	Already scanned
← nvo02lux	3	In	nvo02lux	SNVT_lux	tn50	Ctrl	<input checked="" type="checkbox"/>	Already scanned
→ nvi03lux	4	Out	nvi03lux	SNVT_lux	tn50	Ctrl	<input checked="" type="checkbox"/>	Already scanned
← nvo04lev_percent	5	In	nvo04lev_percent	SNVT_lev_percent	tn50	Ctrl	<input checked="" type="checkbox"/>	Already scanned
→ nvi05lev_percent	6	Out	nvi05lev_percent	SNVT_lev_percent	tn50	Ctrl	<input type="checkbox"/>	Already scanned
← nvo06temp_f	7	In	nvo06temp_f	SNVT_temp_f	tn50	Ctrl	<input type="checkbox"/>	Already scanned
→ nvi07temp_f	8	Out	nvi07temp_f	SNVT_temp_f	tn50	Ctrl	<input type="checkbox"/>	Already scanned
▷ nvo08switch	9	In	nvo08switch	SNVT_switch	tn50	Ctrl	<input type="checkbox"/>	Already scanned
▷ nvi09switch	10	Out	nvi09switch	SNVT_switch	tn50	Ctrl	<input type="checkbox"/>	New
← nvo10motor_state	11	In	nvo10motor_state	SNVT_motor_state	tn50	Ctrl	<input type="checkbox"/>	New
→ nvi11motor_state	12	Out	nvi11motor_state	SNVT_motor_state	tn50	Ctrl	<input type="checkbox"/>	New

Figure 110: Example of an incremental data point scan

# 6 BACnet

---

## 6.1 Project Settings

### 6.1.1 BACnet Settings

The BACnet configuration tab as shown in Figure 111 allows configuring properties of the device's BACnet port. The options are:

- **Enable Unsolicited COV:** Put a check mark on this option to enable COV-U on the BACnet port. When active, the device sends unsolicited COV broadcast on all BACnet objects, when their value changes in accordance to the respective COV rules.
- **Always create value objects on auto-create:** If activated, the auto-create BACnet points function of the configuration software creates commandable value objects (AV, BV, MV) instead of output objects (AO, BO, MO) and non-commandable value objects (AV, BV, MV) instead of input objects (AI, BI, MI). This feature can be activated if the regular input/output model is not desired.
- **Use 255.255.255.255 for global broadcast:** This setting overrides the standard behavior of BACnet to send broadcasts as global IP broadcasts. This can solve scanning problems with some BACnet devices.
- **Enable periodic I-Am broadcast:** This setting enables the periodic transmission of I-Am broadcasts. Specify the interval in seconds. If disabled, the device sends an I-Am only when starting up. This is the default behavior of BACnet devices.
- **Support proprietary properties:** Check this option if a scan on a remote device shall find proprietary properties in addition to the standard properties of supported objects.
- **Enable extended BACnet features:** Check this option to enable additional properties in BACnet server objects. This affects Elapsed\_Active\_Time, etc. properties in binary objects, custom properties in scheduler objects (value labels).
- **Keep OWS values in device:** Check this option, if BACnet properties changed by the OWS shall be maintained in the device even after a new configuration download. Without this option, a new configuration will overwrite any changes made by the OWS with the values defines in the configuration (e.g., high and low limits of alarm conditions). The default is to overwrite with configuration values. If this option is set, BACnet object names are made writeable by the OWS as well.
- **String encoding:** This setting defines, how strings in BACnet objects are encoded. By default it is ASCII/UTF-8, which is compatible with most BACnet software. To support characters of Western European languages, choose ISO-8859-1. To support Unicode character sets (e.g., Japanese) select UCS-2.
- **Default Poll cycle, Default COV Expiry, Default Write Priority:** This setting defines the default values that are used when creating new client mappings. Changing this option does not affect already existing client mappings. The default write priority is also used when writing to commandable server objects.
- **Preallocated Calendar Objects:** This setting defines how many BACnet calendar objects shall be created as a default. These are filled up with calendar patterns as they are defined.

- **Native L-IOB objects start with instance nr:** This setting defines, which BACnet object instance numbers shall be assigned to native L-IOB BACnet objects starting with the defined instance number. This enables you to keep native BACnet objects for L-IOB I/Os in a separate instance number range than regular BACnet objects.

Figure 111: BACnet Project Settings.

### 6.1.2 BACnet Settings for L-DALI Models

Figure 111 shows the BACnet configuration tab for L-DALI models. The additional options in the **L-DALI BACnet Interface** section are:

- **Interface Version:** This setting determines the scheme used for the BACnet object IDs and the BACnet objects available on the BACnet interface of the L-DALI.
- **Enable BACnet object name editing:** When this box is not checked, the name of the BACnet objects is derived from the name of the corresponding DALI device, group or channel, respectively. It therefore cannot be modified. To be able to change BACnet object names independent of the name of DALI devices etc., check this check-box.
- **Interface:** This section allows configuring with function is available via BACnet objects on the BACnet interface of the L-DALI. One the one hand parts of the interface, which are not required for a specific project (e.g. Constant Light Controller, etc.) can be disabled. On the other hand additional functionality can be enabled (e.g. for emergency light applications or DALI buttons support).

For details on the L-DALI BACnet interface see the L-DALI User Manual [3].

The screenshot shows the 'BACnet' tab in the LINX Configurator. It contains two main sections: 'BACnet Settings' and 'L-DALI BACnet Interface'.

**BACnet Settings:**

- ☐ Enable Unsolicited COV
- ☐ Always create value objects on auto-create
- ☐ Use 255.255.255.255 for global broadcast
- ☐ Enable periodic I-Am broadcast
  - I-Am Interval: 60 sec
- ☐ Support proprietary properties
- ☐ Enable extended BACnet features
- ☐ Keep OWS values in device
- String encoding:
  - ☒ ASCII/UTF-8
  - ☐ UCS-2 (Unicode)
  - ☐ ISO-8859-1
- Default Pollcycle: 60 sec
- Default COV Expiry: 900 sec
- Default Write Priority: 8 (dropdown)
- Preallocated Calendar Objects: 10

**L-DALI BACnet Interface:**

- Interface Version: Full featured (dropdown)
- ☐ Enable BACnet object name editing
- ☒ Lamp Actuator objects
  - ☒ Feedback
  - ☐ Command
  - ☐ Battery Charge
- ☒ Group Actuator objects
  - ☒ Feedback
  - ☒ Scene
  - ☒ Status
  - ☒ Energy
  - ☐ Command
  - ☐ Battery Charge
- ☒ Channel Actuator objects
  - ☒ Feedback
  - ☒ Scene
  - ☒ Status
  - ☒ Energy
  - ☐ Command
  - ☐ Battery Charge
- ☒ Sensor objects
- ☒ Constant Light Controller objects
- ☐ Button objects
- ☐ Sunblind Controller objects

Figure 112: BACnet Project Settings for L-DALI models.

## 6.2 BACnet Workflow

This section discusses a number of work flows for configuring a BACnet L-INX in different use cases in addition to the simple use case in the quick-start scenario (see Chapter 0). The description is intended to be high-level and is depicted in flow diagrams. The individual steps refer to later sections, which describe each step in more detail.

### 6.2.1 Involved Configuration Files

In the configuration process, there are a number of files involved:

- LINX Configurator project file: This file contains all ports, data points, and connections of a project. These files end with “.linx”, “.liob”, “.ldali”, or “.gtw”. It stores all relevant configuration data and is intended to be saved on a PC to backup the device’s data point configuration.
- EDE file: When engineering offline, the Configurator can import remote BACnet data points via an EDE file. Out of this information client mappings are created.

### 6.2.2 Engineer Online

The flow diagram in Figure 113 shows the steps on how to configure the BACnet port when being on-line. In this case, the device must be present in the BACnet network and configured with an IP address. The user can connect to the device and scan for existing BACnet devices and objects on the network.




Figure 113: Basic work flow to engineer on-line.

Start the Configurator in stand-alone mode and connect to the device via the FTP method (see Section 4.4.1). If changing an existing configuration, upload the current configuration from the device (see Section 4.4.2). In the Configurator, start an on-line network scan to discover devices and BACnet objects (see Section 6.3.1). Select the data points that the device shall expose (see Section 6.3.3). Alternatively, you can create client mappings (see Section 6.3.4) and local BACnet server objects (see Section 6.3.5) manually. Finally, the configuration needs to be downloaded to the device (see Section 4.4.4). It is recommended to backup the device configuration to a file for being able to replace the device in the network (see Section 4.4.6).

### 6.2.3 Engineer Offline

The flow diagram in Figure 114 shows the steps on how to configure the BACnet port when being off-line. In this case, the device doesn't need to be present in the BACnet network. The systems integrator can engineer the BACnet port and download the configuration at a later point in time.






Figure 114: Basic work flow to engineer off-line.

Start the Configurator in stand-alone mode and select the appropriate device model in the menu **Model** (see Section 4.4.1). In the Configurator, import external BACnet data points from an EDE file (see Section 6.3.2). Select the data points that the device shall expose (see Section 6.3.3). Alternatively, you can create client mappings (see Section 6.3.4) and local BACnet server objects (see Section 6.3.5) manually. When finished store the configuration on the hard drive and download later to the device (see Section 4.4.4).

## 6.3 BACnet Configuration

### 6.3.1 Scan for BACnet Objects

LOYTEC devices also support an online network scan on the BACnet network. In this scan the device searches for other devices on the BACnet network and pulls in the BACnet object information of these devices. These BACnet objects can then be used on the device as the basis for client mapping.

#### To Scan for BACnet Objects

1. Go to the **Datapoints** tab.
2. Select the folder BACnet Network Scan



3. Right-click on that folder and select **Scan BACnet Network...**. This opens the BACnet Network Scan dialog as shown in Figure 115.




Figure 115: BACnet network scan dialog.

- Click on the button **Discover Devices**. This starts a network scan. To narrow down the scan range and reduce scanning time, enter a device ID range into the **Scan from** and **to** fields. The results are put in the device list box. A progress bar below indicates how many devices are being scanned.
- Select a device in the device list and click the button **Scan Objects**. This scans the BACnet objects on the selected device and adds them to the **BACnet Network Scan** folder as a separate sub-folder for the device.
- If the scan does not give the expected results, change the **Device Scan Mode** to normal or slow and try again. With this setting the scanner uses simpler but slower protocol features.
- Click **Close** when all devices needed have been scanned.

*Note:* If proprietary properties access on a remote device is required, support for proprietary properties must be enabled in the BACnet tab of the Project Settings dialog (see Section 6.1).

### To Incrementally Scan New Objects

- Open the BACnet scan dialog as described above, select the desired BACnet device and click on **Scan Objects** in order to re-scan objects on that device.
- The resulting device folder in the **BACnet Network Scan** folder will be updated with the new objects found on the BACnet device.
- The last two columns **Used on Device** and **Last Scan** can be used to determine, which objects are new and have yet been used on the device, as shown in Figure 116.

Object Name	No.	Direction	Type	Instance	Device	Use	Used...	Last Scan
▸ TxioFmo	2	Value	Multistate Value	0	AS_1(1)	1	<input checked="" type="checkbox"/>	Already scanned
▸ PLFmo	3	Value	Multistate Value	1	AS_1(1)	1	<input checked="" type="checkbox"/>	Already scanned
▸ Dalifmo	4	Value	Multistate Value	2	AS_1(1)	1	<input checked="" type="checkbox"/>	Already scanned
▸ TXM16RL_0_1PrphDev_1	5	Value	Multistate Value	9	AS_1(1)	1	<input checked="" type="checkbox"/>	Already scanned
▸ TXM18RB_0_1PrphDev_1	6	Value	Multistate Value	10	AS_1(1)	1	<input type="checkbox"/>	Already scanned
▸ B_1R_1LgtCmd_D11_Grp01Pr...	7	Value	Multistate Value	26	AS_1(1)	1	<input type="checkbox"/>	New
▸ B_1R_1LgtCmd_D12_Grp01Pr...	8	Value	Multistate Value	27	AS_1(1)	1	<input type="checkbox"/>	New

Figure 116: Result of an incremental BACnet network scan.

### 6.3.2 Import from EDE or IEIEJ File

If the device is engineered offline or some of the required BACnet devices are not yet online in the network, the engineering process can be done by importing a device and object list from a set of EDE files. These objects also appear in the import folder and can be later used on the device as client mappings. The IEIEJ format is a Japanese import format.

There are a set of EDE files. Select the main EDE file, e.g. *device.csv*. The EDE import will also search for the other components, which must be named *device-states.csv*. Which components are expected, please refer to the Chapter “Operating Interfaces” of the LOYTEC Device User Manual [1]. Example EDE files can be found in the ‘examples’ directory of the LOYTEC Configurator software installation directory.

#### To Import BACnet Objects from an EDE File

1. Go to the **Datapoints** tab.
2. Select the folder **BACnet EDE File**




3. Right-click and select **Import File**. In the following file selector dialog, choose the EDE import file and click **OK**. The import detects whether the .csv file is an EDE or IEIEJ import file.
4. If an IEIEJ file has been selected for import, a dialog opens and prompts for a device instance and device name.
5. Now the **BACnet EDE File** folder is populated with the imported BACnet objects.



### 6.3.3 Use Imported BACnet Objects

After BACnet objects have been imported (with a network scan or by importing from an EDE file) the user can select the BACnet objects that the device shall access. When executing the **Use on device** the configuration software allocates client mappings on the device. These client mappings will read or write values from the BACnet objects in the network.

In an additional step, there can be also server objects allocated on the device. These server objects can be created automatically from converting a client mapping to a server object. This is usually done, if the imported BACnet objects shall also be directly modified over the BACnet network on the device itself.

#### To Use Imported BACnet Objects on the Device

1. Open the data point manager dialog and select the desired BACnet objects in one of the import folders.
2. Use the multi-select feature by holding the *Shift* or *Ctrl* keys pressed.
3. Click on the button  **Use on Device** in the tool bar.
4. This creates data points in a remote device sub-folder of the BACnet Port/Datapoints folder. All data points in that folder will be created as client mappings. No server object is created automatically in this case.

 Mapped Property	Present_Value
 Client Map	LVIS-ME2xx (139), BI 1, Present_Value, Auto, Expiry 900 sec / Poll 60 sec

5. To also create server objects select the data points in question using the multi-select feature. Then activate the property **Allocate Server Object** in the section **Advanced**.
6. For editing the client mapping, you may multi-select client map data points and edit the corresponding data point properties **Client Confirmed COV**, **Client COV Expiry**, **Client Map Type**, **Client Write Priority**, **Remote Instance Number**.

### 6.3.4 Create a Client Mapping

The client mapping information can also be created manually. Usually, this is done to create client data points without importing information from EDE or scanning online.

#### To Create a Client Mapping

1. Select the **Datapoints** folder under the **BACnet Port** folder.
2. Right-click in the data point list and select **New Datapoint...** in the context menu. This opens the **Create New BACnet Point** dialog as shown in Figure 117.




Figure 117: Create Client Mapping Dialog.

3. Select the tab **Client Mapping**.
4. Choose a target device in the list of known devices. Enter a **Data Point Name**, choose an **Object Type**, and edit the target object instance number. Then select the **Mapping Type**. For read client mappings edit the **COV expiry** or **Polycle** setting. If the read type **COV unsolicited** is selected, the device listens for unsolicited COV broadcasts only (and no COV subscribe or polling is performed). If **COV unsolicited + poll** is selected, the client mapping also performs polling with the defined polycle. For write client maps edit the **Write Priority**. For value client maps edit both. When finished click **Create Client Mapping**.

---

*Note:* In COV unsolicited mode, value updates are accepted from any UnconfirmedCOV or UnconfirmedEventNotification (regardless of event type) broadcast, if the remote object ID matches.

---


- For an analog client mapping define a **Network Unit**. This is the engineering unit of the remote object. Optionally, define a unit representation of the remote scalar value for the metric (SI) and U.S. unit system on the device.

### 6.3.5 Create Server Object

On the BACnet port server objects can also be created manually. These BACnet objects are visible on the BACnet network and can be modified by other devices. They appear as data points in the **BACnet/Datapoints** folder.

#### To Create Server Objects Manually

- Select the **Datapoints** folder under the **BACnet Port** folder.



- Right-click in the data point list and select **New Datapoint...** in the context menu. This opens the **Create New BACnet Point** dialog as shown in Figure 118.

Figure 118: Create a Server Object manually.

- In the **Mandatory Properties** enter a **Datapoint Name** and an **Object Type**. Optionally, update the **Instance No** and select the **Commandable** check box for value objects, if the value object shall be commandable from the network.
- In the **Optional Properties** you may select **Unit SI** and **Unit U.S.** for analog objects. BACnet objects have no fixed network unit. Depending on the chosen unit system, the analog BACnet object will be created with the specified metric (SI) or U.S. unit in the engineering unit property.
- For all object types you can enter the **Description**. The **Device Type** can be left empty. For multi-state objects you have to select a multi-state map.
- Click **Create Server Object**. The BACnet data point is created and appears in the data point list.

### 6.3.6 Export Server Objects to an EDE File

When engineering offline it can be beneficial to hand out the server object configuration of the device to other parties electronically. For doing so you may export the server object configuration to a set of EDE files. The set of EDE files consist of the main EDE file, e.g. *myDevice.csv*. This file contains the list of all objects and refers to state texts that are exported to a second file named *myDevice-states.csv*. For which components are exported in an EDE file, please refer to the Chapter “Operating Interfaces” for BACnet in the LOYTEC Device User Manual [1].

#### To Export an EDE File

1. Select the **BACnet Port** folder.



2. Right-click and select **Export EDE ...** in the context menu. This opens the EDE export dialog to enter the EDE header information as shown in Figure 119.





Figure 119: EDE Export Dialog.

3. Click the  button to select the EDE file export location.
4. Specify the **Device Name** and **Device Instance**. The device instance will be used by other tools to configure their BACnet clients for accessing the exported device.
5. Optionally fill in project name, author to document that information in the EDE file.
6. Click **Export**.

### 6.3.7 Import Server Objects from an EDE File

It is also possible to import a BACnet server object interface from EDE files. In this use case, the device is configured to resemble a the device of the EDE file. If conflicts in instance numbers or object names arise with already existing server objects, the imported objects are re-assigned.

There are a set of EDE files. Select the main EDE file, e.g. *device.csv*. The EDE import will also search for the other components, which must be named *device-states.csv*. Which components are expected, please refer to the Chapter “Operating Interfaces” for BACnet in the LOYTEC Device User Manual [1]. Example EDE files can be found in the ‘examples’ directory of the LOYTEC Configurator software installation directory.

#### To Import BACnet Server Objects from an EDE File

1. Select the folder **BACnet Port**



2. Right-click and select **Import Server Objects from EDE....** In the following file selector dialog, choose the EDE import file and click **OK**.
3. Now a folder for the device in the EDE file is generated and a report is displayed, informing about the imported objects and possible reassignments.

### 6.3.8 Map other Properties than Present\_Value

When creating a BACnet server object, the Present\_Value property is mapped by the created data point. That means writing and reading on the data point reads or writes the Present\_Value. If other properties shall be accessed, they must be added to the BACnet server object's data point.

#### To Add other BACnet Properties

1. Select the BACnet server object for adding properties.
2. Right-click on the data point and select **Add/Remove BACnet properties ...** from the context menu. The dialog appears as shown in Figure 120.




Figure 120: Dialog for adding/removing BACnet properties.

3. Check the additional properties. Checking the **Read** box will add an input data point, checking the **R/W** box will add a value data point.
4. Click **Close**. The selected data point can now be expanded with the plus icon and show its additional properties as sub-data points.

AI1	1	<input type="checkbox"/>	<input type="checkbox"/>	Out	AI1	Analog Input
High_Limit	1.1	<input type="checkbox"/>	<input type="checkbox"/>	Value	AI1	Analog Input
Low_Limit	1.2	<input type="checkbox"/>	<input type="checkbox"/>	Value	AI1	Analog Input

5. To remove properties perform the same steps and uncheck the corresponding checkboxes. Alternatively, select the property (or more) and press the *Delete* key.

### 6.3.9 Enable International Character Support

By default BACnet objects on the device contain ASCII strings in properties such as object name, description, active/inactive text, state texts. This is the setting most third-party tools are interoperable with. To support international character sets, the device can be configured to expose strings as ISO-8895-1 (for most Western European languages) or UCS-2 (for Unicode character sets such as Japanese).

### To Enable International Character Support

1. In the Configurator software menu go to **Settings → Project settings ...**. This opens the **Project Settings** dialog (see also Section 6.1).
2. Click on the tab **BACnet**.
3. Put a check mark either on **ASCII/UTF-8** (default), **UCS-2** (Unicode, e.g., for Japanese), or **ISO-8859-1** (for Western European languages).
4. Click **OK**.
5. Download the configuration to activate the change.

### 6.3.10 Read the Active Priority

In BACnet objects that possess a priority array the effective value depends on the used write priority slots. A special data point on the device can be added that allows reading out the active priority of such an object, giving a value between 1 and 16.

#### To Read the Active Priority of a Local Object

1. Select the BACnet server object for adding properties.
2. Right-click on the data point and select **Add/Remove BACnet properties ...** from the context menu. The dialog for mapping BACnet properties to data points appears.
3. For the **Present\_Value** select the additional box **Active Priority**.



#### To Read the Active Priority of a Feedback Value

1. Select a write client mapping.
2. Right-click on the data point and select **Create Priority Feedback Point** from the context menu.
3. A new data point is created, which is a feedback client mapping that reads the active priority out of the remote object.

### 6.3.11 Write and Read with Priority

In BACnet objects that possess a priority array the effective value depends on the used write priority slots. As default, data points for those objects have the direction input, which is intended to read the resulting value. Additional priority write output data points can be added for writing to the BACnet object. For those data points, a write priority between 1 and 16 can be defined. The default write priority is defined by the project settings.

To read back the value at a given priority slot, additional priority read input data points can be added. They reflect the value at the configured priority slot between 1 and 16. If the priority slot is NULL the data point stays at invalid value.

#### To Create a Priority Write Data Point

1. Select the commandable BACnet server object.
2. Right-click and select **Create Priority Write Point...** from the context menu.



3. A dialog prompts for the write priority. Note that the write priority can also be changed later.
4. The new priority write data point appears below the original BACnet server object data point.

Datapoint Name	No.	OPC	Param	PLC in	PLC out	Direction
AO1	1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Value
AO1_pri4_Write	2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out

### To Create a Priority Read Data Point

1. Select the commandable BACnet server object.
2. Right-click and select **Create Priority Read Point...** from the context menu.
3. A dialog prompts for the read priority. Note that the read priority can also be changed later.
4. The new priority read data point appears below the original BACnet server object data point.


Datapoint Name	No.	OPC	Param	PLC in	PLC out	Direction
AO1	1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Value
AO1_pri4_Write	2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out
AO1_pri4_Read	3	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In

## 6.3.12 Duplicate BACnet Devices with Data Points

When importing BACnet devices via network scan or EDE file, the resulting client mappings are used on the device. For each BACnet device a sub-folder is created which organizes the client mapping data points for that device. The BACnet device itself appears in the BACnet device manager. After editing the client mapping data points as appropriate, entire device folders can serve as templates for duplication. The created copies of the data points are pointing to an unassigned device, which can be commissioned later on the Web interface.

### To Duplicate BACnet Devices

1. Select a folder created for a scanned/imported BACnet device.



2. Right-click and choose **Duplicate** in the context menu.
3. The **Duplicate data points and set naming rules** dialog opens as shown in Figure 121.




Figure 121: Duplicate BACnet devices.

- In the **Data Point Assignment** section choose to assign the duplicated data points to a new BACnet device instance and click **OK**.
- A new BACnet device folder is created with the duplicated client mapping data points. The original BACnet device is also duplicated, leaving the actual device instance number empty and marking the device to be commissioned later on the Web interface as described in the LOYTEC Device User Manual [1].
- The **BACnet Device Manager** shows the created devices as depicted in Figure 122.

No.	Device Name	Instance No.	Mac Address	Net	Objects	Used
1	FanCoil1	2001		0	Unknown	0
2	FanCoil2	Comm.		0	Unknown	0
3	FanCoil3	Comm.		0	Unknown	0
4	FanCoil4	Comm.		0	Unknown	0

**Mandatory Properties**

Device Instance No.

**Optional Properties**

Mac Address

Destination Network

Device Name

☐ Use static device binding

☒ Commission later

Figure 122: Duplicated BACnet devices for later commissioning.

# 7 M-Bus

## 7.1 Configurator


This section describes how to use the Configurator software for the management of M-Bus data points. For further information on the Configurator software refer to Chapter 4.

### 7.1.1 Activating M-Bus Configuration

Before a new M-Bus configuration can be managed, the M-Bus option must be enabled. The project settings are described in detail in Section 4.3.

#### To Activate the M-Bus Configuration

1. Open the project settings dialog.
2. In the **Device Configuration** tab enable the M-Bus check box on all desired ports.
3. Press the **OK** button.



**Important:** *If the M-Bus Port is deactivated via the checkbox or a firmware or model version is chosen, which does not support M-Bus, the complete M-Bus configuration is deleted. In this case a dialog is displayed, which has to be confirmed.*

### 7.1.2 Data Point Manager for M-Bus

The Configurator uses a central concept to manage data points. The data point manager is used to select, create, edit and delete data points. The dialog is divided into three sections:

- The folder list (Figure 123)

- The data point list (Figure 124),
- And a property view.




Figure 123: Data Point Manager Dialog with M-Bus folder list

No.▲	OPC	Direction		Datapoint Name	M-Bus Counter Type	Storage	Tariff	Subunit	Function	Device Address	ID
19	<input checked="" type="checkbox"/>	In		Electricity_JAN_4_Operating Time1	Operating Time	0	0	2	instVal	4	1055
20	<input checked="" type="checkbox"/>	In		Electricity_JAN_4_Operating Time2	Operating Time	0	0	3	instVal	4	1056
21	<input checked="" type="checkbox"/>	In		Electricity_JAN_4_Operating Time3	Operating Time	0	0	4	instVal	4	1057
22	<input checked="" type="checkbox"/>	In		Electricity_JAN_4_Operating Time4	Operating Time	0	0	5	instVal	4	1058
23	<input checked="" type="checkbox"/>	In		Electricity_JAN_4_Operating Time5	Operating Time	0	0	6	instVal	4	1059
24	<input checked="" type="checkbox"/>	In		Electricity_JAN_4_Operating Time6	Operating Time	0	0	0	instVal	4	105A
25	<input checked="" type="checkbox"/>	In		Electricity_JAN_4_Current	Current	0	0	4	instVal	4	105B
26	<input checked="" type="checkbox"/>	In		Electricity_JAN_4_Power	Power	0	0	5	instVal	4	105C
27	<input checked="" type="checkbox"/>	In		Electricity_JAN_4_Power1	Power	0	0	6	instVal	4	105D
28	<input checked="" type="checkbox"/>	In		Electricity_JAN_4_Power2	Power	0	0	7	instVal	4	105E

Figure 124: Datapoint Manager Dialog with M-Bus Data Point List.

### 7.1.3 Folder List

At the left is a list of folders which is used to sort the available data objects by their category. There are a number of predefined M-Bus folders available. All other folders are described in section 4.2.1:

- **Imported:** This folder has a number of sub-folders for different import methods:
  - **M-Bus Network Scan:** This folder holds data points scanned online from an attached M-Bus network. When scanning an M-Bus device, a subfolder is created under M-Bus Network Scan. The name of this subfolder is generated automatically from the information of the scanned device. Additionally under the device sub-folder a data point folder is created.
- **Device Templates:** This folder contains created data point templates for the different technologies.
  - **M-Bus Device Templates:** This folder contains a sub-folder for each device, which is imported from an M-Bus device template. This device folder also contains a sub-folder with the data points specified in the template. Data points can be added to the folder. Additionally suitable data objects can be created for the use on the device by selecting the **Use on Device** option.
- **Filter templates:** This folder contains filter templates for scanned M-Bus devices

- **M-Bus:** This folder contains a folder with data points for each created filter template.
- **LINX-XXX:** This is the device folder (see Section 4.2.1). For M-Bus an additional port folder exists:
  - **M-Bus Port:** This folder contains the remote M-Bus data points, which are used on the device.

#### 7.1.4 Network Port Folders

The M-Bus network port folder on the device has the same structure of sub-folders as the other network port folders in Section 4.2.2. Currently only the **Datapoints** folder exists for the M-Bus network port.

#### 7.1.5 M-Bus Properties

Apart from the common data point properties discussed in Section 4.2.4 the data points of the M-Bus technology have additional properties:

- **Storage Number:** This property defines the M-Bus storage number of the data point. This number can also be specified by the manufacturer using a DIF/DIFE combination.
- **Tariff:** This property defines the tariff of the M-Bus data point. This number can also be specified by the manufacturer using a DIF/DIFE combination.
- **Subunit:** This property defines the subunit of the M-Bus data point. This number can also be specified by the manufacturer using a DIF/DIFE combination.
- **Function Field:** This property defines the function field of the M-Bus data point. Possible values for this property are instantaneous value, maximum value, minimum value and value during error state. This number can also be specified by the manufacturer using a DIF/DIFE combination.
- **Data Coding:** This property defines how the value for this data point is coded. The information is not relevant for input data points but it is mandatory for output data points. Possible values for this property are instantaneous value, maximum value, minimum value and value during error state. This number can also be specified by the manufacturer using a DIF/DIFE combination.
- **VIF/VIFE:** The VIF and VIFE (Value Information Field and VIF Extension) specify the counter type and its scaling. When the most significant bit of a VIF or VIFE is set, another VIFE follows. Up to ten VIFEs can be specified. When this combination is entered, also the M-Bus counter type and the unit are updated according to the VIF/VIFE combination.
- **M-Bus Counter type:** This information is derived from VIF/VIFE. It informs about the type of the data point value (e.g. Energy counter value or operating time).
- **M-Bus Device Name:** This property shows the name of the M-Bus device the remote data point is connected to.
- **M-Bus Device Address:** This property shows the address name of the M-Bus device the remote data point is connected to.
- **M-Bus Pollgroup:** Each M-Bus input data point is attached to a poll group. If more than one poll group is available, the poll group can be selected. This property is not shown for output data points.
- **M-Bus Poll Mode:** Usually M-Bus data points are read via a default read or a selective read (REQ\_UD2 telegram specifying the appropriate data point). When this value is set to **Defined by device setting**, the method which is specified in the device settings is used. Using **Default Read** or **Selective Read** overrides the device setting for this data point. It is advised to leave this option at the default setting and adapt it only, if a device requires a different configuration for some specific data points.

### 7.1.6 M-Bus Device Capabilities

Communication to an M-Bus device can be configured with a number of options to match the target device's capabilities. Some of them are important to treat special behavior of certain M-Bus devices on the market. In principle, the device capabilities specify, what kind of M-Bus read requests the device is able to process and which other preconditions apply.

- **Default Read:** If nothing else is specified, the default read method is used. Default read usually means that the M-Bus device transfers all available data during a read operation.
- **Append Read RAM:** If Default Read is active, this option can be enabled to send a Read RAM request and append the returned data to the default read result. Some meters provide extra data in their RAM contents.
- **Append Read EEPROM:** If Default Read is active, this option can be enabled to send a Read EEPROM request and append the returned data to the default read result. Some meters provide extra data in their EEPROM contents.
- **Selective Read:** Selective read means that the particular data point to be read can be selected during the read request. If the device is able to perform such a request, the selective read method should be chosen as it saves bandwidth.
- **Send NKE before default read:** If this option is enabled, an NKE message is sent to the device before sending the default read request. This reinitializes the M-Bus device. Devices which send multi-telegram messages start with their first telegram in the next read request; it is advised to set this option for these devices. Please note that some devices perform a complete device reset when they receive an NKE message. In this case the read request may fail. Please refer to the manufacturer's manual of the M-Bus device for more information.
- **Send application reset before default read:** If this option is enabled, an application reset is sent to the device before sending the default read. Please refer to the manufacturer's manual of the M-Bus device for detailed information.
- **Ignore multi-telegram message:** This flag only has an impact on reading M-Bus devices, which send multi-telegram messages. In this case, the transfer is aborted after the reception of the first telegram. It is advised to also set the **Send NKE before default read** when setting this flag.
- **Max. per Request:** This setting specifies the maximum number of data points to be specified within one selective read request (REQ\_UD2 telegram).

---

## 7.2 M-Bus Workflow

This section discusses the workflows for setting up an M-Bus environment. The network can either be set up online using the network scan function or also offline by either setting up the devices and data points manually or by using M-Bus device templates. The change of primary addresses and Baud rates can only be done online.

### 7.2.1 Offline Engineering

This section describes how an M-Bus network can be set up without using the M-Bus network. Figure 125 shows the workflow. First, the M-Bus devices, address and Baud rates of the M-Bus devices must be configured for example by following the device manufacturer's guidelines (see Section 7.3.3). Afterwards the devices and data points are configured in the Configurator either configured manually (see Section 7.3.4) or by using M-Bus device templates (see Section 7.3.5). Also mixing the two methods is possible. When using the device templates also data points can be added manually. The configuration is then downloaded to the device and the device is rebooted (see Section 4.4.4).




Figure 125: Workflow for offline engineering.

## 7.2.2 Online Engineering

This section describes how the M-Bus network is set up when the network can be accessed. Figure 126 shows the workflow. If necessary the addresses and Baud rates the M-Bus devices are using can be configured using the Configurator (see Section 7.3.3). The devices and data points can then be configured by scanning the connected devices (see Section 7.3.2), manual configuration (see Section 7.3.4) or also by using the M-Bus device templates (see Section 7.3.5). The configuration is then downloaded to the device and the device is rebooted (see Section 4.4.4).




Figure 126: Workflow for online engineering.

## 7.3 Using the Configurator for M-Bus

### 7.3.1 Automatic Naming

Operations which automatically generate M-Bus data points or allocate M-Bus devices use auto naming. Automatic naming is also used, when a device is applied and no device name is specified.

The automatic device name is concatenated from the device medium (e.g. Electricity), the 3 character M-Bus manufacturer code and the address. For example the device could be automatically named “Electricity\_LOY\_7”. If a name is specified, the device name of the applied device is concatenated the address, e.g., “Device\_7”.

The automatic data point name is concatenated from the device name the data point is related with and the type of the data point. For example if a data point is an energy counter value in the device “Electricity\_LOY\_7”, the name “Electricity\_LOY\_7\_Energy” is created.

### 7.3.2 Scanning the M-Bus Network

The Configurator software can connect to the device and perform an M-Bus network scan. The network scan searches for connected M-Bus devices and data points on those devices. The device scan goes through each address on the M-Bus network using the specified Baud rates. When scanning for a device the M-Bus scanner starts with the highest specified Baud rate. If the device is found, it is added to the device list, if not, the scan tries to find the device address with the next lower Baud rate and so on.

The M-Bus scan can only scan for input data points. Output data points can be created manually or imported via a device template.

#### To Scan for Devices

1. Connect to the device as described in section 4.4.1.
2. Right click on the Folder **M-Bus Network Scan** and select **Scan M-Bus Network**. This opens the **M-Bus Management** Dialog containing the scan options shown in Figure 127.




Figure 127: M-Bus Network Scan dialog.

3. In **M-Bus Transmission Settings** choose the address scanning mode. The default is secondary address scanning. This prevents problems with duplicate primary addresses of previously uninstalled M-Bus devices.
4. On device models with multiple active M-Bus ports, select **Auto** to scan on all ports or select a specific port.
5. Select all applicable Baud rates for the device scan.

---


**Important:** *Selecting 300 Baud results in a very slow scan. Aborting the scan is possible using the Abort Device Scan button*

---



6. Start the scan by pressing the **Start Device Scan** button. The progress bar shows the progress of the scan. Under the progress bar, a text displays, which device is currently scanned. When a device is found, it is displayed in the device list. The name of the device is automatically created as described in section 7.3.1.
7. The scan can be aborted by selecting the **Abort Device Scan** button.
8. When the device scan is finished (either aborted or ended), the devices can be selected for a data scan. Also multi-select is possible.
9. Select the devices which have to be scanned for data points and press the **Scan Device Data** button. This scans all data points of the selected devices. For every device a folder with the name of the device is created under the **M-Bus Network Scan** folder. The data points found are placed in the **Datapoints** folder of the appropriate devices.

### To Use Datapoints from a Scan


1. Go to the **Datapoints** folder of the device of the M-Bus scan.
2. Select the desired data points, also multi-select is possible.
3. Either press on the **Use on Device** button  or right-click and select **Use on Device**. The selected data points are now available in the **Datapoints** subfolder of the **M-Bus Port** folder.

### To Create Filter Templates from a Network Scan

1. Go to the **Datapoints** folder of the device of the M-Bus scan.
2. Select the desired data points, you wish to create a template from, also multi-select is possible.
3. Right click on one of the selected data points and select **Use as Template**. This creates a folder, containing the selected data points.

### To Use data points from a Scan using Filter Templates

1. Right click on the folder M-Bus Network Scan and select either **Use on device and apply single M-Bus filter templates** or select **Use on device an apply all M-Bus filter templates**. When all filter templates are applied, all matching data points from the scan are used on the M-Bus port of the device.
2. When **Use on device and apply single M-Bus filter templates** is selected, the following dialog is opened:



3. The drop down box shows all available M-Bus filter templates. As additional information, when a filter template is chosen, the number of data points is displayed, which match the template.
4. Select **OK** to use the data points on the device.

### 7.3.3 Network Management Functions

This section describes how the M-Bus network management functions can be used. It describes adding and removing M-Bus devices as well as changing the Baud rate or the primary address. The tasks can be performed offline as well as online.

The **Network Management** dialog shown in Figure 128 shows a list of devices. Devices which have been scanned using a network scan have the status online, devices which have been created manually or using device templates have the status offline. If a device which is online also has been scanned for device data, a green checkmark is displayed in the **Data** column.

#### To Start the M-Bus Network Management Dialog

1. Connect to the device via FTP as described in section 4.4.1.
2. Select the M-Bus dialog by clicking on the **M-Bus** button



in the tool bar of the **Datapoints** tab. The M-Bus Management dialog opens, showing the **Network Management** tab displayed in Figure 128.

**Device List**

Device Name	Address	ID	Port	Status	Datapoints	Template
dev1	Comm.			offline	9	NZR_WZ-HY.mbus

**Device Properties**

Device Name:

Port:

Device Address:  ...  [1 ... 250]

Device Baud rate:

☐ Commission later

**Optional Device Information**

Manufacturer ID:

Version:  [0 ... 255]

Medium:

Model Name:

**Device Capabilities**

☒ Default Read

☐ Selective Read

☐ Send NKE before default read

☐ Send application reset before default read

☐ Ignore multi telegram message

Max. per request:  [1... 32] / 0 default

**Controls**

Create Device    Create From Template

Remove Device    Export Device Template

Update Device    Cleanup unused devices

Replace Device

**M-Bus Transmission Settings**

☒ Use Secondary Addressing

☐ Use Primary Addressing

Port:

**Network Scan**

☐ Send NKE before scan

☐ Send application reset before scan

☐ Ignore multi telegram message

☐ 300 Baud

☒ 2400 Baud

☐ 9600 Baud

Scan for Devices

Abort Device Scan

Scan Device Data

Progress: 0%

Figure 128: M-Bus network management dialog.

#### To Add an M-Bus Device Manually Without Scanning

1. Fill in the **Device Address** and select a **Device Baudrate** from the drop down box. For a device model that has multiple active M-Bus ports select the **Port** as well.

2. A **Device Name** can be specified. If more devices with the same properties have to be created using subsequent addresses, the end address can be specified in the input field on the right hand side of the **Device Address** field.



3. If the device shall be created without knowing the address of any physical device, leave the above address fields empty (port at Auto) and select **Commission later**. This device can then be commissioned on the Web UI as described in the LOYTEC Device User Manual [1].
4. The device capabilities specify, what kind of M-Bus read requests the device is able to process. If nothing is specified here, **Default Read** is used. For other options please refer to Section 7.1.6.
5. The optional device information just represents manufacturer details and model details. This information is used in two cases:
  - a. The device name is not specified – in this case a device name is automatically created from the optional device information. The name is concatenated to MAN\_Medium\_address, where MAN is the 3 character manufacturer code, Medium is the M-Bus medium (e.g. “Heat”) and address is the specified address.
  - b. Device templates can be created from the M-Bus devices. The device templates store the device information in order to identify a device.
6. Click on the **Create Device** button. This creates the M-Bus device and adds it to the device list on the left hand side of the dialog.
7. When a device is selected the device information is displayed in the appropriate fields on the right hand side of the dialog. The information can be changed in the fields. Press the **Update Device** button to store the changes.
8. If a device has to be deleted select the device and press the **Remove Device** button.

### To Add an M-Bus Device Manually Using the Scan Device Information

1. Enter the address of the device which has to be scanned.
2. Press the **Scan Device Information** button. If the device is found in the network, the device properties are filled.
3. Enter a name for the M-Bus device in the **Device Name** field. If no name is specified the name is created automatically as described in section 7.3.1 from the M-Bus data the device sends back.
4. Enter a device address in the **Device Address** field. If more devices with the same properties have to be created using subsequent addresses, the end address can be specified in the input field on the right hand side of the Device Address field.



5. If the device shall be created without knowing the address of any physical device, leave the above address fields empty and select **Commission later**. This device can then be commissioned on the Web UI as described in the LOYTEC Device User Manual [1].
6. Select a device Baud rate from the combo box.

7. Press the **Create Device** Button to add the number of devices.

### To Add an M-Bus Device Manually Using a Template

1. Enter a name for the M-Bus device in the **Device Name** field. If no name is specified the name is created automatically as described in section 7.3.1 from the M-Bus data the device sends back.
2. Enter a device address in the **Device Address** field. If more devices with the same properties have to be created using subsequent addresses the end address can be specified in the input field on the right hand side of the **Device Address** field.



3. Click on the **Create From Template** button. This opens the **Import M-Bus Device Template** dialog shown in Figure 129.





Figure 129: Import M-Bus Device dialog.

4. Press the  button and select a template file from the **Open** dialog.
5. After selecting the file, the device information is displayed.
6. Press **Import** for importing the template or **Cancel** for closing the dialog without any changes.
7. When a template is imported, a folder with the name of the device is created. Under this folder a **Datapoints** folder containing the data points from the template file is created.

---

**Tip:** *Data points can be added to the data points of the template by right-clicking in the data point list and selecting New Datapoint.*

*When you want to create one or more device instance together with its data points, use the button **Create with DP** instead of the button **Create From Template**. This creates the device instance, all the data points from the template can be found in the M-Bus Port's data points folder.*


---

### To Remove an M-Bus Device

1. Select the device which has to be removed, also multi-select is possible.
2. Press the **Remove Device** button. If the device already has data points, these data points have to be deleted before the remove can be performed.

### To Change the Properties of an M-Bus Device

1. Select the device. This shows the device properties.



Device Properties

Device Name	Electricity_JAN_4
Device Address	4
Device Baudrate	2400

2. Update the field **Device Address** or select another Baud rate in the combo box.
3. Press the button **Update Device**.
4. If a device address is specified, which already exists, a failure message is displayed.

### To Scan Devices Using the M-Bus Network Management Dialog

1. Select the Baud rate for the device scan. For more information on scanning the M-Bus network refer to Section 7.3.2.
2. Start the scan by pressing the **Scan for Devices button**.
3. When the device scan is finished, the devices can be selected for a data scan. Also multi-select is possible.
4. Select the devices which have to be scanned for data points and press the **Scan Device Data** button. This scans all data points of the selected devices. For every device a folder with the name of the device is created under the **M-Bus Network Scan** folder. The data points found are placed in the **Datapoints** folder of the appropriate devices.

---

**Important:**

*If a device, which is scanned, is already in the device list, the existing device can either be overwritten; deleting all previously scanned data points of the existing device or the scanned device can be discarded. A dialog is displayed for this decision.*

---

### 7.3.4 Manual Configuration of Data Points

It is possible to manually configure M-Bus data points. Manual configuration is done by specifying all information, the M-Bus device manufacturer provides.

#### To Manually Create an M-Bus Data Point

1. Click on the M-Bus port **Datapoints** folder.
2. Right click in the data point list view and select **New Datapoint** in the context menu.
3. This opens the **Create New M-Bus Datapoint** dialog shown in Figure 130.

Figure 130: Create M-Bus Object dialog.

4. If the M-Bus device which provides the data point is not in the list, it has to be created. In this case open the Network Management dialog by clicking the Edit M-Bus Devices button.
5. Create the device in the **Network Management** dialog and close the dialog.
6. Select the device which provides the M-Bus data point.
7. The data point properties are entered in the group **Datapoint Properties** as shown in Figure 130.
8. Enter a data point name. If no name is entered, the data point is named as described in section 7.3.1.

Datapoint Name

9. At the moment only analog M-Bus data points are supported. Select if the data point is an analog input or output. For analog inputs no M-Bus data coding can be specified.

Object Type

10. Select if the data point shall be specified by providing the numbers for Storage number, tariff, subunit, function field and data coding or if the information configured using the DIF/DIFE list.

☒ Enter Storagenumber, tariff, etc...  
☐ Enter DIF/DIFE

For reference, if one piece of information is entered, the other one is derived from the specified data. Enter the data point information.

Storage Number: 0

Tariff: 0 [0 ... 255]

Subunit: 0 [0 ... 255]

Function Field: instVal

Data Coding: int24

DIF List: [FD:80:...]

If the DIF list is entered, the dialog expects hexadecimal numbers. As soon as the information is entered the other fields are updated.

11. Enter the VIF/VIFE list. This list specifies the M-Bus counter type, and unit of the data point. Also this field has to be specified using hexadecimal numbers.

VIF List: [FD:80:...]

12. Usually data points are added to a default poll group. If the data point has to be member of another poll group than default, the poll group can be selected using the drop down box.

Pollgroup: Default Pollgroup

In the drop down box the previously specified poll groups are shown. If no poll group is configured only the default poll group is displayed. Refer to section 7.3.7 for more information on poll groups.

13. The FIV list defines the network unit of the M-Bus data point. In addition you may choose its representation in the selected unit system.

Unit SI: m³

Unit U.S.: cu.ft.

14. Press the **Create** button to create the M-Bus data point

---

**Tip:** *After creating a data point, the poll group can be changed in the data points property view. Also multi-select can be used.*

---

### 7.3.5 Importing via Device Templates

For some M-Bus devices special templates are available which specify all available data points of an M-Bus device as well as the device properties. Such templates can be imported into the configuration.

#### To import an M-Bus Device Template

1. Right click on the Folder **M-Bus Device Templates** and select **Import device template** from the context menu.
2. This opens the **Import M-Bus Device Template** dialog shown in Figure 131.





Figure 131: Import M-Bus Device Template dialog.

3. Press the  button and select a template file from the **Open** dialog.
4. After selecting the file, the device information is displayed.
5. Press **Import** for importing the template or **Cancel** for closing the dialog without any changes.
6. When a template is imported, a folder with the name of the device is created. Under this folder a **Datapoints** folder containing the data points from the template file is created.

---

*Tip:*


*Data points can be added to the data points of the template by right clicking in the data point list and selecting New Datapoint.*

*Importing a device template from the folder list does not create a device instance. Device instances can only be created using the import in the Network Management Dialog.*

---

### To Use Imported Data Points

Using imported data points is a little different to the use of scanned data points. For a scanned device a device instance already exists – the important information address and Baud rate – devices imported from templates do not have an address or Baud rate.

1. Go to the **Datapoints** folder of the device of the M-Bus Templates.
2. Select the desired data points, also multi-select is possible.
3. Either press on the **Use on Device** button  or right-click and select **Use on Device**. This opens the **M-Bus Configure Device For Use** dialog shown in Figure 132.






Figure 132: Use on Device dialog.

4. The device list displays all devices which have the same Manufacturer ID, version number and Medium. If no device instance matches the device template, create one by entering the network management dialog. The dialog can be entered by pressing the **Edit M-Bus Devices** button. In the management dialog, the device instance can be either created manually (take care of entering the correct Manufacturer ID, Version and Medium) or by simply importing the template again.
5. Select one or more device instances from the list and press the **Use On Device** button. This creates for each selected data point and each selected device one data point in the M-Bus Port's data point list.

### 7.3.6 Creating Device Templates

M-Bus device templates can be created from a data point configuration. In fact, it is only possible to create a device template using an existing device or an existing device template with data points. This device and its data points can either be configured manually, by a scan or also imported from a device template itself.

An M-Bus device template contains the following configuration items describing an M-Bus device:

- M-Bus device settings,
- M-Bus data points,
- Folders used to organize M-Bus data points on a device,
- Structure types, multi-state maps, historic filters used by M-Bus data points,
- Pollgroup definitions used by M-Bus data points.

#### To Create an M-Bus Device Template Using Devices

1. Select the M-Bus dialog by clicking on the **M-Bus** button



in the tool bar of the **Datapoints** tab. This opens the **Network Management** dialog as displayed in Figure 133.





Figure 133: M-Bus Network Management dialog.

2. The device list shows all devices of the current configuration. Select a device.
3. Press the **Export Device Template** button. This opens the **M-Bus Export Template** dialog.



4. Press the **...** button and select a template file from the **Save** dialog.
5. Enter the **Creator**, **Company Name** and **Version** for the template. This information is stored in the template file, when importing the template file the information is displayed after selecting the file.
6. Press the **Export** button.

### To Create an M-Bus Device Template File Using a Device Template

1. Right-click on the folder of the device template that has to be exported or its data point folder and select **Export Device Template...** from the context menu.

2. Proceed as described above to export the template in the **Export M-Bus Device Template** dialog.

### 7.3.7 Poll Groups

In an M-Bus network, the master has to poll the slave devices. Input data points are therefore attached to a poll group. If nothing else is specified, the default poll group is used for input data points. The default poll group has a poll cycle of 60 seconds.

Three different types of poll groups can be specified:

- **Time-based:** The poll group is triggered on a time base. This means that after a specific time – the poll cycle – the poll group is processed.
- **Trigger-based:** The poll group is triggered on a special trigger data point. As soon as the trigger condition is met, the poll group is processed.
- **Trigger-based with synchronization:** This type is similar to the trigger-based. The difference is that when the trigger condition is met, a broadcast synchronization message is sent over the M-Bus. This causes the devices which are able to perform a sync operation to store special data points for later reading. After the broadcast is sent, the poll group is processed.

---

*Tip:* If an M-Bus device is only able to process default read requests, it is advisable to attach all data points of this device to the same poll group (this increases the performance).

*The poll group a data point is attached to can be changed in the properties view of the data points. The poll group can also be changed for multiple data points using multi-select.*

---

#### To Create a Time-Based M-Bus Poll Group

1. Select the M-Bus dialog by clicking on the **M-Bus** button



in the tool bar of the **Datapoints** tab. The **M-Bus Management** dialog opens.

2. Open the **Pollgroups** tab. This shows the dialog displayed in Figure 134.




Figure 134: Pollgroup Management dialog.

3. The default poll group is selected and its properties are displayed. Enter the name of the new poll group and enter the poll cycle in seconds. Make sure that under **Pollgroup Mode** Time-based is selected.
4. Press the **Save** button to store the poll group and continue editing.
5. If a poll group needs to be updated or deleted, select the poll group edit the data and press the **Update Selected** or **Delete Selected** button.
6. Press the **Close** button to finish editing. When the poll groups have not been saved, a dialog asks whether the changes have to be saved or not.

### To Create a Trigger-Based M-Bus Poll Group

1. Select the M-Bus dialog by clicking on the **M-Bus** button



in the tool bar of the **Datapoints** tab.

2. In the **M-Bus Management** dialog, open the **Pollgroups** tab. This displays the poll groups management tab displayed in Figure 134.
3. Enter a new poll group name and select Trigger-based or Trigger-based with synchronization.
4. Create the poll group by pressing the **Create New** button.
5. Select the new poll group. This enables the **Add...** and **Remove** buttons from the triggers.

6. Press the **Add...** button and select a trigger data point. This can for example be a binary user register.
7. The selected trigger data point appears in the trigger list as shown:

Triggers		
Datapoint	Type	Condition
Triggerdatapoint_Read	Value Update	-

8. Select the trigger from the list and check the desired trigger conditions.

Conditions	
Enabled Conditions	
<input type="checkbox"/>	True (!= 0)
<input type="checkbox"/>	False (== 0)
<input type="checkbox"/>	Invalid
<input type="checkbox"/>	Offline

9. The trigger conditions are then displayed in the trigger list.

Triggers		
Datapoint	Type	Condition
Triggerdatapoint_Read	Value Update	True (!= 0), False (== 0)

10. Press the **Close** button to leave the dialog.

### 7.3.8 Trending Synchronized Meter Data

The use of trigger-based poll groups with synchronization allows trending synchronized meter data. A trigger data point triggers a synchronization message over the M-Bus network. The M-Bus meters which are able to perform the synchronization action store the meter values. These values are read out afterwards.

#### To Trend Synchronized Meter Data

1. Create a binary trigger data point.
2. Create a trigger-based poll group with synchronization.
3. Create a trend log as described in Section 4.9. Set the **Trend Mode** to **Change of Value (COV)** and add all required data points.

### 7.3.9 M-Bus Protocol Analyzer

When connected to a device a protocol analyzer is available for any of the M-Bus ports. The protocol analyzer can be found in the M-Bus Management dialog. Figure 135 shows the dialog for the M-bus protocol analyzer. Select the protocol analyzer tab for the respective M-Bus port.

The status on the right hand side of the dialog shows, if the device is connected or if the protocol analyzer is stopped or started. When connected to a device, the protocol analyzer can be started by pressing the **Start Protocol** button. This starts the protocol analyzer in the device. Every time a transmission is made on the M-Bus port, the transmission is displayed in the list. Additionally the protocol data is stored in the device in a rotating log file. The protocol log can hold up to 40 kB of protocol data. So also when the Configurator was not running for an interesting time, the protocol data can be loaded from the device using the

**Load From Device** button. The protocol data can be stored as CSV file using the **Save** button, with the **Clear** button, the shown protocol is deleted.




Figure 135: M-Bus protocol analyzer.

Figure 136 shows a typical protocol analyzer output for the M-Bus port. It shows the following information:

- **Seq.:** sequence number, which is automatically created in the device. This number is unique for one port.
- **Timestamp:** transmission time.
- **Frame Type:** M-Bus frame type (Short Frame, Control Frame Long Frame, E5 – in this case, no other data follows).
- **Dir.:** direction. Either SND (send) or RCV (receive).
- **Start1, Start2:** Start byte (must be equal).
- **Length1, Length2:** Frame length according to the M-Bus standard (must be equal).
- **C Field:** Control field.
- **Address:** M-Bus address.
- **CI Field:** Control information field.
- **Checksum:** Checksum of the frame.
- **Stop:** Stop byte.
- **Payload:** Payload in hexadecimal numbers (this column cannot be used for sorting).

Some frame types do not contain the full set of fields. Please refer to the M-Bus standard for additional information.

Network Management   Pollgroups   Protocol Analyzer													
Start Protocol		Stop Protocol		Load From Device		Save		Clear		Status: Log stopped			
Seq.	Timestamp	Dir.	Frame Type	Start1	Length1	Length2	Start2	C Field	Address	CI Field	Checksum	Stop	Payload
68	2009-05-14 13:57:26.955	SND	Short Frame	10				5B	07		62	16	
69	2009-05-14 13:57:27.048	RCV	Long Frame	68	32	32	68	08	07	72	06	16	01 01 41 82 AE 4C 48 07 44 60 00 0C
70	2009-05-14 13:57:27.378	SND	Short Frame	10				7B	07		82	16	
71	2009-05-14 13:57:27.470	RCV	Long Frame	68	32	32	68	08	07	72	29	16	01 01 41 82 AE 4C 48 07 45 60 00 0C
72	2009-05-14 13:57:27.800	SND	Short Frame	10				5B	07		62	16	
73	2009-05-14 13:57:27.891	RCV	Long Frame	68	32	32	68	08	07	72	84	16	01 01 41 82 AE 4C 48 07 46 60 00 0C
74	2009-05-14 13:57:28.221	SND	Short Frame	10				7B	07		82	16	
75	2009-05-14 13:57:28.312	RCV	Long Frame	68	32	32	68	08	07	72	84	16	01 01 41 82 AE 4C 48 07 47 60 00 0C
76	2009-05-14 13:57:28.643	SND	Short Frame	10				5B	07		62	16	
77	2009-05-14 13:57:28.734	RCV	Long Frame	68	32	32	68	08	07	72	CA	16	01 01 41 82 AE 4C 48 07 48 60 00 0C
78	2009-05-14 13:57:29.064	SND	Short Frame	10				7B	07		82	16	

Figure 136: Typical protocol analyzer output for M-Bus port.

### 7.3.10 Device Replacement

This section describes how an M-Bus device can be replaced using the M-Bus network management functions.

#### To Replace an M-Bus Device on the Network

1. Connect to the device via FTP as described in Section 4.4.1.
2. Disconnect the device which has to be replaced from the M-Bus and connect the new device to the network.
3. Start the M-Bus device scan (see Section 7.3.2). The new device may produce a primary address conflict. This conflict may either be resolved automatically after the scan or manually during device replacement.
4. Select the M-Bus dialog by clicking on the **M-Bus** button



in the tool bar of the **Datapoints** tab. The M-Bus Management dialog opens, showing the **Network Management** tab displayed in Figure 128.

5. Select the device which has to be replaced and press the **Replace Device** button. This opens the dialog displayed in Figure 137.




Figure 137: M-Bus Device Replacement Dialog.

6. In the replacement dialog all compatible devices for replacement are shown. If the required device is not shown in the list, remove the check **Only show exact match**. This

will show all possible devices. Note, that only M-Bus devices can be selected as a replacement device, which do are not yet using data points on the device.

7. Select the replacement device and press **OK**.
8. If the selected replacement device is still in conflict, the Configurator will suggest to automatically update the primary address to that of the replaced device.



# 8 Modbus

## 8.1 Configurator

This section describes how to use the Configurator software for the management of Modbus data points. For further information on the Configurator software refer to Chapter 4.

### 8.1.1 Activating Modbus Configuration

Before a new Modbus configuration can be managed, the Modbus option must be enabled for the appropriate port. The project settings are described in detail in Section 4.3.

#### To Activate the Modbus Configuration

1. Open the project settings dialog.
2. In the **Device Config** tab enable the Modbus check boxes on the desired ports as shown in Figure 138. Setting the check box enables Modbus on that port. Edit the Modbus communication settings.
3. If slave mode is enabled, you may change the default Modbus register layout in the **Modbus Slave Register Configuration** box.
4. Click the **Download** button to activate the changes in the configuration.




Figure 138: Project settings for Modbus.

---

**Important:** *If the Modbus port is deactivated via the checkbox or a firmware or model version is chosen, which does not support Modbus, the entire Modbus configuration is deleted. In this case a dialog is displayed, which has to be confirmed.*

---

### 8.1.2 Data Point Manager for Modbus

The Configurator uses a central concept to manage data points. The data point manager is used to select, create, edit and delete data points. The dialog is divided into three sections:

- The folder list (Figure 139),
- The data point list (Figure 140),
- And a property view.




Figure 139: Data Point Manager Dialog with Modbus folder list.

No.	OPC	Direction		Datapoint Name	Device Name	Start Address	Register Type	Data Length	ID
1	<input checked="" type="checkbox"/>	In		VARh_cap_net	ug5110_1_1	180	HOLD	4	1065
2	<input checked="" type="checkbox"/>	In		VARh_ind_net	ug5110_1_1	178	HOLD	4	1066
3	<input checked="" type="checkbox"/>	In		VAh_net	ug5110_1_1	176	HOLD	4	1067
4	<input checked="" type="checkbox"/>	In		Wh_net	ug5110_1_1	174	HOLD	4	1068
5	<input checked="" type="checkbox"/>	In		VARh_cap_del	ug5110_1_1	172	HOLD	4	1069
6	<input checked="" type="checkbox"/>	In		VARh_ind_del	ug5110_1_1	170	HOLD	4	106A
7	<input checked="" type="checkbox"/>	In		VAh_del	ug5110_1_1	168	HOLD	4	106B

Figure 140: Datapoint Manager Dialog with Modbus Data Point List.

### 8.1.3 Folder List

At the left is a list of folders which is used to sort the available data objects by their category. There are a number of predefined Modbus folders available. All other folders are described in section 4.2.1:

- **Device Templates:** This folder contains created data point templates for the different technologies.
  - **Modbus Device Templates:** This folder contains a sub-folder for each device, which is imported from an Modbus device template. This device folder also contains a sub-folder with the data points specified in the template. Data points

can be added to the folder. Additionally suitable data objects can be created for the use on the device by selecting the **Use on Device** option.

- **LINX-XXX**: This is the device folder (see Section 4.2.1). For Modbus additional port sub-folders exist:
  - **Modbus Port RS-485**: This folder contains the remote Modbus data points of the Modbus RS-485 port, which are used on the device.
  - **Modbus Port TCP**: This folder contains the remote Modbus data points of the Modbus TCP port, which are used on the device.

#### 8.1.4 Network Port Folders

The Modbus network port folder on the device has the same structure of sub-folders as the other network port folders in Section 4.2.2. Currently only the **Datapoints** folder exists for the Modbus network ports.

#### 8.1.5 Modbus Properties

Apart from the common data point properties discussed in Section 4.2.4 the data points of the Modbus technology have additional properties:

- **Modbus Device Name**: This property defines the name of the Modbus slave device which contains the data point.
- **Modbus Device Address**: This property defines the address of the Modbus slave device which contains the Modbus data point.
- **Modbus IP Address**: This property is available for Modbus/TCP master only. It specifies the IP address of the Modbus slave device, which contains the Modbus data point.
- **Modbus Register Start Address**: This property defines the address of the Modbus register.
- **Modbus Register Type**: This property defines the register type of the data point. Also the function code, which specifies the register, is displayed. When the Modbus register type is changed from a read to a write register, also the direction of the data point is changed.
- **Modbus Data Type**: This property defines the representation of data in the slave. This is the data type the Modbus slave uses for the data point internally. This can for example be float, double, int16 or uint32.
- **Modbus Scaling (multiplier, exponent and offset)**: These properties define the scaling parameters for the data point. The value of the data point in the device is calculated as follows:

$$\text{Value} = (\text{ModbusValue} + \text{Offset}) \cdot \text{Multiplier} \cdot 10^{\text{Exponent}}$$

- **Modbus Swap 16 bit, Swap 32 bit and Swap 64 bit**: This information specifies, if the order of received Modbus data has to be changed. When Swap 16 bit is set, the two bytes of a 16 bit word are swapped, if Swap 32 is set, the two words of 32 bit are swapped, and if Swap 64 bit is set, the two 32 bit words of 64 bit long data are swapped. Also combinations are possible. This configuration is necessary because the Modbus slaves can store information in any byte order (the Modbus protocol only specifies, how 16 bit data is transferred).
- **Pollgroup**: This property is only available for input data points. It shows the poll group, the data point is connected to.

#### 8.1.6 Modbus Workflow

This section discusses the workflows for setting up a Modbus environment. Modbus does not provide a scan function and therefore the network has to be setup mostly offline. This can be eased by the use of templates. If no templates are available, the data points have to be set up

manually. If devices are online, an online test feature can help in identifying Modbus registers and their settings.

Figure 141 describes the workflow for setting up a Modbus network. For using Modbus the Modbus ports of the LOYTEC device and the Modbus devices have to be configured. The RS-485 Modbus port must get a Baud rate, the parity is fixed at none and the stop bits are configured to 2. The Modbus TCP port must get the TCP port number of the slave devices. The Modbus devices have to be configured according to the LOYTEC device's port configuration (see Section 8.2.1). When no device template is available for a Modbus device, this template can be created by manually configuring Modbus data points for the device (see Section 8.2.2). If the Modbus device is already online, data points can be created using the online test feature by scanning register values out of the device (see Section 8.2.3). In both cases the created data points can be exported as a device template. The exported device template can then be used to easily add additional Modbus devices with the same data point configuration (see Section 8.2.4). Also mixing the two methods is possible. When using the device templates also data points can be added manually. The configuration is then downloaded to the device and the device is rebooted (see Section 4.4.4).




Figure 141: Workflow for offline engineering.

## 8.2 Using the Configurator for Modbus

### 8.2.1 Modbus Management Functions

This section describes how the Modbus network management functions can be used. It describes adding and removing Modbus.

The **Modbus Management** dialog shown in Figure 142 shows the list of devices. Devices which have been imported from a template show the template name in the last column. For each device the address, the IP address (if available), the port and the number of data points available on that device is shown.

The Modbus Management dialog can also be used for the configuration of poll groups and for accessing the LOYTEC devices protocol analyzer.

#### To Start the Modbus Network Management Dialog

1. Connect to the device via FTP as described in section 4.4.1.

2. Select the Modbus dialog by clicking on the **Modbus** button



in the tool bar of the **Datapoints** tab. The Modbus Management dialog opens, showing the **Modbus Device Management** tab displayed in Figure 142.

Figure 142: Modbus management dialog.

### To Add a Modbus Device Manually

1. Fill in the **Device Address** and select the **Type** (either RS-485 or TCP) from the drop down box. If the device has more than one RS-485 port, select the appropriate **Port**.
2. A **Device Name** can be specified. If no device name is specified, the device name is created automatically. If more devices with the same properties have to be created using subsequent addresses, the number of devices can be specified in the input field under the **Device IP Address** field. If a number of TCP devices has to be created, subsequent IP addresses are configured. If the checkbox **Increase Device Address** is checked, also the Device Addresses (unit IDs) of the TCP devices are increased.

3. The **Device Address** specifies the address of the Modbus device ranging from 1 to 255. In case of a TCP device the device address specifies the unit ID. For a RS-485 device the device address has to be unique, TCP devices can have equal device addresses.

4. For TCP devices the **Device IP Address** has to be specified.
5. If the device shall be created without knowing the address of any physical device, leave the above address fields empty and select **Commission later**. This device can then be commissioned on the Web UI as described in the LOYTEC Device User Manual [1].
6. If the device is not able to read adjacent registers with one read command, activate the checkbox **Single Read**. If the device is not able to process writes of multiple registers in one command, activate the checkbox **Single Write**.
7. The setting **Multiple read limit** allows limiting the number of registers in a multi-read request. The default is disabled. Set this value, if a Modbus device has problems with the default multi-read. The same concept applies to limiting the read of multiple Coil and Discrete Input registers using the **Multiple bit read limit**.
8. The **Device timeout** specifies how long a device may take to reply. After this timeout, the device is assumed offline. When left empty it defaults to 800ms.
9. If the Configurator is connected to a LOYTEC device, the **Test** button can be used to verify the device settings by checking whether the respective Modbus device can be contacted.
10. The optional manufacturer details just represent **Manufacturer** name and **Model** name. This information is used to identify device templates.
11. Click on the **Create Device** button. This creates the Modbus device and adds it to the device list on the left hand side of the dialog.
12. When a device is selected the device information is displayed in the appropriate fields on the right hand side of the dialog. The information can be changed in the fields. Press the **Update Device** button to store the changes.
13. If a device has to be deleted select the device and press the **Remove Device** button.

#### To Add a Modbus Device Manually Using a Template without Creating Data Points

1. Enter a name for the Modbus device in the **Device Name** field. If no name is specified the name is created automatically from the name in the template file.
2. Fill in the **Device Address** and select the **Type** (either RS485 or TCP) from the drop down box. If TCP is selected also enter the **Device IP Address**. If more devices with the same properties have to be created using subsequent addresses, the number of devices can be specified in the input field under the **Device IP Address** field.



Number of Devices

3. Click on the **Create From Template** button. This opens the **Import Modbus Device Template** dialog shown in Figure 143.





Figure 143 Import Modbus Device Template dialog.

4. Press the  button and select a template file from the **Open** dialog.
5. After selecting the file, the device information is displayed.
6. Press **Import** for importing the template or **Cancel** for closing the dialog without any changes.
7. When a template is imported, a folder with the name of the device is created. Under this folder a **Datapoints** folder containing the data points from the template file is created.

---


**Tip:** *Data points can be added to the data points of the template by right-clicking in the data point list and selecting **New Datapoint**.*

---

### To Add a Modbus Device Manually Using a Template Creating Data Points

1. Enter a name for the Modbus device in the **Device Name** field. If no name is specified the name is created automatically from the name in the template file.
2. Fill in the **Device Address** and select the **Type** (either RS-485 or TCP) from the drop down box. If TCP is selected also enter the **Device IP Address**. If more devices with the same properties have to be created using subsequent addresses, the number of devices can be specified in the input field under the **Device IP Address** field.



3. Click on the **Create with DP** button. This opens the **Import Modbus Device Template** dialog shown in Figure 143.
4. Press the  button and select a template file from the **Open** dialog.
5. After selecting the file, the device information is displayed.
6. Press **Import** for importing the template or **Cancel** for closing the dialog without any changes.
7. When a template is imported, a folder with the name of the device is created. Under this folder a **Datapoints** folder containing the data points from the template file is created.
8. The created device is shown in the list together with the number of data points.

### To Remove a Modbus Device

1. Select the device which has to be removed, also multi-select is possible.
2. Press the **Remove Device** button. If the device already has data points, these data points have to be deleted before the remove can be performed.

### To Change the Properties of a Modbus Device

1. Select the device. This shows the device properties.

Device Properties

Type: RS-485

Device Name: ug5110\_1\_1\_44

Device Address: 44 [1 .. 255] / 0 bcast

Device IP Address: 0 . 0 . 0 . 0

Number of Devices:

☒ Increase Device Address

☐ Read Single Registers

Multiple read limit: [1 .. 124] / 0 disable

Manufacturer Details

Manufacturer: elmeasure

Model: ug5110

2. Update the properties which have to be changed.
3. Press the button **Update Device**.
4. When the device type is changed, it is verified that no device with the address exists on the appropriate port – on RS485 the device address has to be unique, on TCP the device IP address has to be unique.

## 8.2.2 Manual Configuration of Data Points

It is possible to manually configure Modbus data points. Manual configuration is done by specifying all information, the Modbus device manufacturer provides.

### To Manually Create an Modbus Data Point

1. Click on the Modbus port **Datapoints** folder.
2. Right-click in the data point list view and select **New Datapoint...** in the context menu.
3. This opens the **Create New Modbus Datapoint** dialog showing only the devices which are available on the appropriate port. This dialog is shown in Figure 144.



Figure 144: Create Modbus Datapoint dialog.

4. If the Modbus device which provides the data point is not in the list, it has to be created. In this case open the Modbus management dialog by clicking the **Edit Modbus Devices** button.
5. Create the device in the **Modbus Management** dialog and close the dialog.
6. Select the device which provides the Modbus data point.
7. Enter the General Data Point Properties. These are the **data point name**, which is automatically created when not specified, and the **Register Type**. The register type of the data point is provided in the Modbus device documentation. The drop down menu shows the Modbus register type, the direction (read and write) and the function code. The data point properties are entered in the presented section of the dialog.

8. Enter the properties of the data point. The register address is specified by the manufacturer. Select the **Modbus Data Type**. This type specifies how the manufacturer stores data in the Modbus device. The **Modbus Data Length** is automatically updated according to the data type. Offset, Multiplier and Exponent can be used for mapping purposes. The Value of the data point is calculated as follows:

$$\text{Value} = (\text{ModbusValue} + \text{Offset}) \cdot \text{Multiplier} \cdot 10^{\text{Exponent}}$$

Modbus does not specify any byte orders of the data stored in devices. For some devices it may be necessary to change the byte order. This is done by the check boxes **Swap 16 bit**, **Swap 32 bit** and **Swap 64 bit**. When Swap 16 bit is activated, the 2 byte of a word are swapped, when Swap 32 bit is activated, the 2 words of a 32 bit value are swapped and if Swap 64 bit is activated, the two 32 bit words of a 64 bit value are swapped. A preview of the byte order is shown under the check boxes. Select the **Data Point Type** of the data point (analog value, multi-state or binary) – only the types which are available for the register type-data type combination are shown.

Register Properties

Register Start Addr.  [0 .. 65535]

Modbus Data Type

Modbus Data Length

Val = (ModbusVal + Offset) \* Multiplier \* 10<sup>Exponent</sup>

Multiplier  [-32768 .. 32767]

Offset  [-32768 .. 32767]

Exponent  [-32768 .. 32767]

☐ Swap 16 bit

☐ Swap 32 bit

☐ Swap 64 bit

Swap Preview [12345678] -> [12345678]

Datapoint type

Custom Type  ...

Network Unit ☒ °C

Engineering Unit SI ☒ °C

Engineering Unit U.S. ☒ °F

Pollgroup

Number of datapoints  [0 .. 2000]

9. For an analog Modbus Master data point define a **Network Unit**. This is the unit of the register on the Modbus device. Optionally, define a unit representation of that remote register value for the metric (SI) and U.S. unit system.
10. Select a poll group for read data points from the **Pollgroup** drop down box. The drop down box is grayed out for write registers. Additional poll groups can be configured in the Modbus Management dialog.
11. In order to create a series of data points in one swoop, enter the **Number of data points** to be created.

Number of datapoints  [0 .. 2000]

12. Press the **Create** button to create the Modbus data points. The register indices will be adapted in ascending order. If data points should already exist at any of those indices, they are skipped.
13. After the point is created the dialog is not closed, so additional data points can be created.

---


**Tip:** *After creating a data point, the poll group can be changed in the data points property view. Also multi-select can be used in the data point property view.*

---


### 8.2.3 Data Point Creation with Online Test

The Modbus technology does not provide for an online scan for devices and data points like others do. Sometimes the data sheets from the vendors are inaccurate regarding register indices and swap information. If the Modbus device is already online, the online test function can be used to scan value information out of the device and create data points with that information. The online test function can also be used to test existing data points.

### To Create Data Points from Online Test


1. Connect to the device.
2. Open the **Create Modbus Datapoint** dialog as described in Section 8.2.2.
3. In the **Modbus Device List** select the Modbus device, which is online and shall be read. A Modbus device with a pre-configured address fills in the **Address (IP-Address** if on Modbus TCP) and **Port** fields. For a commission-later device, the current address information can be retrieved from the connected LOYTEC device by clicking the read slave address button .

Online Register Test

Address  IP-Address  Port  


4. Enter a data point name and select the **Modbus Register Type** in the **General Datapoint Properties** group box.
5. In the **Register Properties** group box select the **Modbus Data Type**, scaling and swap setting as assumed.
6. In the **Online Register Test** area enter the **Read Start Address** and **Number of Modbus Registers** to read. Note, that a Modbus register is always 2 Bytes long.
7. Click the **Read register(s)** button.
8. The data read from the Modbus device is displayed in the **Read raw data** box as hex bytes and in the **Value list** box as interpreted data.

Online Register Test

Address  IP-Address  Port  

Read start address  [0 .. 65535]

Number of Modbus Registers  [1 .. 125]



☐ Read continuously Read cycle  [1 .. 60]

Read raw data

0000 000B 0016 0021 002C 0037 0042 004D 0000 .....!.,.7.B.M..

Value List

	00	01	02	03	04	05	06	07	08	09
00000	11	22	33	44	55	66	77	0		

9. Adapt the value interpretation in the **Register Properties** area until the expected result appears. The results are immediately visible.
10. You may enable the **Read continuously** option, which periodically reads the registers and displays them in the value list. You may use this option to monitor register values and particular registers of interest.
11. Select the register values in the Value list. You may also use multi-select.


Value List

	00	01	02	03	04	05	06	07	08	09
00000	11	22	33	44	55	66	77	0		

12. Click **Create Data Point**. This creates data points that will provide the selected register values.

### To Check Data Points Using Online Test

1. Select one ore more existing Modbus Master data points.
2. Right-click and choose **Test Selected Data Points** from the context menu.
3. The **Data Point Values** window opens and shows the read progress for the selected data points. For each completed read a status result and a value is shown.



## 8.2.4 Importing via Device Templates

For some Modbus devices special templates are available which specify all available data points of a Modbus device as well as the device properties. Such templates can be imported into the configuration.

### To import a Modbus Device Template

1. Right click on the Folder **Modbus Device Templates** and select **Import device template** from the context menu.
2. This opens the **Import Modbus Device Template** dialog shown in Figure 145.





Figure 145 Import Device Template dialog.


3. Press the  button and select a template file from the **Open** dialog.
4. After selecting the file, the device information is displayed.
5. Press **Import** for importing the template or **Cancel** for closing the dialog without any changes.
6. When a template is imported, a folder with the name of the device is created. Under this folder a **Datapoints** folder containing the data points from the template file is created.

*Tip:* Data points can be added to the data points of the template by right clicking in the data point list and selecting **New Datapoint**.

*Importing a device template from the folder list does not create a device instance. Device*

*instances can only be created using the import in the Network Management Dialog. In this dialog also the device instances can also be created with their data points.*

### To Use Imported Data Points On the Device

1. Go to the **Datapoints** folder of the device of the Modbus Templates.
2. Select the desired data points, also multi-select is possible.
3. Either press on the **Use on Device** button  or right-click and select **Use on Device**. This opens the **Choose Modbus Device Instance** dialog.




Figure 146: Choose Modbus Device Instance dialog.

4. The device list displays all devices which have the same Manufacturer, and the same Model Name as the template. If no device instance matches the device template, create one by entering the Modbus management dialog. The dialog can be entered by pressing the **Edit Modbus Devices** button. In the management dialog, the device instance can be either created manually (take care of entering the correct manufacturer and model) or by simply importing the template again.
5. Select one or more device instances from the list and press the **Use On Device** button. This creates for each selected data point and each selected device one data point in the Modbus Port's data point list.

## 8.2.5 Creating Device Templates

Modbus device templates can be created from a data point configuration. In fact, it is only possible to create a device template using an existing device or an existing device template with data points. This device and its data points can either be configured manually or also imported from a device template itself.

A Modbus device template contains the following configuration items describing a Modbus device:

- Modbus device settings,
- Modbus data points,
- Folders used to organize Modbus data points on a device,
- Structure types, multi-state maps, historic filters used by Modbus data points,

- Pollgroup definitions used by Modbus data points.

### To Create a Modbus Device Template Using Devices

1. Select the Modbus dialog by clicking on the **Modbus** button



in the tool bar of the **Datapoints** tab. This opens the **Network Management** dialog opens as described in Section 8.2.1.

2. The device list shows all devices of the current configuration. Select the device you want to export.

Device Name	Device Address	IP Address	Port	Datapoints	Template
ug5110_1_5_5	5		RS-485	3	
TestDevice_14_14	14		RS-485	0	

3. Press the **Export Device Templ.** button. This opens the **Export Modbus Device Template** dialog shown in Figure 147. The list on the left side of the dialog shows the names of the data points which are exported to the template.




Figure 147 Export Modbus Device Template dialog.

4. Press the **...** button and select a template file from the **Save** dialog.
5. Enter the **Creator**, **Company Name** and **Version** for the template. This information is stored in the template file, when importing the template file the information is displayed after selecting the file.
6. Press the **Export** button.

### To Create a Modbus Device Template File Using a Device Template

1. Right-click on the folder of the device template that has to be exported or its data point folder and select **Export Device Template...** from the context menu.
2. This opens the **Export Modbus Device Template** dialog as shown in Figure 147. Proceed as described above.

## 8.2.6 Poll Groups

In a Modbus network, the master has to poll the slave devices. Input data points are therefore attached to a poll group. If nothing else is specified, the default poll group is used for input data points. The default poll group has a poll cycle of 60 seconds.

Two different types of poll groups can be specified:

- Time-based: The poll group is triggered on a time base. This means that after a specific time – the poll cycle – the poll group is processed.

- Trigger-based: The poll group is triggered on a special trigger data point. As soon as the trigger condition is met, the poll group is processed.

---

**Tip:** *The poll group a data point is attached to can be changed in the properties view of the data points. The poll group can also be changed for multiple data points using multi-select.*

---

### To Create a Time-Based Poll Group

1. Select the Modbus dialog by clicking on the **Modbus** button



in the tool bar of the **Datapoints** tab. This opens the **Modbus Management** dialog.

2. Open the **Pollgroups** tab. This shows the dialog displayed in Figure 148.




Figure 148: Pollgroup Management dialog.

3. The default poll group is selected and its properties are displayed. Enter the name of the new poll group and enter the poll cycle in seconds. Values in multiples of '0.1' are allowed for fast polling. Make sure that under **Pollgroup Mode** Time-based is selected.
4. Press the **Save** button to store the poll group and continue editing.
5. If a poll group needs to be updated or deleted, select the poll group edit the data and press the **Update Selected** or **Delete Selected** button.
6. Press the **Close** button to finish editing. When the poll groups have not been saved, a dialog asks whether the changes have to be saved or not.

### To Create a Trigger-Based Modbus Poll Group

1. Select the Modbus dialog by clicking on the **Modbus** button



in the tool bar of the **Datapoints** tab. This opens the **Modbus Management** dialog.

2. In the **Modbus Management** dialog, open the **Pollgroups** tab. This displays the poll groups management tab displayed in Figure 148.
3. Enter a new poll group name and select **Trigger-based**.
4. Create the poll group by pressing the **Create New** button.
5. Select the new poll group. This enables the **Add...** and **Remove** buttons from the triggers.
6. Press the **Add...** button and select a trigger data point. This can for example be a binary user register.
7. The selected trigger data point appears in the trigger list as shown:

Triggers		
Datapoint	Type	Condition
Triggerdatapoint_Read	Value Update	-

8. Select the trigger from the list and check the desired trigger conditions.

Conditions	
Enabled Conditions	
<input type="checkbox"/>	True (!= 0)
<input type="checkbox"/>	False (== 0)
<input type="checkbox"/>	Invalid
<input type="checkbox"/>	Offline

9. The trigger conditions are then displayed in the trigger list.

Triggers		
Datapoint	Type	Condition
Triggerdatapoint_Read	Value Update	True (!= 0), False (== 0)

10. Press the **Save** button to store the changes in the poll groups.


## 8.2.7 Create Modbus Slave Data Points

The Modbus interface of the device can also be configured to be in Modbus slave mode. In this mode, Modbus slave data points can be created. These data points can represent any of the supported Modbus register types. They are locally available as registers to other Modbus masters for reading and writing. The Modbus slave registers appear like user registers; they are value data points. The register types and indices are defined when creating the data points. They must, however, lie within the register index range, which has been set in the system settings for the Modbus port (see Section 8.1.1).




### To Create Modbus Slave Registers


1. Select the **Datapoints** folder of the Modbus port.
2. Right-click in the data point list view and select **New Datapoint...** in the context menu.
3. This opens the **Create New Modbus Datapoint** dialog. In the Modbus device list there is only the **SlaveDevice** entry. It cannot be de-selected.




4. Enter the data point name and select the desired **Modbus Register Type**.
5. In the **Register Properties** group box enter the register start address, the Modbus data type and optionally scaling and swap settings.
6. Select the data point class, which shall be created and the number of data points below.



7. For analog Modbus Slave registers you may define a metric (SI) and U.S. unit. Depending on the chosen unit system, the Modbus Slave register will change its representation (i.e., its value) on the network.



8. Click on the button **Create data point**.
9. The number of Modbus slave register data points is created. The register indices are incremented for each created register. If a register index is already in use, the data point for this index is skipped. Created data points are reported with a green check mark.




## 8.2.8 Structured Modbus Data Points

Modbus registers are always multiples of two Bytes. Modbus devices may encode two Byte fields or bit fields into the registers. For accessing byte or bit-fields, data point structures can be used that provide single data points for the respective sub-fields (see Section 3.1.11). The Configurator provides pre-defined types for byte and bit-fields in the Modbus scope: `modbus_state16` and `modbus_byte2`.

### To Create a Structured Modbus Register

1. Create the register as described in Sections 8.2.2 and 8.2.7 and select the data point type **User**.





- **Payload:** Payload in hexadecimal numbers (this column cannot be used for sorting).

Modbus Device Management

Pollgroups

Protocol Analyzer RS-485

Protocol Analyzer TCP

Start Protocol

Stop Protocol

Load From Device

Save

Clear

Seq.	Timestamp	Frame Type	Dir.	Trans ID	Prot ID	Unit ID	Length	Payload
7312	2009-05-06 17:48:14.094	TCP	SND	8740	0	1	12	22 24 00 00 00 06 01 03 00 00 00 0C
7313	2009-05-06 17:48:14.116	TCP	RCV	8740	0	1	33	22 24 00 00 00 18 01 03 18 40 D2 17 80 00 00 00 00 40 D2
7314	2009-05-06 17:48:14.120	TCP	SND	8741	0	1	12	22 25 00 00 00 06 01 03 00 10 00 04
7315	2009-05-06 17:48:14.138	TCP	RCV	8741	0	1	17	22 25 00 00 00 0B 01 03 08 00 00 00 00 00 00 00
7316	2009-05-06 17:48:14.142	TCP	SND	8742	0	1	12	22 26 00 00 00 06 01 03 00 64 00 08
7317	2009-05-06 17:48:14.159	TCP	RCV	8742	0	1	9	22 26 00 00 00 03 01 83 02
7318	2009-05-06 17:48:14.160	TCP	SND	8743	0	1	12	22 27 00 00 00 06 01 03 00 70 00 0C

Figure 150: Typical protocol analyzer output for Modbus TCP port.

Figure 151 shows a typical protocol analyzer output for the Modbus RS-485 port. It shows the following information for RS-485:

- **Seq.:** sequence number, which is automatically created in the device. This number is unique for one port.
- **Timestamp:** transmission time.
- **Frame Type:** RTU, ASCII or Damaged when something happened with the frame.
- **Dir.:** direction. Either SND (send) or RCV (receive)
- **Addr.:** Slave address
- **CRC:** CRC of the transmission
- **Length:** Payload length of the data frame
- **Payload:** Payload in hexadecimal numbers (this column cannot be used for sorting)

Modbus Device Management	Pollgroups	Protocol Analyzer RS-485	Protocol Analyzer TCP
<input type="button" value="Start Protocol"/>	<input type="button" value="Stop Protocol"/>	<input type="button" value="Load From Device"/>	<input type="button" value="Save"/> <input type="button" value="Clear"/>

Seq.	Timestamp	Frame Type	Dir.	Addr.	CRC	Length	Payload
4	2009-05-07 16:33:17.246	RTU	SND	1	17871	7	01 03 00 00 00 0C 45
5	2009-05-07 16:33:17.285	RTU	RCV	1	27892	29	01 03 18 00
6	2009-05-07 16:33:27.245	RTU	SND	1	17871	7	01 03 00 00 00 0C 45
7	2009-05-07 16:33:27.283	RTU	RCV	1	27892	29	01 03 18 00
8	2009-05-07 16:33:37.245	RTU	SND	1	17871	7	01 03 00 00 00 0C 45
9	2009-05-07 16:33:37.283	RTU	RCV	1	27892	29	01 03 18 00
10	2009-05-07 16:33:47.245	RTU	SND	1	17871	7	01 03 00 00 00 0C 45
11	2009-05-07 16:33:47.291	RTU	RCV	1	27892	29	01 03 18 00
12	2009-05-07 16:33:57.245	RTU	SND	1	17871	7	01 03 00 00 00 0C 45
13	2009-05-07 16:33:57.288	RTU	RCV	1	27892	29	01 03 18 00
14	2009-05-07 16:34:07.251	RTU	SND	1	17871	7	01 03 00 00 00 0C 45

Figure 151: Typical protocol analyzer output for Modbus RS-485 port.

The frame type **Damaged** indicates that either a bad packet (malformed frame, CRC error) was received or that no response packet was received where it is expected.

# 9 KNX

## 9.1 Configurator

This section describes how to use the Configurator software for the management of KNX data points. For further information on the Configurator software refer to Chapter 4.

### 9.1.1 Activating KNX Configuration

Before a new KNX configuration can be managed, at least one KNX interface must be enabled. The project settings are described in detail in Section 4.3.

#### To Activate the KNX Configuration

1. Open the project settings dialog.
2. In the **System Settings** tab enable the KNX for Port 4 and/or for the Ethernet port, as shown in Figure 152.
3. Press the **OK** button.




Figure 152: Enabling KNX/TP1 and KNXnet/IP in the Project Settings Dialog.

---

**Important:** *If the KNX Port is deactivated via the checkbox or a firmware or model version is chosen, which does not support KNX, the complete KNX configuration is deleted. In this case a dialog is displayed, which has to be confirmed.*

---

If the configurator is connected to a device, the **Download** button can be used to download the device configuration.

### 9.1.2 KNX Project Settings

The project settings dialog provides a **KNX** tab for interface specific KNX settings. The interface dialog, as shown in Figure 153 allows selecting a KNX interface for editing in the left-hand tree view. The right-hand pane allows modifying the following properties of the selected KNX interface:

- **Group addressing mode:** The group addressing mode defines how group addresses are displayed numerically. This setting is a display property and has no influence on the KNX communication itself.
  - **Free:** The addresses are displayed as integers, e.g. 12345.
  - **Two-Level:** The addresses are displayed as main groups (5 bit) and group addresses (11 bit), e.g. 6/57.
  - **Three-Level:** The addresses are displayed as main groups (5 bit), middle groups (3 bit) and group addresses (8 bit), e.g. 6/0/57.
- **Unique project ID:** This field contains the ETS project ID from the last import, for example P-053C. This field is used to avoid importing two different projects into one configuration.
- **Physical address:** This field configures the physical (individual) address of the device, e.g. 1.2.3. It needs to be unique in the KNX network and needs to match the line to which the device is connected to.

The following settings are available for the KNXnet/IP interface only:

- **Multicast address:** This IPv4 multicast address is used for sending and receiving KNX. The default value is **224.0.23.12**.
- **Multicast port:** This UDP port number is used for sending and receiving KNX frames. The default value is **3671**. It is recommended to keep the default value, as some KNXnet/IP devices cannot operate on alternate ports.
- **Multicast TTL:** This is the Time to live value for UDP multicast packets. The default value is **16**.

The following fields are informational only and represent the state of the latest KNX database import.

- **Project name:** This field contains the ETS project name.
- **Project number:** This field contains the ETS project number.
- **Contract number:** This field contains the ETS contract number.
- **Last modification:** This field contains the modification time of the ETS project.
- **Start date:** This field contains the start date of the ETS project.
- **Project Id:** This field contains the imported project Id.
- **Comment:** This field contains the text comment of the ETS project.

- **Completion status:** This field contains the completion status of the ETS project.




Figure 153: KNX Project Settings

- **Group import settings:** This setting allows modifying the mapping of linked groups:
  - **Create one communication object for each group:** This setting will create one communication object for each imported group.
  - **Create one communication object for each send group:** This setting will create one communication object for each send group and attach linked group addresses to this communication object.

The data point naming rules tab (see Figure 154) allows specifying how data point names are automatically derived from imported KNX communication objects and groups. The preview shows how names would look like, when the check marks are modified. Note, that changing the name components does not change already created KNX data points; this setting affects only new data points created by an import.

- **Separator:** This setting defines a separator character, which is inserted between the data point name components. As a default no separator is configured.




Figure 154: KNX Data Point Naming Rules

### 9.1.3 Data Point Manager for KNX

The Configurator uses a central concept to manage data points. The data point manager is used to select, create, edit and delete data points. The dialog is divided into three sections:

- The folder list (Figure 155),
- The data point list (Figure 156),
- And a property view.




Figure 155: Data Point Manager Dialog with KNX import and device folders.

Local datapoints - KNXnet IP/Datapoints/7\_Input Properties

Datapoint Name	No.	OPC	PLC	Param	Direction		Type	Use	Comm Object	W-Flag	T-Flag	ID
BinaryCOV_Read	2	<input checked="" type="checkbox"/>	<input type="checkbox"/>		In		KNX/DPT_Switch	1	17	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1514
PollOnStartup_Read	1	<input checked="" type="checkbox"/>	<input type="checkbox"/>		In		KNX/DPT_Switch	0	15	<input checked="" type="checkbox"/>	<input type="checkbox"/>	150D
ReceiveTimeout_Read	3	<input checked="" type="checkbox"/>	<input type="checkbox"/>		In		KNX/DPT_Switch	0	41	<input checked="" type="checkbox"/>	<input type="checkbox"/>	36EA

Figure 156: Data Point Manager Dialog with KNX Data Point List.

### 9.1.4 Folder List

At the left is a list of folders which is used to sort the available data objects by their category. There are a number of predefined KNX folders available. All other folders are described in section 4.2.1:

- **KNX TP1 File Import:** This folder contains the data points from the ETS database import for the KNX/TP1 interface.
- **KNXnet IP File Import:** This folder contains the data points from the ETS database import for the KNXnet/IP interface.
- **LINX-XXX:** This is the device folder (see Section 4.2.1). For KNX, additional port folders exist:
  - **KNX TP1:** This folder contains the data points for the KNX TP1 interface.
  - **KNXnet IP:** This folder contains the data points for the KNXnet/IP interface.

### 9.1.5 Network Port Folders

The KNX network port folder on the device has the same structure of sub-folders as the other network port folders in Section 4.2.2. Currently only the **Datapoints** folder exists for the KNX network port.

### 9.1.6 KNX Properties

Apart from the common data point properties discussed in Section 4.2.4 the data points of the KNX technology have additional properties. These properties are shared among all data points which are connected to the same KNX communication object.

- **Data Point Type:** This property allows setting a data type for the data point. The configurator restricts changes to data point types of the same bit length. The configurator data point repository contains all common KNX data points types (DPTs). For analog objects the DPT defines the fixed network unit.
- **Communication flag:** This flag acts as a communication master switch for the communication object. If it is cleared, the communication object does neither receive nor transmit KNX frames. This flag should be typically kept **on**.
- **Read flag:** The read flag enables communication objects to respond to network read requests. If the flag is cleared, read requests are ignored. Only one object in a group should have the read flag set. This flag is usually set to **off**.
- **Transmit flag:** The transmit flag enables sending group writes to the KNX network when the data point value is written by the application. This flag should be **on** for communication objects which have at least one write data point. The configurator automatically sets this flag when a write data point is created. If the transmit flag is cleared and write data points exist for this communication object, the configurator asks for confirmation before removing write data points.
- **Update flag:** The update flag determines how the communication object reacts on receiving read responses. If the flag is **off**, the communication object ignores read responses initiated by other communication objects. If the flag is **on**, the communication object treats all read responses as group writes and updates the data point properly. This flag is usually set to **off**.
- **Write flag:** The write flag enables receiving group writes from the KNX network. This flag should be **on** for communication objects which have at least one read data point. The configurator automatically sets this flag when a read data point is created. If the write flag is cleared and read data points exist for this communication object, the configurator asks for confirmation before removing read data points.
- **KNX transmission priority:** This property allows selecting one of the KNX transmission priorities for the data point, **low**, **high** and **alert**. Typically, this property is set to **low**.
- **KNX send group address:** The send group address is the group address used for sending group writes. It is also automatically used as a receiving address. As the group addresses are managed by the database import, they should not be modified manually. The KNX project settings determine the format of this string (free, two-level or three-level).
- **KNX receive group addresses:** This is a semicolon separated list of additional receive addresses. As the group addresses are managed by the database import, they should not be modified manually. The KNX project settings determine the format of this string (free, two-level or three-level).
- **KNX communication object ID:** The communication object ID is used for identifying a communication object. As this ID is managed internally, it should not be modified manually.

---

## 9.2 KNX Workflow

This section discusses the workflows for adding the device to an existing KNX network. Figure 157 shows the workflow from project start to a working device configuration. The following sections will describe this process in detail.






Figure 157: Workflow for KNX projects.

### 9.2.1 Selecting a KNX Interface

This section describes how the device can be connected to a KNX network and how to decide which media type is to be used:

1. If the KNX network consists of a single TP1 line, the device is simply connected to the line via the LKNX-300.
2. If the KNX network consists of several TP1 lines and couplers, there are two options:
  - a. If the device shall use group addresses that are mainly used within a line, add the device to this line. This will reduce the traffic over line couplers.
  - b. If the device shall communicate with group addresses spread over several lines, add the device to the main line or to the area line.
3. If the KNX network contains a TP1/IP router and/or has a KNXnet/IP backbone, use the KNXnet/IP interface.

### 9.2.2 Reserve a Physical Address

After selecting the line, a free physical address on this line must be reserved.

---

*Note:* To make sure that the address is reserved in ETS4, you can add an arbitrary device to the line, rename it to “Reserved for LINX” and use the assigned address for the KNX interface.

---

Use this address in the interface configuration dialog (see Section 9.1.2).

### 9.2.3 Coupler Configuration

If the KNX network contains couplers, it must be made sure that the device receives all group telegrams contained in the device configuration. If the network consists of a single line, this section can be ignored.

To configure the couplers to forward all groups to the device, the following options are available:

1. Enable the switch **Pass through line couplers** option in the ETS4 group address or group range options, as shown in Figure 158. If this switch is set, the couplers will forward the group addresses towards the main line.
2. Set the “group telegrams” coupler parameters to **route** instead of **filter** of the coupler. As this will forward all group traffic, this is not the recommended method for larger networks.
3. Drag & drop a group address or an address range on the line which contains the device. This will add manual filter rules to the affected couplers.

---

*Note:* Only configure the group addresses or address ranges used by the device. Forwarding all group telegrams to the main line will only work well for small installations due to the backbone traffic. The coupler filter table can be previewed in the ETS4 with the coupler context menu “Preview filter table ...”

---




Figure 158: Setting the Pass through Line Coupler option.

## 9.2.4 Use KNX Data Types in IEC61131

KNX data points can be used in an IEC61131 program, just like other data points. With a L-LOGICAD version as of 4.2.4, all necessary KNX data types are pre-installed. They can be found under ‘Standard\_Libs/KNX\_Types’.

To use KNX data points in the IEC61131 program with an older L-LOGICAD installation, the KNX data types have to be exported as structured text and have to be imported into a logi.CAD library.

To export KNX types, select **Manage Structured Types** from the Configurator **Tools** menu. Select the export button, as shown in Figure 159.




Figure 159: Export KNX types

In the **Export Types to Disk** dialog, as shown in Figure 160,

1. clear the filter and select the KNX category,
2. copy all KNX data types to the export list
3. select an export file (\*.ST) and
4. click the save button.




Figure 160: Exporting KNX types as Structured Text.

5. In logi.CAD, create a new library KnxTypes with the context menu **New** → **Library**.
6. Select **Export/Import** → **Start ST-Import** from the context menu of the newly created library, as shown in Figure 161.




Figure 161: Importing KNX types in logi.CAD.

7. Check that there have not been any warnings or errors during the import.

## 9.2.5 Setup a Configurator Project

After creating a new project, at least one KNX interface needs to be enabled. Enable the KNX interfaces in the project configuration, as shown in Section 9.1.1. To make sure that the

system settings are written to the device, connect to the device and download the system settings from the system settings editor.

Use the Web interface to verify that the device has the desired KNX interfaces enabled, as shown in Chapter “KNX” of the LOYTEC Device User Manual [1].

### 9.2.6 ETS Project Export

When the KNX network has been installed, the database can be exported to a .knxproj file. The export function can be found in the **Projects** tab of the ETS4 main screen, as shown in Figure 162.




Figure 162: Exporting the ETS project

The KNX project then can be saved to a .knxproj file.

The project export has to be repeated if

- Group numbers have changed or
- New groups should be available to the device.

### 9.2.7 Configurator Project Import

For each enabled KNX interface, there exists a KNX import folder in the data point tree view. The folders are named “KNX TP1 File Import” and “KNXnet IP File Import” respectively.

To import a KNX project file, the context menu entry **Import File** of the import folder needs to be selected. This opens a file requester for selecting the .knxproj-File.

After selecting the file, the configuration merge dialog is displayed, as shown in Figure 163. This dialog allows the initial group address import and is also used to merge configuration changes when the ETS project has evolved.




Figure 163: KNX import dialog

The top part of the dialog shows the project description. For the first import, you need to enter the reserved physical address for this device.

The main part of the dialog is the merge editor which compares the current device configuration with the KNX project configuration. The table displays the following columns:

- **Diff:** This column displays whether the group has been added (**New**), is unchanged (**Unchanged**), has been changed (**Changed**), or has been removed (**Removed**) in the KNX project.
- **Resolution:** This column allows to select different actions for each change:
  - **Create:** This action is the default for groups that exist in the KNX project file, but not yet in the device configuration.
  - **Delete:** This action is the default action for groups that exist in the configuration, but not in the KNX project file. Deleting a data point being in use is not possible, as this would break the PLC program or the gateway configuration.
  - **Update:** This action changes the properties of the group, e.g. if the name has changed.
  - **Force:** This action forces the configurator to the KNX database file as the authoritative data source, even if this will break the PLC program or gateway configuration. It can be used to forcibly delete data points.
  - **Ignore:** This action will ignore the change.
- **New name:** This is the group name in the imported file.
- **New type:** This is the data point type in the imported file.
- **New address:** This is the group address in the imported file.

- **Current name:** This is the group name in the current configuration.
- **Current type:** This is the data point type in the current configuration.
- **Current address:** This is the group address in the current configuration.

Additional controls:

- The filter field above the merge editor allows a substring search to select a subset of the imported groups. The filter can be disabled with the clear filter button.
- The checkbox **Show differences only** allows displaying only those groups which have changes.
- The action buttons on the right top allow switching the Resolution state of the selected data points.
- If the **Propagate changes to device** checkbox is enabled (default), changes will not only be updated in the import folder, but also propagated to existing data points on the device.

The KNX project import presents all groups which are used in the KNX project by at least one device. The default data point names are assembled by the group names, separated by underscores.

To import or merge the KNX project configuration, press the **Merge** button. To leave the device configuration unchanged, press **Cancel**.

### 9.2.8 Creating Data Points

After importing the KNX project file, the import folder contains a list of possible data points. The data point properties can be edited in the import folder. Especially, the data type and communication flags can be selected for each group address. Only data types matching the configured byte length of the group address can be selected. The import folder will typically look like Figure 164.

To use the data points on the device, multi-select the desired data points and select **Use on Device** from the context menu.

When **Use on Device** is selected on an imported data point, the value of the communication flags decide which data points are created:

- If the **Write flag** is enabled, an input data point will be created.
- If the **Transmit flag** is enabled, an output data point will be created.
- If both, the **Write flag** and the **Transmit flag** are enabled, a value data point will be created.

Datapoint Name	No.	OPC	PLC	Param	Direction	Type	Use	Comm Object	W-Flag	T-Flag	ID
Datapoint Name 001	1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/1 bit	0	1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	19DD
Datapoint Name 002	2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_Switch	0	2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19DE
Datapoint Name 003	3	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_Bool	0	3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19DF
Datapoint Name 004	4	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_Enable	0	4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19E0
Datapoint Name 005	5	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_Ramp	0	5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19E1
Datapoint Name 006	6	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_Alarm	0	6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19E2
Datapoint Name 007	7	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_BinaryValue	0	7	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19E3
Datapoint Name 008	8	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_Step	0	8	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19E4
Datapoint Name 009	9	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_UpDown	0	9	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19E5
Datapoint Name 010	10	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_OpenClose	0	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19E6
Datapoint Name 011	11	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_Start	0	11	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19E7
Datapoint Name 012	12	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_State	0	12	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19E8
Datapoint Name 013	13	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_Invert	0	13	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19E9
Datapoint Name 014	14	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_Reset	0	14	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19EA
Datapoint Name 015	15	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_Ack	0	15	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19EB
Datapoint Name 016	16	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_Trigger	0	16	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19EC
Datapoint Name 017	17	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Value		KNX/DPT_Occupancy	0	17	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	19ED

Figure 164: Imported KNX data points

### 9.2.9 Editing KNX Data Points

Once KNX data points have been created, they can be edited using the property editor, as described in Section 9.1.6.

Now it is possible to use Alarming, Scheduling and Trending on the KNX data points. They can be exposed to OPC, and can be used as parameters and IEC 61131 variables. Further they can be used in connections, global connections and math objects.

The KNX data point properties are synchronized between the read and write properties, so for example changing the data type of the read data point will also change the data type of the write data point.

*Note:*

*Because the PLC program and the OPC tags are derived from the data point name, it is advisable to keep the data point name constant. If the KNX group names are expected to be changed, it is a good idea to create data point links in the Favorites folder and use the links in the PLC program or for the OPC server. Then the KNX project can be merged without having to take care of the group names.*

### 9.2.10 Alarming, Scheduling and Trending

KNX data points can be alarmed by the generic alarm server. The configuration of alarming is described in Section 4.8.

KNX data points can be scheduled by the generic scheduler. For devices with CEA709 interfaces, the CEA709 scheduler is used to schedule KNX networks. This works also when the CEA709 node is not commissioned. For BACnet devices, the KNX data points can be also scheduled by a BACnet scheduler. The configuration of scheduling is described in Section 4.7.

KNX data points can be trended with the generic trends which are described in Section 4.9. They can also be configured with historic filters as described in Section 4.12.

# 10 SMI

## 10.1 Configurator

### 10.1.1 Activating SMI

Before SMI devices can be added to a data point configuration, the SMI interface in the project settings must be enabled (LSMI-800 on EXT or LSMI-804 on USB). The project settings are described in detail in Section 4.3. LOYTEC device models with a dedicated SMI port have this enabled as a default.

#### To Activate SMI in the Configuration

1. Open the project settings dialog.
2. In the **System Settings** tab enable the SMI protocol on the EXT port, as shown in Figure 165. When using an LSMI-804 activate the SMI protocol on the USB port.
3. Press the **OK** button.




Figure 165: Enabling SMI in the Project Settings Dialog.

---

**Important:** *If the SMI protocol is deactivated via the checkbox or a firmware or model version is chosen, which does not support SMI, the entire SMI configuration is deleted. In this case a dialog is displayed, which has to be confirmed.*

---

If the Configurator is connected to a device, the **Download** button can be used to download the device configuration.

### 10.1.2 Data Point Manager for SMI

The Configurator uses a central concept to manage data points. The data point manager is used to select, create, edit and delete data points. The dialog is divided into three sections:



- The folder list (Figure 166),
- The data point list (Figure 167),
- And a property view.





Figure 166: Data Point Manager with SMI device folders.

LINX-151 ▶ SMI ▶ motor1

Datapoint Name	No.	OPC	Param	PLC in	PLC out	Direction	Description	Type
Position	1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out	Set point for sunbli...	SMI/Position
PositionFB	2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	Current position of...	SMI/PositionFB
rawPosFb	3	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	Raw position feed...	SMI/Raw Position
MovingDir	4	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	Current moving dir...	SMI/Moving direction
upHyst	5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out	Upper slat hystere...	SMI/Raw Position
downHyst	6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out	Lower slat hysteres...	SMI/Raw Position
turnaround	7	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out	Required steps for ...	SMI/Raw Position
mechSlippage	8	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out	Mechanical slippa...	SMI/Raw Position
minMechAngle	9	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out	min. mechanically ...	SMI/Rotation_Parameter
maxMechAngle	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out	max. mechanically ...	SMI/Rotation_Parameter
minAdjustAngle	11	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out	min adjustable sun...	SMI/Rotation_Parameter
maxAdjustAngle	12	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out	max adjustable su...	SMI/Rotation_Parameter

Figure 167: Data Point Manager Dialog with SMI Data Point List.

### 10.1.3 Port Folder

The SMI port folder represents the SMI interface in the Configurator. In the SMI port folder, one folder per SMI device is created, which contains the data points for that SMI device. SMI device folders are identified by the SMI device icon . SMI device folders can be deleted, renamed and organized in sub-folders.

The data points in an SMI device folder cannot be deleted or renamed. Some of their properties such as OPC exposure, PLC in/out, parameter can be modified. The data points per SMI device are:

- Position (structure): This structured data point has the members function, setting, rotation, which are compatible with the SNVT\_setting definition. When writing this data point the sunblind is commanded to move to the desired position/rotation (see Table 14). The SMI device needs to be calibrated for this to work.
- PositionFB (structure): This structured data point reflects the feedback of the sunblind. Its sub-data point 'pos' is a SNVT\_setting structure which represents the current position of the sunblind. The sub-data point 'error\_code' is a binary data

point that reflects an error of that device. The SMI device needs to be calibrated for this to work.

- **rawPosFb (analog):** This is the analog feedback value of the sunblind in raw motor steps.
- **MovingDir (multistate):** This feedback data point specifies the current moving direction of the sunblind (up, down, stopped).
- **upHyst, downHyst, turnaround, mechSlippage, minMechAngle, maxMechAngle, minAdjustAngle, maxAdjustAngle (analog):** These are parameter data points that contain the calibration data for the sunblind. They are filled in when calibrating the sunblind device on the Web interface. The parameters are intended to be distributed by the LWEB-900 parameter editor for all similar sunblinds in the project.

Function	Setting position $x$	Rotation slat angle $\alpha$	SMI behavior
SET_OFF	d/c	d/c	Sunblind moves up till the end position.
SET_ON	d/c	d/c	Sunblind moves down till the end position.
SET_DOWN	0%	0°	Sunblind moves down till the end position (same as SET_ON).
	0%	0° < $\alpha$ <= 90°	Sunblind rotates the slats downwards by a relative angle of $\alpha$ .
	0 < $x$ <= 100%	0°	Moves the sunblind down by $x$ percent to a new sunblind position. At the new sunblind position, the slat angle is the same as before.
	0 < $x$ <= 100%	0° < $\alpha$ <= 90°	Moves the sunblind moves down by $x$ percent. Then rotates the slats downwards by $\alpha$ degrees.
SET_UP	0%	0°	Sunblind moves up to the position specified in the actuator device (same as SET_OFF).
	0%	0° < $\alpha$ <= 90°	Sunblind rotates the slats upwards by a relative angle of $\alpha$
	0 < $x$ <= 100%	0°	Moves the sunblind up by $x$ percent to a new sunblind position. At the new position the slat angle is the same as before.
	0 < $x$ <= 100%	0° < $\alpha$ <= 90°	Moves the sunblind up by $x$ percent to a new sunblind position. Then rotates the slats upwards by $\alpha$ degrees.
SET_STOP	d/c	d/c	STOP movement immediately.
SET_STATE	0 <= $x$ <= 100%	0 <= $\alpha$ <= 90°	Set the absolute sunblind position to $x$ and slat angle to $\alpha$ .

Function	Setting position x	Rotation slat angle $\alpha$	SMI behavior
GET_POS			Read out the current position of the SMI motor. The PositionFB data point is updated.

Note: The valid range for the rotation depends on the min/max rotation setting. Typical ranges are 0° to 90° (0° to -90° or -90° to 90° are also possible).

Table 14: Functions of the SNVT\_setting structure on the SMI sunblind.

Apart from the SMI device folders, a **Channels** folder exists. This is a fixed folder and contains the following data points:

- Power On X (X=1, 2, etc. per SMI channel): For each physical SMI channel one power-on data point exists. This data point is set TRUE before communication on the SMI channel commences. This can be used to attach a relay that turns on power on the SMI channel to save energy while the motors are left idle.
- Power Off Delay (analog): This data point specifies the number of seconds of idle time until the power-on data point is deactivated again. This is a parameter by default and thus available in LWEB-900. When setting this parameter to '0' the power-off feature is deactivated entirely.

## 10.2 SMI Workflow

### 10.2.1 Creating SMI Devices from Device Templates

SMI devices are created from SMI device templates. The Configurator is distributed with a library of common device templates. Device templates can also be imported from an external source and are stored in the data point configuration.

#### To Create an SMI Device

1. Click on the **SMI** port folder.
2. Right-click in the data point list view and select **New SMI Device...** in the context menu.
3. In the **Create Device** dialog enter a Device Name and a Count of devices to be created as shown in Figure 168.





Figure 168: SMI device creation dialog

4. Then click on  and choose a template file. As a default the directory of the distributed SMI device templates is opened. Choose the desired template file.
5. The device type, device model and device manufacturer information is displayed. Then click **Create Device**.

### 10.2.2 Commission SMI Devices

The SMI device templates do not contain any specific addressing information. The assignment between a device instance in the data point configuration and a physical device has to be done later on the Commission Web interface. SMI motors also need calibration in order to translate raw motor steps into position/rotation values.

#### To Commission an SMI Device

1. On the Web interface go to the menu **Commission** and select the **SMI** technology.
2. The Web UI lists all SMI devices found in the configuration. To manually assign a device enter the serial number. If the SMI motor is online, the device is commissioned and an address assigned.
3. Alternatively, click the **Scan SMI network** button below and wait for the scan to complete.
4. From the list of scanned devices, make the SMI device assignments in the drop-down boxes.
5. Then click the **Assign** button to commission the SMI devices.

For more details on the commission Web UI and motor calibration refer to the Chapter “SMI” in the LOYTEC Device User Manual [1].

### 10.2.3 Organize SMI Devices

Once the SMI devices have been created, they can be modified using the context menu on the device folder. SMI devices can be renamed, moved (but not into other devices) and organized in sub-folders. SMI devices can also be duplicated and deleted.

#### To Organize SMI Devices

1. Click on the SMI port folder and create a new folder by choosing **New Folder** in the context menu.
2. Select one or more SMI device folders and drag them with the mouse onto a sub-folder.
3. To duplicate an existing SMI device, select the SMI device folder and choose **Duplicate Device** from the context menu.
4. To rename an SMI device, select the SMI device folder and choose **Rename Device** from the context menu.

---

*Note:* When moving SMI device folders to other sub-folders or renaming SMI devices, their commissioning data is maintained. When duplicating an existing SMI device, the duplicated devices require to be commissioned.

---

5. To delete SMI devices, select one or more SMI device folders and choose **Delete Device** from the context menu.

## 10.2.4 Using Power-On Data Points

The power-on data points are binary data points that become active as soon as the SMI master is about to communicate on the corresponding SMI channel. This data point can be used to drive a relay, which turns on the bus power. The data point stays active until **Power Off Delay** seconds of idle time on the bus. After that the data point becomes inactive and may turn bus power off. This mechanism can be used to save energy during idle times on the SMI bus.

The power-on data points are located under the **Channels** folder under the SMI port:

**Power On 1 ... 5:** These power-on data points correspond to internal SMI ports 1 to 5 on devices that have them.

**Power On 6 ... 10:** These power-on data points correspond to SMI on the EXT ports 1 to 5 on devices that have them.

**Power On 11 ... 20:** These power-on data points correspond to SMI channels on a USB interface, e.g. the LSMI-804.

Note, that the on-board relays of the LSMI-804 can be used out-of-the-box without connections of the power-on data points. The power-on data points for the LSMI-804 USB channels are for use in internal program logic. For more information on how to switch bus power refer to the LOYTEC Device User Manual [1] SMI Chapter, Section Hardware Installation.

Also be aware of the fact, that a 2-second delay is introduced after powering on and before sending any commands to SMI devices. This is necessary to give SMI devices enough time to start after powering on. This may, however, lead to undesirable delays in manual operation using buttons. In this case, the feature can be entirely disabled by writing '0' to the Power Off Delay data point.

# 11 EnOcean

## 11.1 Configurator

### 11.1.1 Activating EnOcean

Before EnOcean devices can be added to a data point configuration, the EnOcean interface in the project settings must be enabled. The project settings are described in detail in Section 4.3.

#### To Activate EnOcean in the Configuration

1. Open the project settings dialog.
2. In the **System Settings** tab enable the EnOcean protocol on the USB port, as shown in Figure 169.
3. Press the **OK** button.




Figure 169: Enabling EnOcean in the Project Settings Dialog.

**Important:** *If the EnOcean protocol is deactivated via the checkbox or a firmware or model version is chosen, which does not support EnOcean, the entire EnOcean configuration is deleted. In this case a dialog is displayed, which has to be confirmed.*

If the Configurator is connected to a device, the **Download** button can be used to download the device configuration.

### 11.1.2 Data Point Manager for EnOcean

The Configurator uses a central concept to manage data points. The data point manager is used to select, create, edit and delete data points. The dialog is divided into three sections:

- The folder list (Figure 170),
- The data point list (Figure 171),
- And a property view.




Figure 170: Data Point Manager with EnOcean device folders.

LINX-120 ▸ EnOcean ▸ Temperature Sensor

Datapoint Name	No.	OPC	Param	PLC in	PLC out	Direction	Description	Type	Use	ID
Temperature	1	<input checked="" type="checkbox"/>		<input type="checkbox"/>		In	Temperature (linear)	EnOcean/Temperature -20...	0	108F
RSSI	2	<input checked="" type="checkbox"/>		<input type="checkbox"/>		In	Received signal strength	EnOcean/RSSI	0	1090
Location	3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Value	Location of the device	EnOcean/string	0	1091
Description	4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Value	Description of the device	EnOcean/string	0	1092
ID	5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Value	Unique EnOcean ID	EnOcean/string	0	1093

Figure 171: Data Point Manager Dialog with EnOcean Data Point List.

### 11.1.3 Port Folder

The EnOcean port folder represents the EnOcean interface. In the EnOcean port folder, one folder per EnOcean device is created, which contains the data points for that EnOcean device. EnOcean device folders are identified by a small EnOcean logo on the folder icon. They can be deleted, duplicated, renamed and organized in sub-folders.

The data points in an EnOcean device folder cannot be deleted or renamed. Some of their properties such as OPC exposure, PLC in/out, parameter can be modified. The data points named ID, Description, Location are parameters and are also available in LWEB-900.

## 11.2 EnOcean Workflow

### 11.2.1 Creating EnOcean Devices from Device Templates

EnOcean devices are created from EnOcean device templates. The Configurator is distributed with a library of common device templates. Device templates can also be imported from an external source and are stored in the data point configuration.

### To Create an EnOcean Device

1. Click on the **EnOcean** port folder.
2. Right-click in the data point list view and select **New EnOcean Device...** in the context menu.
3. In the **Create Device** dialog enter a Device Name and a Count of devices to be created as shown in Figure 172.





Figure 172: EnOcean device creation dialog

4. Then click on  and choose a template file. As a default the directory of the distributed EnOcean device templates is opened. Choose the desired template file.
5. The device type, device model and device manufacturer information is displayed. Then click **Create Device**.

## 11.2.2 Edit EnOcean Data Points

The EnOcean data points are located under their respective device folders. The data points cannot be deleted or renamed. Some of the data point properties can be edited using the property editor.

Now it is possible to use Alarming, Scheduling and Trending on the EnOcean data points. They can be exposed to OPC, and can be used as parameters and IEC 61131 variables. Further they can be used in connections, global connections and math objects.

## 11.2.3 Alarming, Scheduling and Trending

EnOcean data points can be alarmed by the generic alarm server. The configuration of alarming is described in Section 4.8.

EnOcean data points can be scheduled by the generic scheduler. For devices with CEA709 interfaces, the CEA709 scheduler is used to schedule EnOcean networks. This works also when the CEA709 node is not commissioned. For BACnet devices, the EnOcean data points can be also scheduled by a BACnet scheduler. The configuration of scheduling is described in Section 4.7.

EnOcean data points can be trended with the generic trends which are described in Section 4.9. They can also be configured with historic filters as described in Section 4.12.


## 11.2.4 Teach-In EnOcean Devices

The EnOcean device templates do not contain any specific addressing information. The assignment between a device instance in the data point configuration and a physical device has to be done later on the Commission Web interface. This is called the *teach-in* of EnOcean devices.



### To Teach-In EnOcean Device

1. On the Web interface go to the menu **Commission** and select the **EnOcean** technology.
2. The Web UI lists all EnOcean devices found in the configuration. To teach-in an uncommissioned device, click the **Teach-In** button.
3. The device status changed to “Waiting for Device ID”. Then press the button on the EnOcean device that shall be associated with this device in the configuration. Or click **Cancel** to abort.
4. If the teach-in worked fine, the device status will change to “OK”. The RSSI value is updated. Expand the **Profile** item and check the received data value.

UID Interface	Device	Status Timestamp	Device ID	Profiles	RSSI Rep. Hops
108E 0	Temperature Sensor Thermokon SR65	OK 2015-01-12 11:54:27	0006B35C	<div> <div>A50214</div> <div>Temperature 22.61 °C</div> <div>Parameters</div> </div>	-57.00 dBm 0 

5. Expand the **Parameters** item and enter a device description and location string. This information will be available in LWEB-900 and on the Web UI.

## 11.2.5 Organize EnOcean Devices

Once the EnOcean devices have been created, they can be modified using the context menu on the device folder. EnOcean devices can be renamed, moved (but not into other devices) and organized in sub-folders. EnOcean devices can also be duplicated and deleted.

### To Organize EnOcean Devices

1. Click on the EnOcean port folder and create a new folder by choosing **New Folder** in the context menu.
2. Select one or more EnOcean device folders and drag them with the mouse onto a sub-folder.
3. To duplicate an existing EnOcean device, select the EnOcean device folder and choose **Duplicate Device** from the context menu.
4. To rename an EnOcean device, select the EnOcean device folder and choose **Rename Device** from the context menu.

*Note:*

*When moving EnOcean device folders to other sub-folders or renaming EnOcean devices, their teach-in data is maintained. When duplicating an existing EnOcean device the duplicated devices require a teach-in.*

5. To delete EnOcean devices, select one or more EnOcean device folders and choose **Delete Device** from the context menu.

# 12 MP-Bus

## 12.1 Configurator

### 12.1.1 Activating MP-Bus

Before MP-Bus devices can be added to a data point configuration, the MP-Bus interface in the project settings must be enabled. The project settings are described in detail in Section 4.3. LOYTEC device models with a dedicated MP-Bus port have this enabled as a default.

#### To Activate MP-Bus in the Configuration

1. Open the project settings dialog.
2. In the **System Settings** tab enable the MP-Bus protocol on the MP-Bus port, as shown in Figure 173. When using an LMPBUS-804 activate the MP-Bus protocol on the USB port.
3. Press the **OK** button.




Figure 173: Enabling MP-Bus in the Project Settings Dialog.

**Important:** *If the MP-Bus protocol is deactivated via the checkbox or a firmware or model version is chosen, which does not support MP-Bus, the entire MP-Bus configuration is deleted. In this case a dialog is displayed, which has to be confirmed.*

If the Configurator is connected to a device, the **Download** button can be used to download the device configuration.

### 12.1.2 Data Point Manager for MP-Bus

The Configurator uses a central concept to manage data points. The data point manager is used to select, create, edit and delete data points. The dialog is divided into three sections:

- The folder list (Figure 174),
- The data point list (Figure 175),
- And a property view.




Figure 174: Data Point Manager with MP-Bus device folders.


LROC-400 ▶ MP-Bus ▶ LMB24-MPL\_OEM

Name Filter:

Datapoint Name	No.	OPC	Param	PLC in	PLC out	Direction	Description	Type	Index	Use	ID
CurrentPosition	1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		In	Current position of actuator	MPBus/RelativeV...	1000	0	1327
PosSetpoint	2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		Out	Set point for actuator	MPBus/RelativeV...	1001	0	1328
State1	3	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		In	Operating condition of the actuator	MPBus/State1	1002	0	1329
State2	4	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		In	Operating condition of the actuator	MPBus/State2	1003	0	132E
StartTest	5	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		Out	Start adaption, synchronisation or ...	MPBus/Testrun	1004	0	1336
SetPosition	6	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		Out	Force actuator to postion	MPBus/SetForce...	1005	0	1337

Figure 175: Data Point Manager Dialog with MP-Bus Data Point List.

### 12.1.3 Port Folder

The MP-Bus port folder represents the MP-Bus interface in the Configurator. In the MP-Bus port folder, one folder per MP-Bus device is created, which contains the data points for that MP-Bus device. MP-Bus device folders are identified by the MP-Bus device icon . MP-Bus device folders can be deleted, renamed and organized in sub-folders.

The data points in an MP-Bus device folder cannot be deleted or renamed. Some of their properties such as OPC exposure, PLC in/out, parameter can be modified. The remaining data points such as 'CurrentPosition' or 'PosSetpoint' are created depending on the MP-Bus device model.

## 12.2 MP-Bus Workflow

### 12.2.1 Creating MP-Bus Devices from Device Templates

MP-Bus devices are created from MP-Bus device templates. The Configurator is distributed with a library of common device templates. Device templates can also be imported from an external source and are stored in the data point configuration.

### To Create an MP-Bus Device

1. Click on the **MP-Bus** port folder.
2. Right-click in the data point list view and select **New MP-Bus Device...** in the context menu.
3. In the **Create Device** dialog enter a Device Name and a Count of devices to be created as shown in Figure 176.





Figure 176: MP-Bus device creation dialog

4. Then click on  and choose a template file. As a default the directory of the distributed MP-Bus device templates is opened. Choose the desired template file.
5. The device type, device model and device manufacturer information is displayed. Then click **Create Device**.

### 12.2.2 Edit MP-Bus Data Points

The MP-Bus data points are located under their respective device folders. The data points cannot be deleted or renamed. Some of the data point properties can be edited using the property editor.

Now it is possible to use Alarming, Scheduling and Trending on the MP-Bus data points. They can be exposed to OPC, and can be used as parameters and IEC 61131 variables. Further they can be used in connections, global connections and math objects.

### 12.2.3 Alarming, Trending and Scheduling

MP-Bus data points can be alarmed by the generic alarm server. The configuration of alarming is described in Section 4.8.

MP-Bus data points can be scheduled by the generic scheduler. For devices with CEA709 interfaces, the CEA709 scheduler is used to schedule MP-Bus networks. This works also when the CEA709 node is not commissioned. For BACnet devices, the MP-Bus data points can be also scheduled by a BACnet scheduler. The configuration of scheduling is described in Section 4.7.

MP-Bus data points can be trended with the generic trends which are described in Section 4.9. They can also be configured with historic filters as described in Section 4.12.

### 12.2.4 Commission MP-Bus Devices

The MP-Bus device templates do not contain any specific addressing information. The assignment between a device instance in the data point configuration and a physical device has to be done later on the Commission Web interface. This is called the commissioning of MP-Bus devices.

### To Commission an MP-Bus Device

1. On the Web interface go to the menu **Commission** and select the **MP-Bus** technology.
2. The Web UI lists all MP-Bus devices found in the configuration. To assign an uncommissioned device, click the **Address** button.
3. The device status changed to “Press button on device”. Then press the button on the MP-Bus device that shall be associated with this device in the configuration. Or click **Cancel** to abort.
4. If the assignment worked fine, the device status will change to “OK”. The **Serial** number and **Current pos** value is updated.

UID	Device	Port	Status	MP-Bus ID	Serial	Current Pos.	
10CA	EV015R	0	OK	00	21425-40113-22-76	0.43 %	<input type="button" value="Address"/>

Alternatively, an online scan can be performed to find and assign MP addresses in one sweep. Please refer to the MP-Bus Chapter of the LOYTEC Device User Manual [1] for more details.

## 12.2.5 Organize MP-Bus Devices

Once the MP-Bus devices have been created, they can be modified using the context menu on the device folder. MP-Bus devices can be renamed, moved (but not into other devices) and organized in sub-folders. MP-Bus devices can also be duplicated and deleted.

### To Organize MP-Bus Devices

1. Click on the MP-Bus port folder and create a new folder by choosing **New Folder** in the context menu.
2. Select one or more MP-Bus device folders and drag them with the mouse onto a sub-folder.
3. To duplicate an existing MP-Bus device, select the MP-Bus device folder and choose **Duplicate Device** from the context menu.
4. To rename an MP-Bus device, select the MP-Bus device folder and choose **Rename Device** from the context menu.

---

*Note:* When moving MP-Bus device folders to other sub-folders or renaming MP-Bus devices, their addressing data is maintained. When duplicating an existing MP-Bus device the duplicated devices require a new address assignment.

---


5. To delete MP-Bus devices, select one or more MP-Bus device folders and choose **Delete Device** from the context menu.

# 13 OPC Client

---

## 13.1 Configurator

### 13.1.1 Port Folder

The OPC port folder represents the OPC client interface in the Configurator. In the OPC port folder, one folder per OPC server is created, which contains the data points for that OPC server. OPC device folders are identified by the OPC server folder icon  known from LWEB-900. OPC device folders can be deleted, renamed and organized in sub-folders.

Data points and sub-folders in an OPC device folder can be deleted, renamed and re-organized. Data points can also be OPC exposed, which makes them available as OPC tags in the local OPC server. All other properties can be edited as described in Section 4.2.4.

### 13.1.2 Data Point Properties

Apart from the common data point properties discussed in Section 4.2.4 the data points of the OPC client technology have additional properties.

- **OPC Data Type:** This property shows the OPC data type of the OPC tag on the server.
- **OPC Tag Name:** This property shows the OPC tag name on the OPC server.
- **OPC Tag Path:** This property shows the OPC path to the tag on the OPC server.
- **OPC Device Commission Later:** This property defines whether the OPC device in the OPC client shall be commissioned later on the Web interface.
- **OPC Tag Base Path:** This property shows the OPC tag base path of an imported OPC tag list. This path can be replaced later by another path on the Web UI of the device.
- **OPC Device Name:** This property defines the logical device name used to denote the OPC server instance in the data point configuration. Changing it also updates the OPC device folder name.
- **OPC Device Local uses HTTPS:** This property specifies, whether communication to the OPC server on the local network shall use HTTPS.
- **OPC Device External uses HTTPS:** This property specifies, whether communication to the OPC server from an external (public) local network shall use HTTPS.

### 13.1.3 OPC Device Manager

To add new OPC servers to the project or update the data points associated with an existing OPC server, the OPC device manager window is used. It can be opened from the context menu of the OPC client port folder. Choose **Manage OPC Devices ...**.

On the top right, a tool bar is available to execute various operations.



The buttons from left to right are:

- **Add:** Use this button to add a new OPC server from a configuration file of the device. Supported configuration types include all L-INX, L-GATE, and L-DALI configuration files. Once the device configuration was loaded, suitable OPC client data points will be generated and added to the current project.
- **Refresh Status:** This button refreshes the status of the selected OPC device. It will check if the current data point configuration of the device is still in sync with the data points present in the current project, or if an update is needed.
- **Reload:** This button reloads the device configuration and updates the OPC data points in the current project to match the current configuration of the OPC server. Use this button to update the OPC data points whenever changes were made to the data point configuration of the OPC server.
- **Select Source:** This button allows you to change the device configuration file associated with the selected OPC device. In case the name or location of the configuration file was changed, the OPC device definition must be updated with the new location of the file.
- **Open in Editor:** This button will launch the configuration software suitable for the selected OPC device and load the associated data point configuration.
- **Delete:** This button deletes the selected OPC devices and all associated data points. Note that once the data points have been deleted, there is no easy way to restore them in a way that references from configuration objects to these data points will work again. Even after adding the same device again, the new data points will have different UIDs and all references to the old data points will be broken.

Below the tool bar is a list of all OPC devices. Each of the device entries can be expanded to show a number of properties. These properties can be edited and are explained below:

- **Name:** Internal name for this OPC device. Note that changing the name will also change the data point folder name in which the associated OPC data points are located. In case there are templates or template instances referencing the old data point folder name, they will need adjustment to fit the new name.
- **Local Address / Port:** These properties specify the primary IP address and port number which should be used to contact the OPC server.
- **Local use HTTPS:** When this option is checked, the OPC client will use HTTPS instead of HTTP when contacting the server.
- **Public Address / Port:** These properties define a secondary IP address and port number, which can be tried by the client in case the server is not reachable via the primary address. This can be used in NATed environments, where different addresses need to be used depending on the location of the client.
- **Public use HTTPS:** Same as the option for the local address, but related to the public address.
- **Operator Password:** The operator password to use when contacting the server.
- **Write Aggregation:** Time in milliseconds to wait for more values to write, before a write request is sent to the server. This increases efficiency by reducing the overhead involved in building and transmitting a SOAP request, compared to the number of values written with that request.

- **Lower Limit to Min. Send:** Minimum time in milliseconds for the Min. Send property of the OPC data point. Any value lower than this will be replaced by the specified minimum time.
- **Config Status:** Shows the current status of the server configuration. The configuration is either shown as *up to date*, meaning that the current project is still in-sync with the server configuration, or the status indicates that the server configuration was changed or removed since it was last imported.
- **LWEB Time:** The time when the server configuration was last imported.
- **Source Time:** The time when the server configuration was last modified.
- **Source Path:** The location of the imported server configuration on disk.

---


## 13.2 OPC Client Workflow

### 13.2.1 Integrate Devices via OPC


The Configurator allows adding entire LOYTEC device configurations, which expose data points as OPC tags. The resulting OPC device can be fully configured with its device URL and username/password or created without addressing information to be commissioned later. The imported OPC tags can be edited and trimmed to the required number of tags.

#### To Add an OPC Server

1. Select the **OPC Client** port folder.
2. Right-click and choose **New OPC Device ...** from the context menu.
3. Select a LOYTEC device configuration file such as ‘.linx’ or ‘.dali’.
4. In the **New OPC Device** dialog select **Commission later** or enter an IP address or host name and HTTP port for the Web service.



5. A new OPC device folder will be created.



6. Right-click on the OPC device folder and choose **Rename device ...** from the context menu. Enter the desired OPC device name. This name will be shown on the OPC device commission Web page as described in the LOYTEC Device User Manual [1].



### 13.2.2 Integrate Sub-Trees and Relocate

Apart from integrating entire OPC servers it is also possible to import only a sub-tree. This sub-tree has a base path that can be later replaced by another path. This makes it possible to create tag trees on the OPC server that are identical and cover different areas, such as 'channel1' and 'channel2'. When importing such a sub-tree, the assignment to channel 1 or 2 can be made later on the OPC commission Web page.


For example, the tag tree 'User Registers.channel1' contains the OPC tags 'reg1' to 'reg3'. The tag tree 'User Registers.channel2' contains exactly the same tags, that represent channel 2. The tag tree 'User Registers.channel1' can be exported and imported into the OPC client. Later on the Web UI, the base path 'User Registers.channel1' can be replaced by 'User Registers.channel2'.

#### To Export a Tag Tree


1. Select a data point folder in a device configuration which has the desired OPC tags.
2. Right-click and choose **Export OPC Tags ...**. Store them in a file ending '.opc'.

#### To Import a Tag Tree

1. Select the **OPC Client** port folder.
2. Right-click and choose **New OPC Device ...** from the context menu.
3. Select a tag list file ending '.opc'.
4. In the **Import OPC Device** dialog, edit the device name and check **Commission later**.



5. Then click the **Create New** button. This creates a new OPC device folder for exactly that OPC tag tree.



#### To Relocate a Tag Tree

1. On the Web UI go to **Commission → OPC XML DA Client**.
2. Enter the IP address in the **URL** column and click the save icon.
3. The column **Replacement Path** shows the original OPC base path of the tag import.

UID	Device	Status	URL	Replacement path	User/Password	
14EA	test	Running	http://192.168.24.122/	User Registers.channel1	operator *****	

4. To relocate it, enter a replacement path, e.g. 'User Registers.channel2'. Click the save icon.

URL	Replacement path	User/Password	
http://192.168.24.122/	r Registers.channel2	operator *****	

# 14 ekey

## 14.1 Configurator

### 14.1.1 Activating ekey

Before ekey fingerprint reader devices can be added to a data point configuration, the ekey interface in the project settings must be enabled. The project settings are described in detail in Section 4.3.

#### To Activate ekey in the Configuration

1. Open the project settings dialog.
2. In the **System Settings** tab enable the ekey protocol on an RS-485 port, as shown in Figure 177.
3. Press the **OK** button.




Figure 177: Enabling ekey in the Project Settings Dialog.

---

**Important:** *If the ekey protocol is deactivated via the checkbox or a firmware or model version is chosen, which does not support ekey, the entire ekey configuration is deleted. In this case a dialog is displayed, which has to be confirmed.*

---

If the Configurator is connected to a device, the **Download** button can be used to download the device configuration.

### 14.1.2 Data Point Manager for ekey

The Configurator uses a central concept to manage data points. The data point manager is used to select, create, edit and delete data points. The dialog is divided into three sections:

- The folder list (Figure 178),
- The data point list (Figure 179),
- And a property view.




Figure 178: Data Point Manager with ekey device folders.

LINX-112 ▶ ekey ▶ reader1

Datapoint Name	No.	OPC	Param	PLC in	PLC out	Direction	Description	Type
Authenticated	1	<input checked="" type="checkbox"/>				In	Authentication res...	ekey/Authenticated
AuthStr	2	<input checked="" type="checkbox"/>				In	Authentication info...	ekey/AuthStr
Enable	3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			Out	Enable or disable ...	ekey/Enable
EkeyAddr	4	<input checked="" type="checkbox"/>				In	Device address	ekey/EkeyAddr

Figure 179: Data Point Manager Dialog with ekey Data Point List.

### 14.1.3 Port Folder

The ekey port folder represents the ekey interface. In the ekey port folder, one folder per ekey fingerprint reader device is created, which contains the data points for that reader. The ekey folders are identified by a small ekey logo on the folder icon. They can be deleted, duplicated, renamed and organized in sub-folders.

The data points in an ekey device folder cannot be deleted or renamed. Some of their properties such as OPC exposure, PLC in/out, parameter can be modified. The data points per fingerprint reader are:

- **Authenticated (binary):** This register becomes TRUE for a short period of time when a finger was authenticated and then falls back to FALSE.
- **AuthStr (string):** When a finger is authenticated, it contains the full authentication information of user and fingerprint. After that it falls back to the empty string.
- **Authenticated user ID (analog):** When a finger is authenticated, it contains the user ID. After that it falls back to invalid value.
- **Authenticated user name (string):** When a finger is authenticated, it contains the user name. After that it falls back to the empty string.
- **Enable (binary):** When this register is set TRUE, the finger reader is enabled and performs authentication of fingers. When setting FALSE this particular fingerprint reader device is disabled. This is a parameter by default and thus available in LWEB-900.
- **EkeyAddr (string):** This data point contains the ekey device address.
- **Users (string):** This parameter data point contains the user and finger enrollment data stored on that reader device. The parameter data point is available in LWEB-900 and can be used to distribute user enrollment over reader devices.

Apart from the ekey fingerprint reader device folders, a **Groups** folder exists. This is a fixed folder and contains 10 group enable data points:

- groupEnable\_X (X=0, ..., 9, binary): Each of the 10 group enable registers corresponds to a user group. Setting it FALSE temporarily denies access to all members of the corresponding user group. Setting it TRUE allows access to all members of the corresponding user group. This is a parameter by default and thus available in LWEB-900.

---

## 14.2 ekey Workflow

### 14.2.1 Create From Device Templates

The ekey fingerprint reader devices need to be created using device templates. The Configurator is distributed with a library of ekey fingerprint reader device templates. An ekey device created in the data point configuration needs to be commissioned later online on the Web UI.

#### To Create an ekey Reader Device

1. Click on the **ekey** port folder.
2. Right-click in the data point list view and select **New ekey Device...** in the context menu.
3. In the **Create Device** dialog enter a **Device Name** and a **Count** of devices to be created as shown in Figure 180.





Figure 180: ekey fingerprint reader device creation dialog

4. Then click on  and choose an '.ekey' device template file. As a default the directory of the distributed ekey device templates is opened. Choose the desired template file.
5. The device type, device model and device manufacturer information is displayed. Then click **Create Device**.

### 14.2.2 Enroll Fingerprint Readers

The fingerprint reader devices do not contain any specific addressing information. The assignment between a reader instance in the data point configuration and a physical reader device has to be done later on the Commission Web interface.

#### To Enroll a Reader Device

1. On the Web interface go to the menu **Commission** and select the **ekey** technology.

- The Web UI lists all ekey reader devices found in the configuration. To enroll an uncommissioned device, which is connected and online, click the **Scan ekey network** button.
- When the scan completes it lists all found ekey devices. Those which are unassigned have a drop-down box.

Assignment	Address	Data	Serial	Version
Reader_7	855244823		80158220140023	06.12.07.10
UNASSIGNED	855244835		80158220140035	06.04.08.30



- Choose an uncommissioned reader device from the configuration and click on the **Assign** button.
- The assigned reader should now go online and show address and serial number in the device list. Edit a description and click the save icon.

UID	Device	Status	Address	Data	Encryption	Serial
107D	Reader_1	OK	855244832	2 users, 10 fingers	Active	80158220140032
	Front door					


### 14.2.3 Enroll Users and Fingers

To enroll fingerprints for a user locate a reader device where the user has physical access. The enrollment process is performed on that reader device. The enrollment data can then be transferred to other reader devices that shall grant access to that user as well.

#### To Enroll User Fingers

- On the commission Web UI locate the desired reader in the device list and click on the **Show users** icon .
- The user list of the selected reader device is displayed. Click on the plus icon  to add a new user.

ID	Username	Group	Fingers
1		9	LS LR LM LI LT RT RI RM RR RS
2		9	

- To edit the user click the pencil icon  which opens the **User configuration** page as shown in Figure 181. Enter a user name and select a finger to enroll, e.g. left index finger.

## ekey User Configuration

[Device list](#)
[Device configuration](#)
[User list](#)
[User configuration](#)

User ID

User name

Enable User

Enable Fingers

Group

Enroll

Remove

2

Jane Doe

☒

LS LR LM LI LT RT RI RM RR RS

Group 9 (Default)

Left Index Finger

Please select

→ enroll

→ remove

Save Settings

Get Settings

Figure 181: ekey User Configuration page.

- Then click on the **enroll** button and move the correct finger as described in the instructions.
- Repeat this enrollment with other fingers as well. At least two fingers should be enrolled. To finalize click on **Save Settings**.

**To Transfer a User Configuration**

1. In the **ekey User Configuration** page of a given user, click on the **Export link** to generate a user configuration XML file.
2. Then navigate to a different reader device and pull up the **User List** of that device.
3. Add a new user as described above. On the user configuration page of that new user, click on the **Choose File** button. Select the previously stored XML file.
4. Then click the **Import** button.

# 15 DALI

---

## 15.1 Non-programmable Models

This section describes the DALI related user interfaces and workflows for the L-DALI models, which come with a standard lighting application (non-programmable). Specifically this includes the following models:

- LDALI-ME201-U
- LDALI-ME204-U
- LDALI-3E101-U
- LDALI-3E102-U
- LDALI-3E104-U
- LDALI-ME204
- LDALI-E201-U
- LDALI-3E101
- LDALI-3E102
- LDALI-3E104
- LDALI-E101-U
- LDALI-3101-U

### 15.1.1 Configurator

To install and manage the DALI channels the tabs **DALI Installation**, **DALI Groups**, **DALI Channels**, **DALI Parameters** and **DALI Scenes** are used:

- The **DALI Installation** tab is used to assign DALI ballasts to Lamp Actuator objects, DALI sensors to Sensor objects, and DALI buttons to Button objects. Additionally, a name can be assigned to each ballast, sensor, and button. For details see Section 15.1.1.1.
- The **DALI Groups** tab is used to assign ballasts to DALI groups. Additionally, a name can be assigned to each group. For details see Section 15.1.1.2.
- The **DALI Channels** tab can be used to virtually connect two DALI channels (“bridging”). Additionally, a name can be assigned to each channel. For details see Section 15.1.1.3.

- The **DALI Parameters** tab is used to configure parameters related to DALI devices, groups and channels and to the lighting application (if available). For details see Section 15.1.1.4.
- The **DALI Scenes** tab can be used to set up DALI lighting scenes. For details see Section 15.1.1.5.

### 15.1.1.1 DALI Installation Tab

The DALI Installation tab is shown in Figure 182. It is used to scan a DALI channel and assign DALI devices to Lamp Actuator, Sensor objects, and Button objects. The dialog is divided into three sections:

- The channel selection and functions section (number 1 in Figure 182).
- The DALI network database with the device assignment (number 2 in Figure 182).
- The DALI network scan results (number 3 in Figure 182).




Figure 182: DALI Installation tab.

#### 15.1.1.1.1 Channel Selection and Functions Section

The following functions are available in on-line and off-line mode:

- The drop down box to the left of this section allows you to choose the DALI channel to work with. The default selection is **Channel 1**. The number of channels available depends on the device model.
- In the middle of this section the drop down box **Mains-Off handling** and the parameters **Mains-On delay** and **Mains-Off delay** are found. This function allows saving the standby energy consumed by the ballasts, by switching off the ballast mains when all ballasts on a channel are off. For further details see the LOYTEC Device User Manual [1].
- The **Export** and **Import** buttons on the right side allow exporting and importing the DALI configuration of the selected channel to/from an XML file. This includes DALI device assignment, device names, group assignment, group names, and the channel configuration.

If you are online the following additional functions are available:



- The **Scan Channel** button starts a scan of the DALI channel. When pressing the button a window showing the scan progress will be shown (see Figure 183). After the scan the devices found will be listed in the DALI network scan results section (number 3 in Figure 182) of the DALI Installation tab.
- Pressing the **Reset** button will clear the DALI configuration of the selected channel including all DALI device assignments, device names, group assignment, group names, and the channel configuration. If on-line it will also reset all DALI devices on the channel to factory defaults.




Figure 183: DALI channel scan progress.

- The **Automatic Status** check box allows enabling and disabling the periodic update of the status of the devices in the DALI network database. Pressing **Get Status** allows updating the device status manually if automatic status update is disabled.

---

*Note:* If there is no IP connection available, disable automatic status update in case there is no need to monitor the status of DALI devices as the status update uses network bandwidth.

---

- The **Protocol Analyzer** button will open the DALI Protocol Analyzer window. See Section 15.1.1.6 for details.

#### 15.1.1.1.2 DALI Network Database Section

This section allows naming DALI devices (ballasts, sensors, and buttons) and assigning them to the Lamp Actuator, Sensor, and Button objects. Optionally the DALI device type can be configured for unassigned ballasts and buttons. The upper table contains 64 entries, one for each potential DALI ballast on the channel, the middle table contains – depending on the model – 16 or 64 entries, one for each potential DALI sensor on the channel, and the lower table contains 64 entries, one for each potential DALI button device on the channel.

For each entry the tables contain the following columns:

- **Lamp/Sensor/Button name:** Contains the name of the DALI device. Double click on the name to modify it. The name should be chosen in a way which allows identifying the lamp (e.g. room number/ballast number). This is specifically important in off-line work flow (see Section 15.1.2.2) for the installer to pick the correct lamp during the final on-line phase and to identify a lamp if it reports an error.
- **Type:** Show the type and optionally the make of the DALI ballast, sensor, or button assigned. For assigned and online ballasts this information is read from the ballast. In case of unassigned ballasts and buttons, the DALI device type can be chosen using a drop-down box or **Set device type...** from the context menu (can be used with multi-select). Selecting the device type allows to configure DALI device type specific parameters during off-line preparation including the button functions. Further, this information is used during device assignment when on-line to ensure only a matching device type can be assigned. For information on the device type reported by a ballast please refer to the documentation provided by the vendor of the ballast or luminaire.
- **Status:** Shows the status of the DALI device if a DALI ballast, sensor, or button is assigned and the DALI configuration was downloaded. If the DALI device is online the status is **OK**, if it is not reachable via the DALI network it is **Offline**. The device is marked **modified** if its configuration/assignment was changed, but not yet

downloaded to the device. If **Automatic Status** is checked the status is periodically updated. Press **Get Status** to manually trigger an update of the Status column.

- **Short Addr.:** Shows the DALI short address of the device. The DALI short address can be in the range 0 to 63.
- **Serial Nr.:** Shows the serial number of the device, if available. If the serial number of the device is known during preparation phase of off-line work flow (see Section 15.1.2.2) it can be entered by double clicking on this field. In this case the assignment is automatically performed once the DALI configuration is downloaded to the device.

The list can be sorted by clicking on one of the column headers.

A device can be winked by selecting the corresponding row and clicking on the **Wink** button located between the DALI network database section and the DALI scan result section.

#### 15.1.1.1.3 DALI Network Scan Result Section

If a DALI network scan has been performed by pressing the **Scan Channel** button, the unassigned devices found during the scan are displayed in the table in the DALI network scan result section.

For each entry the tables contain the following columns:

- **Short Addr.:** Shows the DALI short address of the device. For DALI devices which do not contain a short address it will be automatically assigned during network scan.
- **Device:** Can be **Ballast**, **Sensor**, **Button**, or **Unknown**. Unknown devices are devices not supported by the LOYTEC DALI interface. See the LOYTEC Device User Manual [1] for details on the different DALI device types.
- **Type:** Show the type and optionally the make of the DALI device.
- **Serial Nr.:** Shows the serial number of the device, if available.

The list can be sorted by clicking on one of the column headers.

Devices found during a DALI network scan can be assigned to Lamp Actuator, Sensor, or Button objects either one by one or using the **Auto Assign** button.

To manually assign a device select one device in the scan results list on the right side and an unassigned entry in the Lamp Actuator, Sensor, or Button objects lists on the left side and press the **Assign** button. Alternatively you can drag a device from the scan results list and drop it to an unassigned entry in the object lists. DALI ballasts must be assigned to Lamp Actuator objects. DALI sensors must be assigned to Sensor objects. DALI buttons must be assigned to Button objects.

To remove an assignment from an object select the corresponding entry and press the **Unassign** button. The entry in the object list will become unassigned again and the DALI device will be moved to the scan results list to the right.

To identify a device in the scan results list select the corresponding row and click on the **Wink** button. The duration of the **Wink** action can be chosen in the drop down box besides the button. When a device winks it dims between its minimum and maximum value for the specified wink duration.

---

**Tip!**

*Use auto assign if you do not care about the assignment of a specific device. This is typically the case if you are using the on-line work flow (do not prepare DALI installation off-line)*

*and you do not use the Lamp Actuator objects to control the lights (rather use Group or Channel Actuator objects).*

15.1.1.2 DALI Groups Tab

The DALI Groups tab is shown in Figure 184. It is used to assign DALI ballasts to groups and setup group names.

Similar to the DALI Installation tab the drop down box in the top left corner of the tab allows you to choose the DALI channel to work with. Below there is a table which contains one row for each DALI ballast (64) and one column for each DALI group (16). To add/remove a device to/from a group check/uncheck the check box where the corresponding row and column are crossing. The default name of a group (e.g. “Group 00”) can be changed by double clicking on it.




Figure 184: DALI Groups tab.

The checkbox **Recover group information from devices** allows keeping the group configuration in the devices (ignoring the group configuration defined in the LINX Configurator). It is automatically unchecked if the group configuration is changed with the LINX Configurator.

15.1.1.3 DALI Channels Tab

The DALI Channels tab is shown in Figure 185. It is only available if the device is equipped with more than one DALI channel. This tab is used to change channel names and to configure DALI channel bridging.




Figure 185: DALI Channels tab.

The default name of a channel (e.g. “Channel 1”) can be changed by double clicking on it in the first row of the table.

To connect two channels by channel bridging, check the check box where the corresponding row and column are crossing. For more details on the DALI channel bridging function refer to the LOYTEC Device User Manual [1].

#### 15.1.1.4 DALI Parameter Tab

The DALI Parameters tab as shown in Figure 186. The dialog is divided into the following sections:

- The tree view (number 1),
- the object list (number 2),
- the parameter view (number 3),
- the constant light and sunblind controller bindings and button functions view (number 4) and
- buttons for special functions (number 5).






Figure 186: Parameter Configuration Dialog

The selected node in the tree view (1) determines which objects are displayed in the list view (2). If the root node (e.g. **LDALI-3E104-U**) is selected, all objects are displayed, if a branch is selected, the objects in or below this branch are displayed. For example, selecting **LDALI-3E104-U/Lamp Actuators** displays all Lamp Actuator objects on all DALI channels, whereas selecting **LDALI-3E104-U/Lamp Actuators/Channel 1** displays only Lamp Actuators of DALI channel 1.

In the object list (2) one or multiple objects can be selected. The properties of the selected object(s) are displayed and can be edited in the parameter view (3). In this way it is possible to change a parameter for multiple objects at once.

All DALI ballast, sensor, group and channel parameters can be configured. On L-DALI models in addition the parameters of the Constant Light Controller objects and Sunblind Controller objects are available. Details on the L-DALI parameters can be found in the L-DALI User Manual [3].

In case a single Constant Light Controller or Sunblind Controller is selected the internal bindings section (4) becomes active and allows determining which sensors (occupancy & lux) are used as inputs to and which outputs (light groups or SMI drives) are controlled by the selected constant light or sunblind controller instance, respectively.

Click on the  to add an input or output. Use the drop down box to select a sensor (input) or a light group/SMI drive (output). Click on  to remove an input or output.

In case of **Constant Light Controllers** one *lux level sensor*, but up to 16 *occupancy sensor* inputs can be configured for each controller instance. Whenever at least one occupancy sensor reports occupancy the area controlled by the controller instance is considered occupied. The drop down box allows to select a DALI sensor (occupancy/lux) instance or a data point.

To select a data point select **Choose data point...** from the drop down box. A data point selection dialog appears. Choose a data point and click on **OK**. Any analog data point can be selected as lux sensor, a binary data point as occupancy sensor. For the latter select, which value shall be considered as unoccupied and which as occupied (see Figure 187).







Input/Output	Binding	Add/Remove	Unoccupied Value	Occupied Value
Lux Sensor				
Occupancy				
1.	/User Registers/Reg		inactive	active
Light Band 1				
Light Band 2				
Neighboring Controller				

Figure 187: Select occupied and unoccupied value of data point based occupancy.

As outputs for each of the two *light bands* up to 16 DALI groups can be selected. The primary light band is near the inside of the building, the secondary light band is near the window front. Depending on the outdoor light intensity the primary light band has to be brighter than the secondary light band to illuminate the room evenly.

On LDALI-10x models NV bindings can be used in parallel to the internal bindings. When adding the first manual Constant Light Controller binding on a channel all automatic bindings of that channel will be disabled. Automatic bindings can be re-enabled in the CEA-709 Settings tab of the Project Settings (see Section 5.1.2).

In open office space applications, where different zones of an open space are controlled by different constant light controller instances, the controllers of neighboring zones can be linked together by configuring up to 16 neighboring controller instances for each Constant Light Controller. Whenever a zone is occupied and its lights are on, all neighboring zones/CLCs are also kept at a defined minimum level even if they are not occupied. See the L-DALI User Manual [3] for details on the function “Neighboring Controller”.

Similar for each **Sunblind Controller** instance one *lux level sensor*, but up to 16 *occupancy sensor* inputs can be configured. Whenever at least one occupancy sensor reports occupancy the area controlled by the controller instance is considered occupied. Up to 16 *SMI drives* can be selected as outputs for each instance. On LDALI-10x models NV bindings can be used in parallel to the internal bindings.




Figure 188: Selecting button objects.

Button functions can be configured for the following entities:

- **DALI buttons (Channel 1-4):** See the DALI section in the LOYTEC Devices User Manual [1] for information on which DALI button devices are supported.

---

*Note:* Not all DALI button device types are configurable. Therefore, a button device type supporting button functions must be selected or assigned on the DALI installation tab before the corresponding button object can be configured.

---

- **EnOcean:** Profiles Rocker Switch, 2 Rocker (F6-01) and 4 Rocker (F6-03), and Position Switch (F6-04) are supported. EnOcean devices must be created in the Datapoints tab before being available for button function configuration (see Chapter 11).
- **Data Points:** Any binary data point can be used to trigger button functions. Data points can be used to configure button functions for buttons created in L-WEB graphic projects, for buttons connected to digital inputs of remote IO modules (e.g. BACnet, LonMark, etc.) and for DALI buttons connected to DALI channels on other LDALI controllers. To use an existing data point as trigger for a button function click on the button **Add Data Point Button...** in the special functions (5) of the **DALI Parameters** tab.

In case one or more Button objects supporting button functions are selected the section for button function configuration (4) becomes active (see Figure 189). It allows the configuration of the function executed when a button is operated.

Button	Mode	Function	Destination	Argument 1 (switch on)	Argument 2 (switch off)
T1	push-button	On/Off (short) and Up/Down (long)	room_306		
T2	push-button	Recall scene	room_306	Scene 0	
T3	push-button	Disabled			
T4	push-button	Disabled			

Figure 189: Button function configuration.

The **Mode** drop down box allows to select whether a switch or a push button is connected to the button input (in case both are supported by a button device/input). The **Function** drop down box allows selecting the function to be performed when the button is pressed. See Table 15 for a list of available function. If the function is used to control light, the **Destination** column allows selecting the DALI group or channel to be controlled. If the function requires additional arguments (e.g. dim values or scene numbers) they are configured in the columns **Argument 1** and **Argument 2**.

Function	Description
Disabled	No action
Network data point	Button input status will be reflected by a data point.
On (maximum)	Switch on (recall maximum).
On (last value)	Switch on to last known value. <i>Note: Requires storing value when switching off.</i>
Auto	(Re-)activate L-DALI constant light controller of target group.
Off	Switch off.
Off (store value)	Store last value and switch off.
On/Off	Toggle between on and off whenever button is pressed or switch is changed depending on current status (changeover switch). Switch light on when it is off and switch light off when it is on.
Auto/Off	Toggle between active L-DALI constant light controller and off whenever button is pressed or switch is changed depending on current status (changeover switch). Switch light on when it is off and switch light off when it is on. <i>Note: Switching off will deactivate the L-DALI constant light controller.</i>
Up	Dim up while button is pressed. The dim speed is determined by the fade rate parameter of each ballast.
Down	Dim down while button is pressed. The dim speed is determined by the fade rate parameter of each ballast.
Up/Down	Toggle between dimming up and down whenever button is pressed. Dim as long as button is kept pressed. The dim speed is determined by fade rate parameter of each ballast.
On/Up	Switch on (recall maximum) if button is pressed shortly, dim up when button kept pressed. The dim speed is determined by the fade rate parameter of each ballast.
On (last value)/Up	Switch on to last known value if button is pressed shortly, dim up when button kept pressed. The dim speed is determined by the fade rate parameter of each ballast.
Auto/Up	(Re-)activate L-DALI constant light controller if button is pressed shortly, dim up when button kept pressed. The dim speed is determined by the fade rate parameter of each ballast. <i>Note: Dimming up will deactivate the L-DALI constant light controller.</i>
Off/Down	Switch off value if button is pressed shortly, dim down when button kept pressed. The dim speed is determined by the fade rate parameter of each ballast.
Off (store value)/Down	Store last value and switch off if button is pressed shortly, dim down when button kept pressed. The dim speed is determined by the fade rate parameter of each ballast.
On/Off and Up/Down	Toggle between on and off whenever button is pressed shortly depending on current status (changeover switch). Toggle between dimming up and down whenever button is pressed longer. Dim as long as button is kept pressed. The dim speed is determined by the fade rate parameter of each ballast.
Auto/Off and Up/Down	Toggle between active L-DALI constant light controller and off whenever button is pressed shortly depending on current status (changeover switch). Toggle between dimming up and down whenever button is pressed longer. Dim as long as button is kept pressed. The dim speed is determined by the fade rate parameter of each ballast. <i>Note: Dimming up/down and switching off will deactivate the L-DALI constant light controller.</i>

Function	Description
On (last value)/Off and Up/Down	Toggle between switching on to last value and off (including storing the last value) whenever button is pressed shortly depending on current status (changeover switch). Toggle between dimming up and down whenever button is pressed longer. Dim as long as button is kept pressed. The dim speed is determined by the fade rate parameter of each ballast.
Dim to	Dim to the value entered as argument 1.
Dim to (toggle)	Toggle between dim value entered as argument 1 and dim value entered as argument 2 whenever button is pressed or switch is changed.
Recall scene	Recall the scene configured with argument 1.
Recall scene (toggle)	Toggle between recalling scene configured with argument 1 and scene configured with argument 2 whenever button is pressed or switch is changed.
Colour warmer	Ramp up colour temperature as long as button is pressed. <i>Note: Requires ballasts of type colour control (device type 8) supporting the colour type colour temperature.</i>
Colour cooler	Ramp down colour temperature as long as button is pressed. <i>Note: Requires ballasts of type colour control (device type 8) supporting the colour type colour temperature.</i>
Sunblind Up	Short Press: Rotate sunblinds until completely open, then move up. Long Press: Drive to upper end position.
Sunblind Down	Short Press: Rotate sunblinds until completely closed, then move down. Long Press: Drive to lower end position.
Sunblind Auto	Relinquish manual override of sunblind controller application and resume automatic operation.
Sunblind Up/Down/Auto	Short Press: Toggle between moving sunblinds up and down, with stop in-between (each second button press). Long Press: Relinquish manual override of sunblind controller application and resume automatic operation.

Table 15: Button functions

Multi-select different button objects to change the configuration of multiple buttons at once. Only changes are applied to the selected objects. The rest of their configuration remains as is. This allows to quickly change selected values (e.g. button function) for multiple button objects.

If buttons are used with Constant Light Controller applications to allow manual and automatic operation please see the L-DALI User Manual [3] on how buttons can interact with the Constant Light Controller application.

Depending on the selected objects the following special functions (5) are available:

- **Lamp Actuators:** Reset run hours and Energy Count
- **Light Sensors:** Calibrate light sensor
- **Constant Light Controllers:** Calibrate constant light controller
- **Sunblind Controllers:** Modify sunblind controller event priorities, link sunblind controller to constant light controller



#### 15.1.1.4.1 Reset Run Hours and Energy Count

To reset the run hours and/or energy count of a lamp actuator click on the **Reset Run Hours/Energy Count...** button. A dialog is displayed which allows you to specify what you want to reset (see Figure 190).




Figure 190: Reset Run Hours and Energy Count

#### 15.1.1.4.2 Calibrate Light Sensor

To calibrate the light sensor click on the **Calibrate Light Sensor ...** button. The dialog shown in Figure 191 is opened.









Figure 191: Light Sensor Calibration

To counter any non-linearity the sensor can be calibrated for up to seven different daylight illumination levels. However, in most cases it is sufficient to calibrate the sensor only once. The best result is achieved if the illumination level is near the setpoint. To calibrate the sensor perform the following steps:

1. Measure the current lux level at the reference area (e.g. desk) using a luxmeter.
2. Enter the measured lux level in the input field **Measured Lux Level**.
3. Select an unused index.
4. Click on the **Calibrate** button.
5. If necessary repeat steps 1.– 4. For different daylight illumination levels.
6. Press the **Done** button.

If the sensor installation scenario is similar for multiple sensors, the calibration information can be applied to other sensor instances by selecting them in the box below the  button

and clicking the button. Similar the calibration information can be exported and imported by using the buttons  and .

The current gain table can be uploaded from the device by pressing the button . It can be cleared with the button .


#### 15.1.1.4.3 Calibrate Constant Light Controller (L-DALI only)

To calibrate the constant light controller click on the **Calibrate Constant Light Controller ...** button. The dialog shown in Figure 192 is opened.

##### Artificial light calibration

Artificial light calibration is required if

1. the artificial light in the controlled area/room is dimensioned outside the range of 500lx to 700lx. In a typical office room artificial light is dimensioned for around 600lx (500lx + 20%). If in the rooms artificial light is dimensioned dimmer or brighter the artificial light factor is used to parameterize the amount of lux provided by the rooms artificial light.
2. the difference in sensor sensibility for artificial light vs. for natural light must be considered. While the natural light comes through the window, the artificial light is provided by luminaires mounted on the ceiling. Thus, the reflection and light distribution is different depending on the light source. This results in a different ratio of the lux level measured by the sensors mounted on the ceiling to the lux level on the reference area (e.g. desk). In most use cases this difference is negligible. However, if it is not the artificial light factor is used to parameterize this influence.



Calibrate constant light controllers

☒ Artificial light calibration (REGULATOR & CONTROL modes)

Avoid natural light in the room, switch lights OFF and measure the lux level.

Luxmeter:  Light sensor:

Avoid natural light in the room, switch lights to maximum and measure the lux level.

Luxmeter:  Light sensor:

Without measuring: Enter 0/0 in the fields for the OFF values and the nominal lux level specified for the room (max. provided by the luminaires) in both ON values.

☒ Gain factor calibration (REGULATOR & CONTROL modes)

Avoid natural light, dim lights until luxmeter shows desired lux setpoint.

Luxmeter:  Light sensor:

Figure 192: Calibrate Constant Light Controller.

To measure the amount of light provided by the rooms artificial light the following steps have to be performed:

1. If possible darken the room.
2. Switch the lamp off. Measure the lux value on the reference area (e.g. desk) with a luxmeter and enter it in the first **Luxmeter** input field. Enter the value measured by the light sensor in the first **Light Sensor** input field.
3. Switch the lamp on. Measure the lux value on the reference area (e.g. desk) with a luxmeter and enter it in the second **Luxmeter** input field. Enter the value measured by the light sensor in the second **Light Sensor** input field.

4. Click on the **Calibrate** button.

If the lighting output of the rooms artificial lighting is known (in lux on the reference area) you can use those values as an approximation instead of measuring:

1. Enter 0 in both “OFF” fields (Luxmeter and Light sensor).
2. Enter the lux value corresponding to the lighting output of the room in both “ON” fields (Luxmeter and Light sensor).
3. Click on the **Calibrate** button.

#### **Gain factor calibration**

The gain factor has to be calibrated only if

1. a light sensor connected via CEA-709 or BACnet is used and this sensor cannot be calibrated.
2. the constant light controller is operated in CONTROL mode to define the ratio between the measured outdoor lux level and the resulting indoor lux level.

To calibrate the gain factor perform the following steps:

1. Switch the light off and measure the current lux level at the reference area (e.g. desk) using a luxmeter.
2. Enter the measured lux level in the input field **Luxmeter**.
3. Enter the value measured by the light sensor in the field **Light sensor**.
4. Click on the **Calibrate** button.

#### **15.1.1.4.4 Modify Sunblind Controller Event Priorities (L-DALI only)**

To modify the priority of event which influence the sunblind controller click on the **Modify Sunblind Controller Event Priorities ...** button. Depending on the L-DALI model the corresponding dialog differs. For a description of the different events refer to the L-DALI User Manual [3].

#### **LDALI-10X**

On LDALI-10x (LONMARK) models the dialog shown in Figure 193 is opened.




Figure 193: Modify Sunblind Event Priorities (LDALI-10x).

The button **Higher** increases the priority of the selected event; the button **Lower** decreases the priority.

Events can be disabled with the **Remove** button. Previously deleted events appear in the drop-down list and can be enabled by pressing the **Add** button.

Per default an event which is activated with identical parameters multiple times in succession will be executed multiple times. For some events (e.g. local control) this default behavior can be changed by pressing the **toggle re-evaluation** button. The text “not re-evaluated” will appear beside the event and successive identical commands will be ignored.

To store the modified event priorities press the **Modify** button. The event priorities can be reset to the default values by pressing the **Reset to default** button.

### LDALI-20x

On LDALI-20x (BACnet) models the dialog shown in Figure 194 is opened.




Figure 194: Modify Sunblind Event Priorities (LDALI-20x).

In this dialog the BACnet priorities for the events automatically generated by the Sunblind Controller application can be configured. In BACnet higher values correspond to lower

priorities. BACnet priorities may be in the range 1 to 16. The value 0 disables the corresponding event.

---

*Note:* Each event must use a unique BACnet priority value! That is, no two events may use the same BACnet priority value.

---

#### 15.1.1.4.5 Link Sunblind Controller to Constant Light Controller

To synchronize the lights and sunblinds of a room the sunblind controllers of a room have to be linked to the room's constant light controller. When clicking on the **Link Sunblind Controller to Constant Light Controller...** button the dialog shown in Figure 195 is opened. Select a constant light controller and press the **Link** button.




Figure 195: Link Sunblind Controller to Constant Light Controller.

#### 15.1.1.4.6 Configure Emergency Light Auto-Test Calendar

This function is only available if the Configurator is connected to an L-DALI and one or more Lamp Actuator objects are selected, which are assigned to a DALI ballast of type emergency light. Further, the DALI network has to be commissioned by downloading the DALI configuration.

To configure the Auto-Test Calendar of a DALI emergency light click on **Configure Emergency Test Interval & Delay...** The dialog shown Figure 196 in is opened.




Figure 196: Configure Emergency Test Interval & Delay.

For both tests – function and duration test – a test interval in days and the time and date of the next execution of the test can be specified. A Test Interval of 0 disables auto-test of the selected test. Click **Configure** to store the new values in the selected devices. Click on **Upload** to read the currently configured values from the device.

---

*Note:* The resolution of the duration test interval is 7 days, the resolution of the delay to the next test execution is 15 minutes. In both cases the value entered will be rounded to the next appropriate value.

---

Test results will be stored in the appropriate emergency light test log (see LOYTEC Device User Manual [1]).

#### 15.1.1.5 DALI Scenes Tab

Figure 197 shows the **DALI Scenes** tab. It allows configuring DALI lighting scenes. Similar to the DALI Installation tab the drop down box in the top left corner of the tab allows you to choose the DALI channel to work with.

DALI Installation   DALI Groups   DALI Channels   DALI Parameters   DALI Scenes   Datapoints   Local Connections   Global Connections   Conr					
Channel 1					
#	Lamp Name / Scene Name	Scene 00	Scene 01	Scene 02	Scene 03
0	LA1	0.0	0.0	0.0	0.0
1	LA2	0.0	0.0	0.0	0.0
2	LA3	0.0	0.0	0.0	0.0
3	LA4	0.0	0.0	0.0	0.0
4	LA5	0.0	0.0	0.0	0.0
5	LA6	0.0	0.0	0.0	0.0

Figure 197: DALI Scene configuration.

Each DALI ballast allows to store up to 15 scenes<sup>1</sup>. For each scene a name can be configured. Click on the scene name to edit it. For each ballast a different dim level can be configured for each of its scenes. If recalling the scene shall not affect the ballast's dim level set the value to '--'. In addition a name can be assigned to each scene. Start editing by double-clicking on the name.

<sup>1</sup> DALI ballasts support up to 16 scenes. Scene 15 is used by the LOYTEC DALI controller and the LOYTEC DALI buttons to store the last dim value when switching off and therefore is not available.





Figure 198: Scene colour selection for devices supporting colour type XY Coordinates.

For ballasts supporting colour control (DALI device type 8, DT8) the scene can include colour information, too.

For devices supporting *Colour Temperature* only two values can be entered for each scene. The upper value is the dim level, the lower value is the colour temperature for the scene. In all cases enter '--' in the upper value if the dim level shall not be affected when the scene is recalled and enter '--' in the lower value if the colour shall not change when the scene is recalled.

When clicking on the  button a colour picker dialog as shown in Figure 198 appears. The left side of the dialog shows the colour type(s) supported by the ballast. For ballasts supporting multiple colour types, first choose the appropriate type. Depending on the selected type the colour information is configured as follows:

- **Colour Temperature** (see Figure 199): This colour type is also referred to as tunable white. Here a slider allows to select the colour temperature between a “warmer” white (red) and “cooler” white (blue). Alternatively, the desired colour temperature can be entered as number in Kelvin. Note, that a lower Kelvin value is considered a “warmer” white and vice versa.




Figure 199: Selecting a colour temperature.

- **XY Coordinates** (see Figure 198): This colour type allows choosing a colour in the CIE 1931 colour space. Either manually enter the x and y coordinate of the scene colour within CIE 1931 colour space or pick the colour by clicking in the colour diagram on the left side of the dialog. The last six colour values used are shown in the history below the colour diagram for quick reference.
- **RGBWAF** (see Figure 200): For this type the resulting colour is composed by selecting a percentage value of 0% to 100% for the intensity of up to six predefined channels (red, green, blue, white, amber and free colour). Note, that a specific ballasts supporting RGBWAF might only support a subset of those six channels (e.g. only red, green, blue).




Figure 200: Selecting a colour for colour type RGBWAF.

- **Primary-N**: Similar to RGBWAF up to six colour channels are available for composing the resulting colour. However, in this case the colours represent the primary colours of the LEDs used on the luminaire. Similar to RGBWAF, a specific ballast might support less than six primary-N channels.

When online and the check box **Live preview** is checked the ballast will dim to the selected colour whenever a new value is selected.

---

*Note:* When an offline pre-configuration of scenes shall be performed all ballasts where scene values shall be configured must be given a non-default name to make them appear in the DALI Scenes tab. If the scenes shall containing colour information the device type colour control must be selected for the corresponding ballasts in the DALI Installation tab.

---

Scenes are stored for each ballast, but are typically recalled for a group. To show only the ballasts belonging to a certain group select the group in the drop down box next to the channel selection drop down box.



When online the scene can be tested without download by clicking on the corresponding button. This will dim the ballasts selected by the current filter to the values configured for the scene.

Scenes can be recalled using buttons or by the LOYTEC DALI controller via its data point interface.

#### 15.1.1.6 DALI Protocol Analyzer

When online a DALI protocol analyzer is available via the corresponding button in the DALI Installation tab. When clicking on the button the DALI Protocol Analyzer window as shown in Figure 201 opens up.




Figure 201: DALI protocol analyzer

Check boxes allow selecting the DALI channels to log. Multiple channels can be logged at the same time. With the **Set filter flags** button the number of logged frames can be reduced by configuring a filter to logging only certain frame types. By pressing the button **Start Log** or **Stop Log** the protocol analyzer can be started and stopped respectively. When stopped click on **Save** to store the protocol log as a CSV file. **Clear** clears the log data. Check **Automatic Scrolling** to always show the newest frames by automatically scrolling to stay at the end of the page. The check box **Log to file** allows long time logging to a file.

Each line contains the following information:

- **Timestamp** (Example: "11:08:05.284"): Local time on the device when the frame was received (end of frame).
- **Settling time** (Example: "45.00TE"): Settling time between this and the previous frame in Te (1 Te = 416.67  $\mu$ s). The maximum value shown is "99TE".
- **Direction** (Example: "->"): Frames sent by the LOYTEC DALI controller are marked by "->", while frames received are marked by "<-".
- **Hex Data**: Raw frame as hex number.
- **Frame type** (Example: "REQ"): Type of DALI frame. Some possible frame types are shown in Table 16.

Frame type	Description
REQ (16-bit)	DALI request (IEC 62386-102, control gear)
CMD (16-bit)	DALI command (IEC 62386-102, control gear)
REQ (24-bit)	DALI request (IEC 62386-103, control device)
CMD (24-bit)	DALI command (IEC 62386-103, control device)
RESP (8-bit)	DALI response
EVNT	DALI event (IEC 62386-103, control device)
REQ (OSRAM)	DALI request (OSRAM proprietary)
CMD (OSRAM)	DALI command (OSRAM proprietary)
EVNT (Philips)	DALI event (Philips)
???	Unknown type

Table 16: DALI frame types.

- **Destination address** (Example: “s03”): Destination address of the frame. Possible address types are:
  - **sXX**: DALI short address, where XX is the short address (00-63).
  - **gXX**: DALI group address, where XX is the group number (00-15).
  - **b\***: DALI broadcast address.

In brackets the channel, group or – if the device is assigned - device name is shown, respectively.

- **Message type & data** (Example: “QUERY STATUS”): Shows the DALI message type and the corresponding data (argument).

## 15.1.2 DALI Workflow

This section discusses a number of work flows for commissioning and configuring DALI devices in different use cases. The description is intended to be high-level and is depicted in flow diagrams. The individual steps refer to later sections, which describe each step in more detail. In principle, the LINX Configurator supports the following use cases:

- On-Line (see Section 15.1.2.1)
- Off-Line (see Section 15.1.2.2)

### 15.1.2.1 On-Line

The flow diagram in Figure 202 shows the steps that need to be followed in order to set up the DALI network when the LOYTEC device and the DALI network including all DALI devices (e.g. ballasts, sensors, etc.) are available on-line.




Figure 202: Basic on-line design-flow.

First, the LINX Configurator must be started and a connection must be established to the LOYTEC device. In the Configurator, the DALI network is scanned for DALI devices and the devices are setup and assigned to DALI groups (see Section 15.1.1.1 and 15.1.1.2). Then the parameters for the DALI devices, groups and channels and – in case of L-DALI models – for the light application and the sunblind application can be configured (see Section 15.1.1.4). Optionally, DALI scenes can be configured (see Section 15.1.1.5). Finally, the configuration needs to be downloaded to the LOYTEC device.

To add more DALI devices, change DALI group assignment or application parameters simply repeat the steps described above.

### 15.1.2.2 Off-Line

The flow diagram in Figure 203 shows the steps that need to be followed in order to pre-configure the DALI network off-line. In this scenario the first steps can be performed without the LOYTEC device and the DALI network being physically available. This allows to prepare the on-line commissioning and thus to speed up the time required for on-site installation. Further, some steps of the on-line commissioning part can be performed by less skilled personnel using the Web Interface of the LOYTEC device.




Figure 203: Basic off-line design-flow.

First, the LINX Configurator must be started. Select the correct LOYTEC device model in the **Model** menu. Note, that the device is off-line. Next setup names, groups and optionally device type for the DALI devices (see Section 15.1.1.1 and 15.1.1.2). The names assigned must allow identifying physical devices later on (e.g. “Room 301-1” for first ballast in room 301). The device type (e.g. emergency light) must be selected if any device type specific parameters shall be configured in the next step. Then the parameters for the DALI devices, groups and channels and – in case of L-DALI models – for the light application and the sunblind application can be configured (see Section 15.1.1.4). Optionally, DALI scenes can be configured (see Section 15.1.1.5). Save the created configuration to a file.

Once the LOYTEC device and the DALI network is physically available, start the LINX Configurator again and load the file created during the off-line preparation. Now a connection must be established to the LOYTEC device.

To complete the commissioning of the DALI network the DALI devices in the network must be assigned to the names entered during off-line preparation. This task can be performed in two ways:

- Use the DALI Installation tab in the LINX Configurator to perform a scan of the DALI network and assign all DALI device found (see Section 15.1.1.3). Then download the configuration to the LOYTEC device.
- Download the Configuration to the LOYTEC device and use the DALI web-UI of the device to accomplish the DALI device assignment (see LOYTEC Device User Manual [1]).

Finally, it is recommended to upload and save the complete configuration to a file for being able to replace an LOYTEC device. Additionally a backup should be created.

To add more DALI devices, change DALI group assignment or application parameters it is recommended to use the on-line work flow (see Section 15.1.2.1).

### 15.1.2.3 Configuration Upload and Download

When uploading or downloading the configuration of a device with DALI interfaces the item **DALI Configuration and Parameters** is available. The DALI Configuration contains the configuration of the DALI network, including device names, device types, device assignment

(DALI short address), scene values, group names and group assignment as configured on the DALI Installation, DALI Groups, DALI Channel and DALI Scenes tabs. The Parameters contain the parameters of the L-DALI light and (if available) sunblind applications, including CLC Bindings and button functions as configured on the DALI Parameters tab.

---

*Note:* As new DALI devices are commissioned during the download of the DALI configuration this operation may take some time depending on the number of DALI devices to be commissioned.

---

If the dialog shown in Figure 204 appears, the software has detected a version mismatch between the DALI configuration in the device and the one in the Configurator.




Figure 204: DALI configuration mismatch.

Possible reasons for this message are:

- The DALI configuration on the device was changed using the web interface.
- An old configuration file version was loaded to the LINX Configurator software.
- No configuration file was loaded to the LINX Configurator software but the device contains a DALI configuration.

If you are sure, you are loading a matching DALI configuration to the device, you can answer the question by clicking on **Yes**. In any case the log ("Show details") will contain the message "Syncro counter did not match" for each affected channel.

If errors occurred during the configuration download, clicking on the button **Show Details** opens a Log-window. The Configuration Download Details log window as shown in Figure 205 opens up.







Figure 205: Configuration Download Details Log.

To filter out info messages use the button . Similar warning messages can be filtered by pressing the button  and error message by pressing the button . Press the **Save** button to store the log file on your harddrive (e.g. for sending in to LOYTEC support for analysis).

## 15.2 Programmable Models

This section describes the DALI related user interfaces and workflows for the controller models, which can be programmed using the L-STUDIO programming tool. Specifically this includes the following models:

- LDALI-PLC4
- LROC-400
- LROC-401

For this workflow, the LINX Configurator is used either standalone or as L-STUDIO Add-In.

### 15.2.1 Configurator

#### 15.2.1.1 Data Point Manager for DALI

The Configurator uses a central concept to manage data points. The data point manager is used to select, create, edit and delete data points. The dialog is divided into three sections:

- The folder list (Figure 206),
- The data point list (Figure 207),
- And a property view.




Figure 206: Data Point Manager with DALI device folders.

Datapoint Name	No.	OPC	Param	PLC In	PLC out	Direction	Description	Type	Index	Use	ID
Name	1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	Name of DALI channel	DALI/String	1011	0	1244
Location	2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Value	Location of the DALI channel	DALI/String	1012	0	1245
DimLevel	3	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out	Value for DIM level	DALI/Value	1094	0	1246
Colour	4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out	Colour control for changing the light colour of the channel	DALI/Colour	1095	0	1249
Command	5	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Out	Data point for issuing commands to the DALI channel	DALI/Command	1096	0	128F
Feedback	6	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	Feedback value	DALI/ValueFeedba...	1097	0	12C0
Energy	7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	Energy consumption based on nominal energy	DALI/Analog/Valu...	1098	0	12C5
RunHours	8	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	Time for which channel has been switched on	DALI/Analog/Valu...	1099	0	12C6
BatteryCharge	9	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	Current charge level of battery	DALI/Analog/Valu...	1100	0	12C7
BurnInTime	10	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Value	Burn-in time for ballast on the channel	DALI/Analog/Valu...	1101	0	12C8
BusPower	11	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In	Status of DALI bus power	DALI/BusPower	1102	0	12C9

Figure 207: Data Point Manager Dialog with DALI Channel Data Point List.

### 15.2.1.2 Port Folder

The DALI port folder represents all DALI interfaces available on the controller. In the DALI port folder, each DALI device, DALI group and DALI channel is represented by one folder. Each of these folders contains the data points for that DALI device, group or channel, respectively. They can be deleted, duplicated, renamed and organized in sub-folders.

Depending on the model certain folders are automatically created: On all models one folder per DALI channel. On the LDALI-PLC4 folders for all 16 DALI groups per channel are created in addition. The creation of the latter can be disabled in the project settings. These automatically created folders cannot be deleted.

The data points in a DALI device/group/channel folder cannot be deleted or renamed. Some of their properties such as OPC exposure, PLC in/out, parameter can be modified. The data points marked with the Param flag are parameters and are also available in LWEB-900.

## 15.2.2 DALI Workflow

### 15.2.2.1 Creating DALI Devices from Device Templates

DALI devices and – if not pre-allocated – DALI groups are created from DALI device templates. The Configurator is distributed with a library of common device templates. Device templates can also be imported from an external source and are stored in the data point configuration.

#### To Create a DALI Device

1. Click on the **DALI** port folder.
2. Right-click in the data point list view and select **New DALI Device...** in the context menu.
3. In the **Create Device** dialog enter a Device Name and a Count of devices to be created as shown in Figure 208.





Figure 208: DALI device creation dialog

4. Then click on  and choose a template file. As a default the directory of the distributed DALI templates is opened. Choose the desired template file. See Section 15.2.2.2 for more information on DALI templates.
5. The device type, device model and device manufacturer information is displayed. Then click **Create Device**.

### 15.2.2.2 DALI Templates

The following standard templates exist:

### DALI Actuators

- **DALI lamp actuator** (LampActuatorStd.dali): The Standard DALI Lamp Actuator provides data points for dimming, either absolute (*DimLevel*) or relative and via scenes (*Command*). The data point *Command* further allows various other DALI commands (e.g. burn-in, emergency test, etc.) to be triggered. The data points *DaliCfg*, *Group* and *NominalPower* can be used for configuration of the DALI ballast. *Feedback* provides the current dim level and *Status* provides various status information (e.g. errors, emergency test execution) provided by the ballast.
- **DALI lamp actuator disabled** (LampActuatorDisabled.dali): Is a minimal set of data points required for the configuration of the ballast. It is intended to be used if lamps are only controlled via groups or channel wide and never one by one. By using the template in this use case the number of data points can be significantly reduced.
- **DALI lamp actuator emergency** (LampActuatoremergency.dali): Similar to **DALI lamp actuator**, but with an additional data point for the battery charge status (*BatteryCharge*).
- **DALI lamp actuator colour** (LampActuatorColourControl.dali): Similar to **DALI lamp actuator**, but with an additional data points for colour control. Output colour can either be controlled via the *Colour* data point, mapping the three DALI colour control methods (colour temperature/Tc, xy-coordinate, RGBWAF), or via *Hue* and *Saturation* data points.
- **DALI group actuator** (GroupActuator.dali): Similar to **DALI lamp actuator**, but for controlling DALI groups. Thus, it contains no configuration data points. Data points for colour control (*Colour*) and emergency lights (*BatteryCharge*) are always provided. *Energy* provides the accumulated energy of all group members, while *BatteryCharge* and *RunHours* provided the minimum and maximum value, respectively.
- **DALI channel actuator** (ChannelActuator.dali): Similar to **DALI group actuator**, but for controlling all ballasts on a DALI channel.

### DALI Sensors

- **DALI multi-sensor** (SensorMulti.dali): This template contains the data points for a typical DALI multi-sensor, providing occupancy (*Occupancy*) and up to two lux level values (*Lux*, *Lux2*). *Gain* and *Gain2* are used to store a calibration gain table of the two lux sensors. *FieldCalibr* is used to perform calibration for the first lux level sensor: The field *index* is set to the index in the gain table (0-6), where the calibration value shall be stored, and *value* to the value currently measured with a lux meter at the reference area.

### DALI Buttons

- **DALI push-button** (ButtonDigital.dali): This template is used for standard (DALI-2) push-buttons. It can map up to 32 push-button instances. The status of each button is reflected by the corresponding bits of the *Button* data point. The number of push-button instances available on the assigned device is provided in the *Capabilities* data point.
- **DALI event button** (ButtonEvent.dali): Some (proprietary) DALI devices provide information on buttons via Events (e.g. Philips OccuSwitch and ActiLume IR-remote). Those type of devices can be mapped with this template. Each button press is represented by an event code provided via the *Event* data point.

#### 15.2.2.3 Edit DALI Data Points

The DALI data points are located under their respective device folders. The data points cannot be deleted or renamed. Some of the data point properties can be edited using the property editor.

Now it is possible to use Alarming, Scheduling and Trending on the DALI data points. They can be exposed to OPC, and can be used as parameters and PLC variables. Further they can be used in connections, global connections and math objects.



#### 15.2.2.4 Alarming, Scheduling and Trending

DALI data points can be alarmed by the generic alarm server. The configuration of alarming is described in Section 4.8.

DALI data points can be scheduled by the generic scheduler. For devices with CEA709 interfaces, the CEA709 scheduler is used to schedule DALI networks. This works also when the CEA709 node is not commissioned. For BACnet devices, the DALI data points can be also scheduled by a BACnet scheduler. The configuration of scheduling is described in Section 4.7.

DALI data points can be trended with the generic trends which are described in Section 4.9. They can also be configured with historic filters as described in Section 4.12.

#### 15.2.2.5 Organize DALI Devices

Once the DALI devices have been created, they can be modified using the context menu on the device folder. DALI devices can be renamed, moved (but not into other devices) and organized in sub-folders. DALI devices can also be duplicated and deleted.

##### To Organize DALI Devices

1. Click on the DALI port folder and create a new folder by choosing **New Folder** in the context menu.
2. Select one or more DALI device folders and drag them with the mouse onto a sub-folder.
3. To duplicate an existing DALI device, select the DALI device folder and choose **Duplicate Device** from the context menu.
4. To rename a DALI device, select the DALI device folder and choose **Rename Device** from the context menu.

---

<i>Note:</i>	<i>When moving DALI device folders to other sub-folders or renaming DALI devices, their assignment data is maintained. When duplicating an existing DALI device the duplicated devices require a new assignment.</i>
--------------	--

---

5. To delete DALI devices, select one or more DALI device folders and choose **Delete Device** from the context menu.

#### 15.2.2.6 Assigning DALI Devices

The DALI device templates do not contain any specific addressing information. The assignment between a device instance in the data point configuration and a physical device has to be done later, once deployed, on the Commission Web interface. This is called the assignment of DALI devices.

---

<i>Note:</i>	<i>DALI channel and DALI group folders are already linked to the corresponding DALI channel or group. Thus, they do not require an assignment via the web-UI.</i>
--------------	---

---

##### To assign a DALI Device

1. On the Web interface go to the menu **Commission** and select the **DALI** technology.
2. The Web UI lists all DALI devices found in the configuration in the **Unassigned Devices** list (see Figure 209).

Channel 1 Channel 2 Channel 3 Channel 4

Wink duration: 30 sec Mains-Off handling: Disabled Mains-On delay: 600 ms Mains-Off delay: 0 min DALI Power: Off Manual Override: Auto Save Reload

Devices in Database (bus power usage assigned/total: 0/0 mA) Filter by name...

Action on Selected: Execute Reset

#	Name	Location	Type	Status	Serial No.	Short Addr.	Run Hrs	Nom. Pwr	Bus Pwr
No devices found									

Scanned Devices not in Database

Scan Clear Results Save Assignment

Name	Type	Serial No.	Short Addr.▲
Rescan necessary			

Unassigned Devices Filter by name...

Search

Name▲	Location	Type	Serial No.	Bus Pwr
<b>Lamps</b>				
Search	Lamp_Room303_1			
Search	Lamp_Room303_2			
Search	Lamp_Room303_3			
Search	Lamp_Room303_4			
<b>Sensors</b>				
Search	Multi-Sensor_Room303			
Search	Temp-Sensor_Room303			
Search	LDALI-MS2_Room303			
<b>Buttons</b>				
Search	Button_Room303_1			
Search	Button_Room303_2			
Search	LDALI-BM2_Room303			
Search	LDALI-MS2 buttons_Room303			

Figure 209: Unassigned DALI devices in configuration.

- Press the **Scan** button found above the **Scanned Devices not in Database** section.

16% - Found device: LDALI-MS1

4 lamps found (0 assigned, 4 unassigned).  
 0 sensors found (0 assigned, 1 unassigned).  
 0 buttons found (0 assigned, 0 unassigned).

Figure 210: DALI scan.

- After the scan of the DALI channel was completed, the devices can be assigned as described in the section *DALI Installation* in the LOYTEC Devices User Manual [1]. Assignment can be performed either using manual assignment (after devices were identified either via winking or via physical selection) or via the DALI Device Search Wizard.

Channel 1 Channel 2 Channel 3 Channel 4

Wink duration: 30 sec Mains-Off handling: Disabled Mains-On delay: 600 ms Mains-Off delay: 0 min DALI Power: Off Manual Override: Auto Save Reload

Devices in Database (bus power usage assigned/total: 0/0 mA) Filter by name...

Action on Selected: Execute Reset

#	Name	Location	Type	Status	Serial No.	Short Addr.	Run Hrs	Nom. Pwr	Bus Pwr
No devices found									

Scanned Devices not in Database

Scan Clear Results Save Assignment

Name	Type	Serial No.	Short Addr.▲
<b>Lamps</b>			
Wink Unassigned	LED device	1982081025	00
Wink Unassigned	LED device	1982081025	01
Wink Unassigned	LED device	1982081025	02
Wink Unassigned	LED device	1982081025	03
<b>Sensors</b>			
Wink Unassigned	LDALI-MS1	1073742080	L00
<b>Buttons</b>			
Unassigned	LDALI-BM1	1010090	L00
Wink Unassigned	LDALI-MS1 IRT	1073742080	L00

Unsigned Devices Filter by name...

Search

Name▲	Location	Type	Serial No.	Bus Pwr
<b>Lamps</b>				
Search Lamp_Room303_1				
Search Lamp_Room303_2				
Search Lamp_Room303_3				
Search Lamp_Room303_4				
<b>Sensors</b>				
Search Multi-Sensor_Room303				
Search Temp-Sensor_Room303				
Search LDALI-MS2_Room303				
<b>Buttons</b>				
Search Button_Room303_1				
Search Button_Room303_2				
Search LDALI-BM2_Room303				
Search LDALI-MS2 buttons_Room303				

Figure 211: Assigning DALI devices with manual assignment or using DALI Device Search Wizard.

# 16 Script Engine

## 16.1 Overview

The scripting feature on LOYTEC devices that provide it is based on a JavaScript engine and follows a strict event-based model known from the node.js model. The script engine allows users to implement custom protocols using RESTful APIs, JSON, Web services for IoT integration into the LOYTEC data point model. The dpal-js API gives JavaScript modules access to the data point server. Script modules are embedded into and deployed along with the data point configuration.

The device firmware is able to run script modules in a separate process. Each script module is based on a script resource that contains the JavaScript sources and other necessary files and libraries. This concept is similar to constructing an npm package of the node package manager (see [www.npmjs.com](http://www.npmjs.com)). A data point API allows the code working with data points.

The *script resource* can be considered as the “program source code”. It is packaged to the data point configuration and executed in the device. Data points in a script resource are referenced programmatically by using path and name, e.g. “/User Registers/reg1” or by browsing the data point folder tree. This results in a fixed assignment in the JavaScript code. Changing the data point references requires changing the code. This style of data point access is beneficial for global modules (e.g. a weather forecast module) or modules that can find all data pointy by smart browsing algorithms (e.g. MQTT implementation).




Figure 212: Explicit data point usage in a script resource.

An alternate way for referencing data points are so-called *script objects*. These are configuration objects similar to math objects that contain data point variables. A script object is based on a script resource (i.e. the JavaScript program) that implements a class interface, including an object constructor and some meta-data. The data points referred to in the script code are part of the object constructor and are accessed in the code as `v[1]`, `v[2]`, etc., instead of using an absolute path. The actual linkage to data points is made by the user who creates the script object in the data point configuration. The concept is depicted in Figure 213.

For each script object, an instance of the JavaScript object implemented by the referred script resource is created. For example, a script resource “myModule.js” implements the code and

exposes an object constructor. When creating to script objects Object1 and Object2 in the configuration, the constructor of myModule is called two times, creating two separate instances of the myModule object class. Each one of them with different data point references.




Figure 213: Concept of script objects and object instances.

Referencing data points by using script objects is beneficial for gateway applications, where certain functionality needs to be instantiated multiple times and data points are configured for each remote device. Another application of script objects are library components in L-STUDIO projects.

## 16.2 Script Resources

The LINX Configurator supports embedding a JavaScript program into the data point configuration. This is called a script resource, very much like an npm module. A separate dialog for managing script resources has been added, that keeps track of embedded scripts. Script resources are imported from the hard drive. There are two basic types of script resources:

- **Script file:** This is a single .js file that contains the JavaScript code in a single unit. Alternatively, a ZIP archive containing an archive of a script folder can be selected.
- **Script folder:** This represents a folder that contains a collection of files which constitutes the script resource. Similar to an npm module a main file has to be appointed. This can be implicit by naming convention (`index.js` or `foldername.js`) or explicit by looking into the `package.json`. The script management dialog reveals the `main.js` file in the expanded details as shown in Figure 214.

The script resource (folder or ZIP file) may also contain a data point configuration file. The user registers and favorites of that data point configuration are imported along with the JavaScript program. This is a convenient way to create those data points that are referred to programmatically by the script resource.




Figure 214: Manage script resources dialog

Once imported, the Configurator keeps track of changes to the script files on the source location. In the development cycle they are typically edited by a JavaScript IDE. When opening the dialog, it scans for newer files on the hard drive and marks them in the dialog as **new**. For library components the sources are typically not locally stored. They are marked by a green jigsaw 🧩.

Script resources managed by this dialog are deployed to the device. Each script resource is then instantiated on the device and executed by the script engine. Typically, a script resource will look for certain data points in the configuration to link its internal data objects to data points.

### To Add Script Resources

1. Go to the menu **Tools → Manage Script Resources**.
2. In the Manage Script Resources dialog select a **Category** (e.g. User) and decide which type of script resource shall be added.
3. Click on the plus button ➕ and choose either script resource file or folder.
4. If the script resource includes a data point configuration, the user registers and favorites are merged into the existing configuration. A dialog as shown in Figure 215 lists the merged data points and identifies any conflicts. Already existing data points are not overwritten.












Figure 215: Merging data points defined by script resource

5. When editing the script files on the hard drive, the sync status will be refreshed and displays **new** to indicate there is newer content not yet in the configuration. For library components that don't have local sources a green jigsaw  is shown.

Category	Name	Description	Sync	Status
▶ User	 uptime2.js	uptime2		
▶ User	 weather	weather		
▶ User	 on_change.js	on_change	<b>new</b>	

6. To embed the latest changes, select the line and click on the **Update content** button 
7. The script content will be downloaded to the device with the next data point configuration download.

### 16.3 Script Objects

Script objects provide an explicit way to link data points into the script resource. A script object can be instantiated like math objects in the Configurator and refers to an existing file script resource in the configuration. The variables are then linked to data points of the data point configuration. An example is shown in Figure 216.





Figure 216: Script object

### To Create a Script Object

1. Under the **Global Objects** folder, select the **Script Object Configuration** sub-folder.



2. Right-click and select **New Datapoint Script Object ...** from the context menu.
3. In the **Create New Datapoint Script Object** dialog enter a **Name** and optional **Description**.
4. Choose the file script resource by clicking on **Select Script....**
5. If the file script resource is valid the dialog shows the script's variable references starting v1, v2, etc.

---

*Note:* The script resource must be designed to work with script objects, i.e., contain a `metaData` element that specifies the script variables v1, v2, etc. If this element is missing, the script resource cannot be used in a script object.

---

6. Select the variable line and click the button **Attach DP...** to attach a data point to the script variable. Use **Detach DP** to remove a data point reference.

## 16.4 Developing Scripts

### 16.4.1 Data Point Integration

One of the primary functions of a script module is interfacing to the data point model on the device. For doing so, a script needs to require the `dpal-js` module that provides a JavaScript data point API:

```
var dp = require('loytec/dpal-js');
```

Data points can be accessed via data point objects that need to be created by path or UID:

```
var v1 = new dp('/User Registers/uptime');
var v2 = new dp(0x1150);
```



On the data point objects various methods are available to read, get notified or modify the data point value. Use the write method to write values onto a data point:

```
v1.write(20.5);
```

Or get event notifications on new values using the value event:

```
v1.on('value',(data) => { console.log('Value is' + data[0]) });
```

Operations on multiple data points can be done by the dp class methods. Reading multiple values from data points in one sweep is accomplished by calling the dp.readAll() class method:

```
dp.readAll([v1, v2, '/User Registers/someOtherDP'], (err, values) => {  
  console.log('Value is'+values[0]+' '+values[1]+' '+values[2])  
});
```

Another method to get notified about data point updates is to subscribe to all data points that are in a certain folder and its sub-folders:

```
dp.subscribeAll(['/User Registers/']).then((subscription) => {  
  subscription.cov.on('value',(data) => {  
    // iterate over all COVs; the object key represents the data point path  
    for (var key in data) {  
      var value = data[key][0];  
      // do something with the value  
    }  
  });  
});
```

A convenient way to write to multiple data points is the dp.writeAll() class method, that accepts a data point object, path or UID:

```
dp.writeAll([v1, 5], ['/User Registers/xyz', 47], [0x1150, true]);
```

Refer to the example scripts uptime.js, on\_change.js and weather.js to explore the basic data point API usage. These script resources can be found in the script examples folder of the Configurator program installation.

## 16.4.2 Using Libraries

Script resources may rely on third-party libraries that implement certain functionalities such as XML decoding or an implementation wrapper of a specific protocol. There are pre-installed library modules on a LOYTEC device that can be readily required in a script file:

- axios: Implement RESTful services
- debug: Enables debug output for a script
- xml2js: XML to JavaScript converter
- nodejs-websocket: utility to establish websocket communication

A script resource may also require other library modules. This can be accomplished by creating a script folder resource and add custom libraries local to this folder in its own 'node\_modules' sub-folder. This is compatible with installing npm modules locally in the script resource folder.

This is an example: The folder resource 'myProtocol' requires the custom 'express' and 'debug' modules. This is done by installing the 'express' npm locally to the 'myProtocol' folder. This library module will be placed into the 'node\_modules/express' sub-folder along with other dependent modules. An example is shown in Figure 217. The entire 'myProtocol' folder is then added as a folder resource to the Configurator.




Figure 217: Example for using local libraries

### 16.4.3 Write a Script Object Resource

Script resources that can be used by data point script objects need to follow certain rules. They must be a single file resource and implement an object constructor of a given style. For an example look at the code snippet below in Figure 218.

```

// script module for data point script object must export a constructor
module.exports = function(dpReferences) {
    const dp = require("loytec/dpal-js");

    // create dp objects from supplied dpReferences
    var v = dp.newVector(dpReferences);

    // uptime of script in seconds
    var uptime=0;
    setInterval(function() { uptime++; v[1].write(uptime); }, 1000);
    console.log("uptime2 script object instantiated");
}

```

Figure 218: Constructor for a data point script object.

The module exports the constructor function(dpReferences). Inside the constructor a data point vector is created by calling dp.newVector(dpReferences). This vector contains the data point access objects v[1], v[2], etc. as seen in the data point script object.

The module also needs to define a metaData object as shown in Figure 219. This object describes the variables used in the script object and their required data point class (e.g. analog or binary). This meta-data is evaluated by the Configurator when instantiating a new data point script object.

```

// meta data evaluated by Configurator for display in data point script dialog
const metaData = {
    "descr": "Uptime counter in sec",
    "v1": { "descr": "Script uptime", "otype": "analog" },
    "v2": { "descr": "Enable uptime", "otype": "binary" },
    "v3": { "descr": "Not used" }
};

```

Figure 219: Script object meta-data

Finally, the meta-data object needs to be added to the module exports at the end of the file:

```

/* export metaData */
module.exports.metaData = metaData;

```

### 16.4.4 Serial Port

The JavaScript resource can use the pre-installed serial port module to access the device's serial port. The API of the internal serial port module is compatible with the serialport npm. Please refer to the SerialPort API description on how to program for the serial port in JavaScript. The remainder of this section describes the differences to the standard module.

To include the built-in serial port module use the following line as well as the system API:

```
var SerialPort = require('loytec/serialport');  
var system = require('loytec/system');
```

The script resource must define meta-data that describes some properties of the serial implementation. The protocolInfo element is required to display a custom serial protocol on the device's Web interface as shown in Figure 220. The fields 'name' and 'info' are shown on the Web interface, 'key' is an internal identifier for the protocol.

```
const metaData = {  
  "descr" : "DMX Protocol",  
  "vl": { "descr": "Address of the DMX device", "otype": "Analog"},  
  "protocolInfo" : {  
    "key" : "dmx",  
    "type" : "rs485",  
    "opts" : [ "serial", "any" ],  
    "name" : "DMX",  
    "info" : "This protocol supports DMX on RS-485.",  
  }  
};
```

Figure 220: Script object meta-data for a serial protocol

For a script resource having the protocolInfo as part of its meta-data, a selection for the protocol is added to the Web interface as shown in Figure 221.




Figure 221: Custom protocol selection on the Web interface.

Depending on the protocol selection on the Web interface, the script resource module must determine, whether it can use the serial port or not. This is done by using the system.serialEnumerate() API. Employ the code pattern shown in Figure 222 to bootstrap opening the serial port.

```

system.serialEnumerate(metaData.protocolInfo, (err, ports) => {
  if (err) return debug(err);
  if (ports && ports.length > 0) {
    console.log('DMX starting on ${ports[0].port}');
    port = openPort(ports[0].port);

    port.on('error', function(err) {
      debug(err.message);
    });

    port.on('open', () => {
      scheduleNextSend();
    });
  } else {
    console.log('DMX not starting, no port found');
  }
});

```

Figure 222: Code pattern to bootstrap the serial port

Note, that the custom serial protocol may be enabled on more than one serial port, if the device has more than one serial port. In this case, the length of the ports vector is larger than one. In the above example we initialize the protocol to run on the first port available.

### 16.4.5 Open Ports in the Firewall

A script module may need to implement a service that runs under a specific TCP or UDP port, e.g. an HTTP server on TCP port 4000. This port is normally blocked by the firewall on the LOYTEC device. In order to open a port use the system module and the following code pattern:

```

const system = require('/loytec/system');
// allow a port in the firewall
system.firewallAllow({ protocol: 'tcp', port: 4000 }).then((rule) => {
  console.log(`opened port ${rule.port} in firewall`);
}).catch((e) => {
  console.log(e);
});

```

### 16.4.6 Prototyping

Normally, script resources are deployed by the Configurator software. This is a streamlined solution for the end user but not very practical when prototyping a script implementation. To do a simple test of a script resource, the script files can be placed on the device as *unmanaged* scripts.

Managed script resources are located in a sub-directory named just like the scope name, e.g. “User” in ‘/var/lib/node\_app/User’ on the device. This folder is managed by the Configurator and its contents will be overwritten with each deployment. A prototype script can be placed into the unmanaged folder ‘/var/lib/node\_app/unmanaged’ using a file manager that can transfer over SSH (e.g. WinSCP).

If no such tool is available or SSH is blocked by a firewall, one can use the transfer functions of the script configuration Web interface (see Figure 223). The scripts need to be stopped first.






Figure 223: Transfer prototype script resources on the Web interface.

Click the **Upload** button in the **Upload unmanaged module** section to load an unmanaged script resource onto the device. If the script is a file resource, simply select the .js file. If the script is a folder resource, you need to ZIP the folder first, then upload the .zip file. The folder on the device is named after the .zip filename.

To retrieve the JavaScript code of a script resource from the Web interface, click on the save to disk button  of the desired module. To delete a script resource from the device click on the delete button .

### 16.4.7 Debugging

Script resources on the LOYTEC device are automatically started when the device boots up. In order to debug a script, it is necessary to stop the running scripts and start them in a debug mode. This can be accomplished on the Web interface on the device. Use the **Stop** button as indicated in Figure 224. Note that the console log persists till the next start.




Figure 224: Stop the script and start in debug mode

To debug click the **Debug** button and wait till the script debugger URL for Google Chrome is printed on the Web UI as shown in Figure 225.





Figure 225: Debug URL for Google Chrome inspector

Copy this URL to Google Chrome and wait for Chrome to connect. Then click the GO button  to start the script. Use Chrome DevTools debugging techniques as for Web pages. When debugging it is useful to turn auto-respawn of scripts off. In this case the root cause of an uncaught exception is easier to find. For doing so, deselect the check box **Respawn scripts when exited**.

Another debugging technique is to use console.log() output and observe the output in the node.js Web UI log window. An example is shown in Figure 226.




Figure 226: Example console output generated by a script

A more advanced method to output debug or log information that is separated by module is to use the debug module in the script:

```
const debug = require('debug')('dmx');  
debug('Starting protocol');
```

The code to print these messages can be left in a production script resource. The output of the messages can be enabled on the script Web interface by specifying the debug keyword, e.g. 'dmx' as shown in Figure 227. The script has to be stopped and the keyword needs to be saved by clicking **Save Settings**.




Figure 227: Configure a debug keyword to enable module messages.

## 16.5 Prototyping on the PC

### 16.5.1 Set up a Project

For fast prototyping, the script can be developed on the PC and executed on the PC. For doing so, install node.js on the PC as well as a suitable JavaScript IDE. A good example is Visual Studio Code that has a built-in method to start and debug node.js scripts within the IDE.

Since the script will eventually be running on the LOYTEC device, a number of things need to be considered. We assume the development directory on the PC is 'C:\work' and a LOYTEC device exists under the IP 192.168.2.150. For prototyping on the PC, explicit data point access via data point path or by browsing is mandatory and a matching data point configuration is loaded onto the device. Instances via script objects are not possible, because the data point configuration is not local on the PC.

### To Create a Prototype Project

1. Set up the pre-installed device libraries: Copy the libraries from the LOYTEC device '/var/lib/node\_modules' to 'C:\work\node\_modules' using WinSCP.
2. Create a folder 'C:\work\user' to hold your developed script resources. In that user directory create a file called 'dpal-host.json' and edit it to define your device connection (assuming the default operator password):

```
{ "host": "192.168.2.150", "port": "443" }
```

3. Create a module directory, e.g. 'C:\work\user\myModule'. In that directory start your script project with an index.js file.
4. Set up the required data point configuration on the LOYTEC device.
5. Start a new Visual Studio Code project from 'C:\work\user\myModule'. Use **File → Open Folder ...** and choose the project folder.
6. Install any npm packages required by your project into the myModule directory, resulting in a 'C:\work\user\myModule\node\_modules' directory.

Eventually the folder 'C:\work\user\myModule' can be zipped into an archive 'myModule.zip'. That archive is ready to be imported as a script resource in the LINX Configurator for distribution.


## 16.5.2 Setting up an Attach Configuration in Visual Studio Code

Visual Studio Code provides an excellent environment for developing node.js applications on the PC. In order to start a debug session in your project, an attach configuration needs to be added.

The attach option requires more work compared to an auto-attach configuration but allows configuring various debug configuration options explicitly on the command line. The simplest "attach" configuration looks like this:

```
{
  "name": "Attach to Process",
  "type": "node",
  "request": "attach",
  "port": 9229
}
```

The port 9229 is the default debug port of the --inspect-brk command line options. To use a different port (e.g. 12345), add it to the options like this: --inspect-brk=12345 and change the port attribute in the launch configuration accordingly.

Then start the node application in the Visual Studio Code terminal: node --inspect-brk index.js as indicated in Figure 228. The node app is then launched and waits for the debugger to connect. Then attach Visual Studio Code to the process using the attach configuration by clicking on .




Figure 228: Launch a node app in Visual Studio Code

For a full reference on how to debug node.js apps please refer to the Visual Studio Code documentation Chapter NODE.JS/JAVASCRIPT, Section Node.js Debugging.



# 17 File Formats

---

## 17.1 Data Point CSV File

The data point CSV file (.dpcsv) is the flexible format for editing data point properties and for creation of data points from a list of data point templates. The first lines of the file must contain a comment, starting with a hash character '#' specifying a number of meta-information. The last comment line specifies the columns used by the template CSV file:

```
#LOYTEC data point CSV
#creator: LOYTEC LINX Configurator 6.0 Mar  3 2016 17:26:16
#config:
#date: 2016-03-04 15:33:33
#dp_csv_ver: 1
#target: User Registers
#UID;IdPath;Name;Description;FullPath;DataType;Path;Direction;PlcIn;PlcOut
```

After that line any number of comment lines starting with the hash character '#' are allowed. Lines that are not comments specify a data point to be modified or created, using the column name as the respective data point property name. The most important properties are described in Table 17. The columns are separated by commas ',' or semi-colons ';'.

When importing a data point CSV file, each line is evaluated whether an edit or a create operation shall be executed. An edit is done if a value in an identifier column (UID, IdPath) exists. That value identifies an existing data point. The remaining columns are then written to the respective properties of the data point.

If no data point is identified, the data point is created under the specified 'Path' and 'Name'. The path is relative to the location where the import was started (i.e. if the import was started on the folder 'User Registers.Room1' then the path is relative to 'User Registers.Room1'. For creating a data point, additional property columns must be specified, depending on the technology. The import result will be displayed in a log file, which states missing information.

Alternatively, a data point template file (.dptmpl) may be specified in the 'TemplateFile' column, which contains all the information to create a data point of a given technology (e.g., a BACnet server object or a user register with an alarm condition). The file paths of the referenced data point template XML files are relative to the location of the data point template CSV file.

Column	Field	Example	Description
A	UID	0x10dd	This is a key column and references an existing data point by its unique ID.
B	IdPath	User Registers.reg1	This is a key column and references an existing data point by its full path.
C	Path	Floor1.Room101	The path under which the data point shall be created. The path is relative to the folder on which the import/export was executed-
D	Name	RoomTemp	The name of the data point to be created. For structured data points, this is the name of the top-level data point. This name overrides the name of the template data point.
E	Description	Room Temperature	Optional description used in the data point. This overrides the description in the template data point.
F	PlcIn	1	Set the PLC in flag ('1') or clear it ('0') on the created data point. This overrides the PLC setting of the template data point. If left empty, the PLC setting of the template data point is used. For structured data points this setting is ignored.
G	PlcOut	0	Set the PLC out flag ('1') or clear it ('0') on the created data point. This overrides the PLC setting of the template data point. If left empty, the PLC setting of the template data point is used. For structured data points this setting is ignored.
H	Opc	1	Set the OPC flag ('1') or clear it ('0') on the created data point. This overrides the OPC setting of the template data point. If left empty, the OPC setting of the template data point is used. For structured data points this setting is ignored.
I	Trend	1	If this field is '1' the created data point is trended in a generic trend. The user can override this decision to use another trend technology during the import.
J	Schedule	1	If this field is '1' the created data point is scheduled by a generic scheduler. The user can override this decision to use another scheduler technology during the import.
K	TemplateFile	TempBACnet.dptmpl	The data point is created from this data point template. The location is relative to this CSV file.

Table 17: CSV columns of the data point template import file.

The data point CSV file may be further divided into sub-sections, which define the target technology of the data points. A section is started with a comment line `#target` followed by the data point root folder of that technology. For example, the CEA-709 section is started by:

```
#target: CEA-709 Port
```

All data point CSV lines following this comment are destined for the CEA-709 Port folder and its sub-folders. This is especially important, if data points of multiple technologies shall be created by a single data point CSV file. When importing from a different root folder, all target sections of other root folders are skipped.

## 17.2 CEA-709 NV Import File

Network variables can be imported to the Configurator software in a CSV file. The format of this file is described in this section.

The first line of the file must contain a comment, starting with a hash character '#' specifying the format version and import technology:

```
#dpal_csv_config;Version=1;Technology=CEA709
```


After that line any number of comment lines starting with the hash character '#' are allowed. Lines that are not comments specify one NV per line, using the column information as described in Table 18. The columns are separated by commas ',' or semi-colons ';'. Which separator is used can be configured in the system settings (see Section 4.3.3).

Column	Field	Example	Description
A	SNVT	39	A numeric value of the SNVT (as defined in the SNVT master list). The example value 39 represents a SNVT_temp.
B	NV index	0	The NV index in decimal notation of the NV on the network node. Index starts at 0.
C	NV selector	1	The NV selector in decimal notation of the NV on the network node.
D	NV name	nvoTemp	The NV programmatic name of the NV on the network node.
E	is output	1	Defines if this NV is an output on the network node. '1' means the NV is an output on the network node.
F	flag auth cfg	1	'1' defines that authentication can be configured for this NV on the network node.
G	flag auth	0	'1' defines that the NV is authenticated.
H	flag priority cfg	1	'1' defines that the priority can be configured for this NV on the network node.
I	flag priority	0	'1' defines that the NV is using priority.
J	flag service type cfg	1	'1' defines that the service type can be configured for this NV on the network node.
K	flag service ack	1	'1' defines that the NV is using acknowledged service.
L	flag polled	0	'1' defines that the NV is using the polled attribute
M	flag sync	0	'1' defines that the NV is a synchronous NV.
N	Deviceref	1	This field is a numeric reference to a device description. If it is the first occurrence of this reference in the file, the columns defined below must be filled in. Otherwise, they can be left out.
O	programID	9000A44850060402	The program ID string of the network device.
P	neuronID	80000000C8C8	The NID of the network device.
Q	Subnet	2	The subnet address of the network device. Use '0' if the device has no subnet address information.
R	Node	3	The node address of the network device. Use '0' if the device has no node address information.
S	location str	0	The location string of the network device. Use '0' if no information is available.
T	Device name	DDC	The device name of the network device. Leave this field blank if this information is not available.
U	node self-doc	&3.2@0,2	Self-documentation string of the device (special characters are escaped)
V	NV length	2	NV length in bytes
W	NV self-doc	@0 4	NV self-documentation string (special characters are escaped)

Table 18: CSV Columns of the NV Import File.

## 17.3 Terminal Configuration File

The terminal configuration file can be used to configure the I/Os of L-IOB devices in a L-IOB host project. The CSV file defines one I/O per line and contains the following columns:

- a. Bus: either “LIOB” or “LIOB-FT”. If the field in this column starts with “#”, the whole line is ignored. This can be used e.g. for a column header line or other comment lines in the CSV file.
- b. Station ID: station ID of the L-IOB device (1-8) within the bus.
- c. Device Template: file name of the device template, e.g. “liob100.xml”.
- d. Device Name: user defined name of the device, e.g. “LIOB\_Heating”.
- e. NID: specifies the Node ID of the device if already known. Otherwise, the field is left blank.
- f. Terminal: the terminal identifier as listed in the column “Terminal” of the **Inputs / Outputs** list, e.g. “UI1”.
- g. Terminal Name: user defined name of the I/O, e.g. “Temperature A”
- h. Terminal Template: file name of the terminal configuration (which was stored using **Export object to disc** ) , e.g. “Humid\_Sensor.xml”.
- i. Description: user defined description of the I/O.
- j. Favorite Name: optional name of a data point in the folder “Favorites”. If this column entry exists for an I/O, an additional data point (input or output value) in the “Favorites” folder of the L-IOB host will be created.
- k. OPC: specifies if the Favorite data point shall be OPC exposed (‘true’) or not (‘false’).
- l. PLC In: specifies if the Favorite data point shall be exposed as a logic program input data point (‘true’) or not (‘false’).
- m. PLC Out: specifies if the Favorite data point shall be exposed as a logic program output data point (‘true’) or not (‘false’).

An example of such a CSV file is shown here:

```
#Bus;St.ID;Dev.Template;Dev.Name;NID;Terminal;Term.Name;Term.Template ;Description;FavoriteName
LIOB;1;liob100.xml;LIOB_Heating;;UI1;TempA;NTC.xml;TempRoomA;FavTA;true;false;false
LIOB;1;liob100.xml;LIOB_Heating;;UI2;TempB;NTC.xml;TempRoomB;FavTB;true;true;false
LIOB;2;liob100.xml;LIOB_Cooling;;UI1;HumidA;Humid_Sensor.xml;HumidRoomA;FavHA;false;false;false
LIOB;2;liob100.xml;LIOB_Cooling;;UI2;HumidB;Humid_Sensor.xml;HumidRoomB;FavHB;false;true;false
LIOB-FT;1;liob150.xml;LIOB_Shades;;AO1;MotorUp;Motor.xml;MotorUpDirection;FavMU;false;false;false
LIOB-FT;1;liob150.xml;LIOB_Shades;;AO2;MotorDn;Motor.xml;MotorDnDirection;FavMD;true;true;true
```

The terminal configurations “NTC.xml”, “Humid\_sensor.xml”, and “Motor.xml” would have to be present in the same folder as the CSV file. The file would e.g. look like this in MS Excel:

	A	B	C	D	E	F	G	H	I	J	K	L	M
1	#Bus	St.ID	Dev.Template	Dev.Name	NID	Terminal	Term.Name	Term.Template	Description	FavoriteName	OPC	PLCIn	PLCOut
2	LIOB	1	liob100.xml	LIOB_Heating		UI1	TempA	NTC.xml	TempRoomA	FavTA	true	false	false
3	LIOB	1	liob100.xml	LIOB_Heating		UI2	TempB	NTC.xml	TempRoomB	FavTB	true	true	false
4	LIOB	2	liob100.xml	LIOB_Cooling		UI1	HumidA	Humid_Sensor.xml	HumidRoomA	FavHA	false	false	false
5	LIOB	2	liob100.xml	LIOB_Cooling		UI2	HumidB	Humid_Sensor.xml	HumidRoomB	FavHB	false	true	false
6	LIOB-FT	1	liob150.xml	LIOB_Shades		AO1	MotorUp	Motor.xml	MotorUpDirection	FavMU	false	false	false
7	LIOB-FT	1	liob150.xml	LIOB_Shades		AO2	MotorDn	Motor.xml	MotorDnDirection	FavMD	true	true	true

# 18 Application Notes

---

## 18.1 The LSD Tool

Please refer to application note “AN002E LSD Tool” for further information about the LOYTEC system diagnostics tool for the CEA-709 device models.

---

## 18.2 Use of Static, Dynamic, and External NVs on a Device

Please refer to application note “AN009E Changing Device Interface in LNS” for more information on the static NV interface, XIF files, device templates and the use of static, dynamic, and external NVs on LOYTEC gateway products.

# 19 References

- [1] LOYTEC Device User Manual 7.0, LOYTEC electronics GmbH, Document № 88086506, May 2019.
- [2] LIOB-10x/x5x User Manual 6.2, LOYTEC electronics GmbH, Document № 88078511, April 2017.
- [3] L-DALI User Manual 6.4 LOYTEC electronics GmbH, Document № 88077114, May 2018.
- [4] LWEB-802/803 User Manual 3.0, LOYTEC electronics GmbH, Document № 88074219, April 2018.
- [5] LWEB-900 User Manual 2.2, LOYTEC electronics GmbH, Document № 88081507, June 2017.
- [6] L-VIS User Manual 6.2, LOYTEC electronics GmbH, Document № 88068522, August 2017.

# 20 Revision History

Date	Version	Author	Description
2016-03-23	6.0	STS	Initial revision of the LINX Configurator User Manual.
2016-10-19	6.1	STS	Updated for 6.1 release. Updated 4.2.3 Data Point List – configure columns. Section 4.12.1: description on how to remove historic filters. Updated Section 5.1.1 CEA-709 Settings. Added Section 5.4.7 Incremental Scans. Updated Section 6.3.1 Scan for BACnet Objects by incremental scan. Added Section 10.2.4 LSMT-804 and power-on data points. Added Chapter 12 MP-Bus.
2017-04-24	6.2	STS	Updated for 6.2 release. Section 3.1.9 Added Sun Azimuth, Sun Elevation system registers. Section 3.4.6 specified tolerance interval for historic filters. Section 3.7.1 BACnet client supports unsolicited COV. Section 10.1.3 Document SNVT_setting behavior in SMI. Section 10.2.4 describe how to deactivate SMI power-off feature.
2017-12-20	6.3	JB, STS	Updated for 6.3 release. Section 3.1.9 Documented voltage reading with AC power. Section 4.8.3 Added table on alarm state triggers. Chapter 15: DALI-2 support.
2018-05-15	6.4	STS, JB	Updated for 6.4 release. Added Section 3.15.7 Run hours for inputs. Documented calendar and scheduled event limits in Sections 3.4.3, 3.6.4, 3.7.3. Updated Section 4.15.3 on digital interpretation of analog UI. Updated Section 7.3 regarding multiple M-Bus ports. Updated Section 8.2.1 Modbus device management dialog. Updated Section 8.2.3 Online test for commission-later devices. Added Chapter 16 Script engine. Added description of DALI workflow for programmable controllers. Added description of new DALI colour picker.
2019-05-15	7.0	STS	Updated for 7.0 release. Added Section 1.3 Crash dump disclaimer. Added Section 4.1.4 Language Setting. Section 4.3.1 documented project ID in system setting. Section 3.1.12 documented msgXXX relations for alarm messages. Section 3.4.1 Added description of alarm text placeholders and new % {bacName}, % {bacDescr}. Described "Comm. Val" placeholder for feedback alarm condition. Section 6.3.2 documented IEIEJ import feature. Section 6.3.4 documented new COV unsolicited + Poll option and EventNotification behavior. Section 7.1.6 M-Bus Device Capabilities Read RAM/EEPROM. Section 16.1 Describe concept of script resource and script object. Added Section 16.4.4 serial port programming. Added Section 16.4.5 Open Ports in the Firewall. Added Section 16.5 Prototyping Scripts on the PC.