

Document 88071601
10/2006
Printed in Austria
Data is subject to change




LOYTEC
<http://www.loytec.com>
support@loytec.com

NIC709-IP NIC709-IPxE100 EIA-709/IP Interface

Installation instructions

Instructions de montage
Montageanweisung
Montagevoorschrift

Istruzioni di montaggio
Instrucciones de montaje
Monteringsanvisning



Document 88071601
10/2006
Printed in Austria
Data is subject to change


LOYTEC
<http://www.loytec.com>
support@loytec.com





NIC709-IP NIC709-IPxE100 EIA-709/IP Interface

Installation instructions

Instructions de montage
Montageanweisung
Montagevoorschrift

Istruzioni di montaggio
Instrucciones de montaje
Monteringsanvisning





Status LEDs	
B	GREEN flashing fast RED permanent RED flashing fast
C	GREEN GREEN flashing ORANGE RED
D	GREEN
E	GREEN flashing
G	GREEN
H	OFF RED flashing RED

Connectors	
4	EIA-709 input EARTH GND port 1
5	EIA-709 input B port 1
6	EIA-709 input A port 1
8	Ethernet 10/100 BaseT (RJ45)
15	Power supply input earth ground
16	Power supply input MINUS
17	Power supply input PLUS
40	RS-232 interface (DB9 male)

Buttons	
a	Reset
b	Press to identify in L-Config tool

Status LEDs	
B	GREEN flashing fast RED permanent RED flashing fast
C	GREEN GREEN flashing ORANGE RED
D	GREEN
E	GREEN flashing
G	GREEN
H	OFF RED flashing RED

Connectors	
4	EIA-709 input EARTH GND port 1
5	EIA-709 input B port 1
6	EIA-709 input A port 1
8	Ethernet 10/100 BaseT (RJ45)
15	Power supply input earth ground
16	Power supply input MINUS
17	Power supply input PLUS
40	RS-232 interface (DB9 male)

Buttons	
a	Reset
b	Press to identify in L-Config tool